



PM1说明书  
尺寸：65\*70MM


TOZO®


EN

1.0 Product Description









2.0 Specifications

Battery Capacity	560mAh
Input	5V= 570mA
Impedance	2Ω±15%
Frequency Response Range	150Hz-20KHz±5dB

TOZO®

EN

3.0 Magnetic Clip

1. Pinch the back clip to open it, and attach the speaker to your chest pocket, collar, or anyother suitable spot you prefer.

2. The speaker's back clip features a built-in magnet, allowing it to be easily attached to metal surfaces or poles made of iron.

4.0 About Bluetooth

Bluetooth connection:

After powering on, the red and blue lights will flash alternately. Open your phone's Bluetooth settings, search for available devices, and select "TOZO PM1" to connect. Once connected, the white light will remain steady.

Disconnect Bluetooth:

While connected via Bluetooth, double-tap the Volume + and - buttons simultaneously to disconnect the current connection and re-enter pairing mode.

Refresh Bluetooth:

When powered on but not connected, double-tap the play button to refresh the Bluetooth signal, making it easier for your phone to detect the speaker.

TOZO®

EN

5.0 Key Function Guide

X1: Press once X2: Press twice Hold: Press and hold

Hold

Power on/off

Long press 2 second to power on; Long press 2 second to power off.

X1

Play/Pause

In music mode: Switch between play/pause.

X1

Answer/Hang up

In phone mode: Short press play key answer/hang up call.

Hold

Reject

In phone mode: Long press >1 second to reject the call.

X1

Volume up

Short press to increase the volume by 1 step (total 16 steps)

Hold

Next song

Long press 1.5 second to switch to the next song.

TOZO®

EN

6.0 Voice Assistant

1. When the speaker is powered on and connected to your phone via Bluetooth, double-tap the play button to activate Siri or the AI voice assistant. (Note: The AI voice assistant feature requires setup within the app.)

2. When the voice assistant function is enabled, press and hold the button for 2 seconds to exit the voice assistant function.

3. Note that some Android phones may not support this button mode.

7.0 Charging

1. When the Type-C charging cable is plugged in, the speaker's power indicator will show a steady red light while charging. Once fully charged, the indicator will turn to a steady white light.

2. When the speaker has a low battery, the charging indicator light will flash slowly (on for 500ms, off for 500ms) along with a beeping sound.

TOZO®

EN

8.0 TOZO APP

Download the TOZO App for UI customization, EQ settings and more.

• EQ settings: There're lots of EQ settings you can choose in the App to optimize your experience while enjoying different music genres.

• Earbuds firmware update: The earbuds firmware can be updated in the App. You will be informed once the new version of firmware is detected when you connect the earbuds with the App.

9.0 TOZO APP Pairing


Step 1:


Download the TOZO App on your phone.

Q TOZO

Download on the App Store


GET IT ON Google Play






Step 2:

Bluetooth pairing with your speaker.







TOZO®


EN

Step 3:

TOZO App pairing with your speaker.







2.5-5.0 W

The power delivered by the charger must be between min 2.5 Watts required by the radio equipment, and max 5.0 Watts in order to achieve the maximum charging speed.

CE

RoHS

CE


REACH

RoHS

REACH

Thank you for purchasing the TOZO authentic product. For more latest products, parts and accessories, please visit: [www.tozostore.com](http://www.tozostore.com) For any assistance please contact Email: [info@tozostore.com](mailto:info@tozostore.com)

Scan the QR code to get the manual in other languages



TOZO®

EN

10.0 Solutions to Common Problems

If there is a problem with the speaker.

• Power on the speaker.

• Check the status of the status indicator.

• Make sure the mobile device supports Bluetooth technology.

• Charge the battery.

• Turn up the volume on the speaker, device, and music app.

• If necessary, the product can be restored to the factory settings.

• Move the device closer to the speaker and away from other distractions or obstructions.

If you cannot solve the problem, see the table below for symptoms and solutions to common problems.

If you are still unable to resolve the problem, please contact TOZO Customer Service. Please visit: [www.tozostore.com](http://www.tozostore.com)

Symptoms	Solutions
Not powered (battery)	The battery may be in protection mode or the battery may be fully discharged. Connect the speaker to the wall charger.
Speakers cannot be connected to mobile devices	On your device. 1: Disable and reactivate the Bluetooth function. 2: Remove the speaker from the Bluetooth list on your device. 3: Clear the pairing list of the speaker. Connect again. ected to mobile devices.

TOZO®

EN

Nosound

1: Make sure the voice prompt is on, press the Bluetooth button and listen to the connected device.

2: Make sure you are using the right device.

3: Please use another music source.

4: If two devices are connected, pause the audio on the first device and then play the audio on the other device.

5: If two devices are connected, move the device to within speaker range (within 10m)

Poor sound quality

1: Please use another music source.

2: Disable any audio enhancements on your device or music app.

3: If the speakers have been in contact with water, let them dry and try again.

Speaker cannot be charged

1: Make sure the connector of the cable is properly aligned with the connector on the speaker.

2: Try another charging source.

3: Secure both ends of the USB cable.

4: If your speaker has been exposed to high or low temperatures, wait for it to return to room temperature, then retry charging

11.0 FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

TOZO®

EN

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

• Reorient or relocate the receiving antenna.

• Increase the separation between the equipment and receiver.

• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

• Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.  
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

12.0 EU Battery Regulation

This symbol on the battery(ies) or on the packaging indicates that the battery(ies) provided with this product shall not be treated as household waste. Instead, please separate battery(ies) from other types of waste and recycle it/them through your local recycling system to protect environment and health. (When Cd is more than 20ppm or Pb is more than 40ppm, the chemical symbol of the excess substance shall be marked under the separate collection symbol) For more detailed information about recycling of this battery(ies), please contact your local authority or the shop where you purchased the product or battery(ies)

TOZO®

EN

13.0 ISED Compliance Statements

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:  
(1) This device may not cause interference.  
(2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:  
(1) L'appareil ne doit pas produire de brouillage;  
(2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment.  
This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Cet équipement est conforme aux limites d'exposition aux radiations IC CNR-102 établies pour un environnement non contrôlé. Cet émetteur ne doit pas être colocalisé ou fonctionner en conjonction avec une autre antenne ou un autre émetteur.


14.0 CE-DOC

Hereby, [Manufacturer] declares that the radio equipment type [Model No.] is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address: [www.tozostore.com](http://www.tozostore.com)

TOZO®

www.tozostore.com



User Manual

PDF  
Adobe