

Figure 11
Inside of the EUT



Figure 12
Inside of the EUT




Figure 13
Inside of the EUT




Figure 14
Inside of the EUT




Figure 15
Inside of the EUT




Figure 16
Inside of the EUT



Figure 17
Inside of the EUT




Figure 18
Inside of the EUT




Figure 19
Inside of the EUT




Figure 20
Inside of the EUT




Figure 21
Inside of the EUT




Figure 22
Inside of the EUT




Figure 23
Inside of the EUT




Figure 24
Inside of the EUT




Figure 25
Inside of the EUT




Figure 26
Inside of the EUT




Figure 27
Inside of the EUT




Figure 28
Fan




Figure 29
Fan




Figure 30
Frontside of the Main Board




Figure 31
Frontside of the Main Board




Figure 32
PCB of the EUT




Figure 33
PCB of the EUT




Figure 34
PCB of the EUT





Figure 35
Adapter**Figure 36**
Adapter

Figure 37
Label of the Adapter

