

P900 : QSG

12/03/2014

Polaroid 9" Tablet & Wireless Keyboard

Quick Start Guide
Model : P900

In the box

- 9" Tablet
- Case
- Quick Start Guide
- Bluetooth® Wireless Keyboard
- Tablet Stand
- AC Adapter
- USB Cable
- Headphones

Buttons, ports & hardware

Front: 1. Power Button, 2. Home Button, 3. Micro USB port, 4. Headphone Jack, 5. DC Input, 6. Micro SD Card Slot, 7. Mini HDMI, 8. Microphone, 9. Front Camera, 10. Rear Camera, 11. Speaker

Back: 1. Power Button, 2. Home Button, 3. Micro USB port, 4. Headphone Jack, 5. DC Input, 6. Micro SD Card Slot, 7. Mini HDMI, 8. Microphone, 9. Front Camera, 10. Rear Camera, 11. Speaker

Google Play™

Google Play lets you store up to 25,000 songs for free and download new songs. It's home to 100,000 Android™ apps and games. It houses the world's largest selection of eBooks. It's where you can watch thousands of movies including new releases and HD Blu-ray. It's how you buy and download digital entertainment on your Android device and any other Internet-capable device.

To take advantage of these features, download or set up a Google™ account. This can be done in the setup wizard the first time you power on the tablet.

Play Store

Charging the tablet

Connect the tablet to a wall outlet using the included AC adapter as shown below.

Tablet (Top view)

Power ON / OFF

Turning on the tablet
Press and hold the On/Off button until the startup screen appears.

Power off the tablet
Press & hold the On/Off button until the "Power off" options appear.

Lock the tablet (standby)
Briefly press the On/Off button. Lock the tablet to conserve the battery.

Unlock the tablet
Briefly press the On/Off button, and slide the "Lock icon" to the right.

Lock icon

Startup screen

Lock screen

Home screen

WiFi and Bluetooth®

To setup WiFi or connect the tablet to a Bluetooth-enabled device, slide down on the top right of the Home screen as shown below.

Slide down

Using the wireless Bluetooth® keyboard

Charging the keyboard
You can charge the Bluetooth Keyboard by connecting it with included USB cable to a PC.

Turning the keyboard on / off
Slide the switch as shown above, the indicator light will briefly turn on.

Pair button

Pairing the keyboard to the tablet

1. Turn on the keyboard.
2. Press the "Pair" button, the Bluetooth indicator light will blink and the keyboard is ready to pair with the tablet.
3. On the tablet, go to Settings > Bluetooth, turn on Bluetooth, and select "Bluetooth Keyboard".
4. Using the keyboard, type the password shown on the tablet and press enter.
5. After pairing successful with the tablet, "Bluetooth Keyboard Connected" is displayed.

Use the included tablet stand with your wireless keyboard.

Home screen

Apps appear when connecting the tablet to a PC.

Home screen (horizontal view)

Notifications, Date, Drive, Settings, Volume, Previous, Home, Multiple, Volume +

Apps screen

Apps screen (vertical view)

To add a widget, press and hold anywhere on the home screen, select the Widgets option as shown below.

Widgets

Press and hold Widgets to place them on the Home screen.

Micro SD card

Inserting a Micro SD card
The tablet supports Micro SD cards up to 64GB (not included). To install a Micro SD card into the tablet, insert the card as shown below into the card slot and push it back into the slot. To remove the Micro SD card, gently press it inward to eject.

Micro SD slot

Tablet (Back view)

Specifications

- Operating System: Android™ 4.4 (KitKat®)
- Processor: Quad-Core
- Display: 9" (1024X600)
- Cameras: Front + Rear
- Speaker: Built-in
- Internal Memory: 8GB*
- External Memory: Micro SD
- Networking: WiFi (802.11 b/g/n)
- Connectivity: WiFi & Bluetooth®
- Battery: Rechargeable Li-ion Polymer

HDMI®

You can connect the tablet to an HD display with a mini HDMI to HDMI cable (not included).

To connect:

1. Connect the mini end of the HDMI cable to the HDMI port of the tablet.
2. Connect the other end of the HDMI cable to the HDMI port of the TV or display.
3. Select the correct input on your TV or display.
4. The tablet display is now shown on your TV or display.

Tablet (Bottom view)

HD video out

HDMI cable (not included)

*Actual internal memory may vary depending on the operating system of the device and the pre-installed apps.

Legal information

Limited warranty

