


Manufacturer Name: ShenZhen YunJi Intelligent Technology CO., LTD Manufacturer Address: A-side A2 Building 2/F Enet New Industrial Park,No.2 Industrial Zone, Aobei Community, GuanLan, LongHua New District, ShenZh




0



Comes with the GoogleTM app and Google ChromeTM . Android is a trademark of Google LLC

EN



Comes with the Google™ app and Google Chrome™ . Android is a trademark of Google LLC

How to boot

Non-removable battery Press the power button for 3-5 seconds to boot

How to send SMS, MMS

SMS

- · Open the SMS app
- Select New Information
- · Enter a phone number or browse your contacts
- · Select Edit Information and enter your text
- Send ≽

MMS-video

- · When writing a text message
- Select images, videos, or other files you want to add, even you can take a new picture or video right away
- Selecting or sending

4 Language switching settings

- Main menu-settings system-language and input method Language and input method-language-language adding
- · Select the language you need, the system will automatically
- · jump back to the language interface
- · Select the icon after the language bar and drag it to the first one

🔁 SAR

- The maximum electromagnetic radiation absorption ratio (SAR) of this product is <2.0W/kg
- In line with the requirements of the national standard GB 21288-2007

EN62209-1:2016; EN 62209-2:2010; EN 62479:2010; EN 50360:2017; EN 50566:2017;

Comes with the Google™ app and Google Chrome™ . Android is a trademark of Google LLC



 Thoroughly understand the maintenance of this pad to use the pad more safely and effectively, and extend the service life of the pad as much as possible.

 Please follow the instructions in the manual to open the pad, disassemble the accessories, and do not try other

 Please avoid dropping, knocking, or shaking your pad.
Rough handling of the pad can cause the screen to rupture, damaging the internal circuit board and the delicate structure.

• Do not use chemical solvents or detergents to clean your pad. Wipe the pad case with a soft cotton cloth dampened with water and mild soap.

• Clean the lens with a clean, dry, soft cloth. (Example: camera lens) and display.

 When the charger is not in use, please unplug it from the power outlet. Do not connect the battery that has been fully charged to the charger for a long time, as overcharging will shorten the battery life.

 This machine's standard package (Package box-Pad-Manual-Protective film-Protective case-Headset-USB data cable-OTG cable-Charger)

Comes with the Google ${}^{\rm TM}$ app and Google Chrome ${}^{\rm TM}$. Android is a trademark of Google LLC

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

FCC RF Exposure Information and Statement

The SAR limit of USA (FCC) is 1.6 W/kg veraged over one gram of tissue. Device types Tablet (RT3) (FCC ID:2ANMU-RT3) has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for use at the body is 0.722W/kg and Simultaneous Transmission is 1.18W/kg. This device was tested for typical body-worn operations with the back of the handset kept 0mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements, and should be avoided



Accessories



Battery

RT3 enthält eine interne Batterie. Sie können Ihren Batteriestatus mit dem Symbol oben rechts auf dem Bildschirm verfolgen.



Warning

- Verwenden Sie nur von OUKITEL zugelassene Batterien, die speziell für Ihr Telefon entwickelt wurden.
- Inkompatible Batterien können schwere Verletzungen oder Schäden an Ihrem Telefon verursachen.
- Legen Sie niemals Batterien oder Telefone auf oder in Heizgeräte wie Mikrowellenherde, Öfen oder Heizkörper, Batterien können bei Überhitzung explodieren.

Prihaja z aplikacijo Google ™ in Google Chrome ™. Android je blagovna znamka družbe Google LLC



🗿 Einsetzen der Karte

Damit Ihr Pad Anrufe tätigen kann, setzen Sie die SIM-Karte in der folgenden Reihenfolge ein.

• Stecken und drücken Sie den Auswerferstift in das seitliche Loch ein, um das Kartenfach herauszuholen.






 Nehmen Sie den Kartensteckplatz heraus und legen Sie zwei Nano-Karten oder eine Nano-Karte und eine TF-Karte mit der Metallseite nach unten ein. Achten Sie darauf, dass die schräge Ecke des Kartensteckplatzes und der SIM-Karte zueinander passen.



 Halten Sie das Pad mit der Bildfläche nach oben und führen Sie den Kartenhalter in Pfeilrichtung in das Pad ein.



Prihaja z aplikacijo Google ™ in Google Chrome ™. Android je blagovna znamka družbe Google LLC DE

6.Sicherheit - Um die Sicherheit bei Gebrauch des Produkts zugewährleisten, müssen Sie folgende Regeln strikt einhalten

- Halten Sie das Pad mindestens 15cm von medizinischen Implantaten oder Rhythmuseinstellern entfernt und stecken es niemals in die Manteltasche.
- Legen Sie das Gerät und andere Batterien nicht in die hohen Temperaturen aus oder mit wärmeerzeugenden Geräten wie Sonnenlicht, Heizungen, Mikrowellen, Öfen oder Wasserkocher zusammen. Überhitzte Batterien können explodieren.
- Wenn der Ladevorgang abgeschlossen ist oder nicht aufgeladen wird, trennen Sie das Ladegerät vom Gerät und ziehen den Netzstecker aus der Steckdose.
- Wenn das Gerät mit einem nicht austauschbaren Akku ausgestattet ist, ersetzen Sie den Akku nicht selbst, um eine Beschädigung des Akkus oder des Geräts zu vermeiden.
- Verwendung einer nicht zugelassenen oder nicht kompatiblen Stromquelle, eines Ladegeräts oder eines Akkus kann zu Brand, Explosion oder anderen Gefahren führen.
- Zerlegen Sie die Batterie nicht, setzen sie nicht zurück, setzen keine anderen Gegenstände ein, tauchen sie nicht ins Wasser oder andere Flüssigkeiten ein, um ein Auslaufen der Batterie, Überhitzung, Feuer oder Explosion zu vermeiden.
- Lassen Sie die Batterie nicht fallen. Quetschen, zerkratzen oder stoßen Sie sie nicht, um übermäßigen Druck auf die Batterie zu vermeiden, der zu einem internen Kurzschluss und einer Überhitzung der Batterie führen kann.
- Der Hersteller übernimmt keine Verantwortung für Unfälle, die durch Verwendung fremder Ladegeräte verursacht werden.

Die vollständige CE-Konformität finden Sie unter dem Link: http://www.oukitel.com

Prihaja z aplikacijo Google ™ in Google Chrome ™. Android je blagovna znamka družbe Google LLC