

投影仪英文使用说明书

PROJECTOR USER MANUAL	
Opening Remarks	
Thank you very much for your support. You can learn to use and operate on this projector by reading this manual. This projector has powerful features like compact, convenient etc. It is specifically designed for home, entertainment, business and other occasions. The projector let you enjoy the fun of the big screen reality anytime and anywhere, and you are also welcome to share your fun and opinions with us. If you have any questions about this product, please contact our after-sales department. We are happy to service for you.	

CATALOGUE	
Cautions And Warnings	01
List Of Items	02
The Remote Control	03
Installation And Debugging	04
The Software Settings	06
Media Player	08
Same screen	09
Warranty Card	10
Clean And Maintain	12

CAUTIONS AND WARNINGS	
For use within, it is recommended that you use this product in a dark room.	
1. Do not install the machine where directly blown by the air conditioner, the water condensation or high temperature may cause machine failure.	
2. Make sure that there is sufficient ventilation and the ventilation fan will operate. Do not block the ventilation fan for 10 minutes.	
3. Prevent dust or paper falling into the machine, and do not put any metal objects into machine. For customer's inquiries, please turn off the power immediately and do not start until it is fixed.	
4. Due to extreme risk of leakage, do not place any liquid on the machine.	
5. When transporting the projector, please use the carrying case to avoid damage during transporting.	
6. Going to enter the projector, the safety of the machine user will become not very clear with your hands.	
7. Do not shake the lens when the machine is powered on, it may cause serious damage to your lens.	
NOTICE	
Do not open this case. Please entrust qualified professional technicians personnel to perform maintenance.	
This device shall be used as an entertainment display. It is not designed to be used as a display for professional use. It is not designed to be used as a display for professional use.	
NOTICE	
To prevent fire or electric shock, do not expose this machine to rain or moisture.	

LIST OF ITEMS	
Projector	Remote Control
User Manual	Power cord or adapter

Thank you very much for purchasing our products. Please check whether the physical products received are complete. If the products and accessories you receive are not complete, please contact the sales personnel in a timely manner. (For specific items, please refer to the actual package.)

THE REMOTE CONTROL	
Power: To turn on/off the unit. Mute: To mute or unmute the projector speaker. Menu: To open the menu or applications or other. Volume +/-: Increase/Decrease the volume. Enter: Confirm/Click. Directional Keys: Move the cursor to the desired location. Return: Back to previous menu or close the active window. Home: Back to homepage. Stop: Stop the projector. Switching between opening/reopening data. After touch length: Adjust the touch screen length. Touch: Open product settings function.	

INSTALLATION AND DEBUGGING	
Focus: When the projection image is blurry (as shown in the right figure), adjust the focus adjustment button on the remote control to move forward or backward to achieve satisfactory imaging results. If satisfactory clarity cannot be achieved through adjustment, please move the machine back and forth appropriately. (Version of autofocus, with autofocus enabled on the settings interface, mobile devices can achieve autofocus.)	
INTELLIGENT PROJECTOR MADE IN CHINA	
Projection Distance Reference	
Projection Size (mm) Projection Distance (m)	
33" 1.5 M	
55" 1.7 M	
67" 2.0 M	
85" 2.5 M	
95" 2.8 M	
105" 3.0 M	
125" 3.8 M	
How To Power Off	
1. Press the ON/OFF button on the remote control or the power switch on the unit. 2. Put the lens cap on and store the unit in a dry and cool place.	

THE SOFTWARE SETTINGS	
Home Page	
Projection Setting	
Note: With the update of system version, there will be differences from the actual interfaces. Please refer to the displayed interfaces as final.	

INTELLIGENT PROJECTOR MADE IN CHINA	
Wi-Fi Setting	
Bluetooth Settings	

MEDIA PLAYER	
You can play videos, music, or pictures from a storage device in the following ways.	
(1) After the projector is turned on, insert a USB flash drive, and the system will detect the external device by itself, and a pop-up control will appear. Select the type of file you want to play, and press the "OK" button on the remote control panel to enter.	
(2) Press the signal input button on the remote control and select USB device to turn it on.	

SAME SCREEN	
For screen sharing function, please use Miracast for Apple Phones, and Airscreen for Android phones.	

Product Warranty Description	
The after-sale service of projector is strictly based on the "Consumer Rights Protection Law of the People's Republic of China" and "Product Quality Law of the People's Republic of China". service content detailed as below: Within 12 months upon purchasing, faults that not caused by improper use of human factors shall be inspected by after-sale service center; free maintenance service shall be provided for you with valid purchase proof if it is determined as defect that caused by product quality itself.	
Non-Warranty Regulations:	
1. Accessories such as Remote Controller, User manual, Power cord are not warranted. 2. Damage caused by self-disassembly or unauthorized maintenance, modification etc. 3. Damage that caused by artificial damage. 4. Period of warranty validity has expired.	

After-Sale Service Card	
Customer Name: _____	
Customer ID: _____	
Customer Tel: _____	
Customer Email: _____	
Fault Description (Please describe in detail for quick maintenance):	

FCC Warning	
This Device Complies With Part 15 Of The FCC Rules. Operation is Subject To The Following Two Conditions: (1) This Device May Not Cause Harmful Interference, And (2) This Device Must Accept Any Interference Received, Including Interference That May Cause Undesired Operation. Changes Or Modifications Not Expressly Approved By The Party Responsible For Compliance Could Void The User's Authority To Operate The Equipment. This Equipment Has Been Tested And Found To Comply With The Limits For A Class B Digital Device, Pursuant To Part 15 Of The FCC Rules. These Limits Are Designed To Provide Reasonable Protection Against Harmful Interference In A Residential Installation. This Equipment Generates Uses And Can Radiate Radio Frequency Energy And, If Not Installed And Used In Accordance With The Instructions, May Cause Harmful Interference To Radio Communications. However, There Is No Guarantee That Interference Will Not Occur In A Particular Installation. If This Equipment Does Cause Harmful Interference To Radio Or Television Reception, Which Can Be Determined By Turning The Equipment Off And On, The User Is Encouraged To Try To Correct The Interference By One Or More Of The Following Measures: • Reorient Or Relocate The Receiving Antenna. • Increase The Separation Between The Equipment And Receiver. • Connect The Equipment Into An Outlet On A Circuit Different From That To Which The Receiver Is Connected. • Consult The Dealer Or An Experienced Radio/TV Technician For Help. Radiation Exposure Statement This Equipment Complies With FCC Radiation Exposure Limits Set Forth For An Uncontrolled Environment. This Equipment Should Be Installed And Operated With Minimum Distance 20cm.	

INTELLIGENT PROJECTOR	
------------------------------	--