



210mm

99mm

594mm




CHARGING




BLUETOOTH PAIRING


Step 1: Turn on the device. Step 2: Press the Bluetooth icon on the device. Step 3: The device will enter pairing mode and the Bluetooth icon will flash.




FUNCTION



MICROPHONE




APP




TECH SPEC

Model	Power	Frequency	Range	Weight	Dimensions
Donner Soundwin Karaoke	10W	20Hz-20KHz	10m	1.2kg	210mm x 99mm x 594mm




CHARGING




BLUETOOTH PAIRING


Step 1: Turn on the device. Step 2: Press the Bluetooth icon on the device. Step 3: The device will enter pairing mode and the Bluetooth icon will flash.




FUNCTION



MICROPHONE



APP



TECH SPEC

Model	Power	Frequency	Range	Weight	Dimensions
Donner Soundwin Karaoke	10W	20Hz-20KHz	10m	1.2kg	210mm x 99mm x 594mm