Greetings from realme mobile

This guide will show you how to use the phone and its important functions . You may also visit realme official website to get more information about the phone.



A Warning

- > Do not place the phone or battery near or inside heating equipment, cooking equipments, high pressure vessels (such as microwave ovens, induction cooker electric oven, heater, pressure cooker, water heater, gas stove, etc.) to prevent the battery overheating which may lead to an explosion.
- > The original charger, data cable and battery shall be used. Unapproved chargers, data cables, or batteries that are not certified by the manufacturer may result in electric shock, fire, explosion, or other hazards.
- Back cover can't be removed.

عند الشحن، يرجى وضع الجهاز في بينة ذات درجة حرارة غرفة عادية وتهوية جيدة. يوصى بشحن الجهاز في بيئة ذات درجة حرارة تتراوح بين 5 درجة منوية و35 درجة منوية. كبفية اعادة تشغيل الهاتف:

اضغط مع الاستمرار على زر التشغيل وزر رفع الصوت في الوقت نفسه حتى يتم عرض الرسم المتحرك لتشغيل هاتف realme لإعادة تشغيل الهاتف

كيف بمكنني نقل ما تم تخزينه على هاتفي القديم الي هاتف جديد؟ يمكنك استخدام "استنساخ الهاتف" من realme لنقل الصور و مقاطع الفيديو و مقاطع الموسيقي و جهات الاتصال و الرسائل و التطبيقات و ما الى ذلك بسهولة من هاتفك القديم الى الهاتف الجديد . ١. إذا كان لديك هاتف Android قديم فقم او لا بمسح رمز الاستجابة السريعة أدناه , ثم قم بتتزيل و تثبيت التطبيق و بعد ذلك افتح " استنساخ الهاتف " على كل من الهاتفين الجديد و القديم و اتبع التعليمات الظاهرة على الشاشة لإكمال العملية.



https://i.cloneph

٢- إذا كان لديك هاتف iPhone قديم فاقتح "استنساخ الهاتف" على الهاتف الجديد و انبع التعليمات الظاهرة على الشاشة لتسجيل الدخول الى حساب iCloud و مزامنة الملفات. الملحقات القياسية سيتم تزويدك بالملحقات القياسية التالية: ١ هاتف، ١ شلحن، ١ أداة لإدخال وإخراج بطاقة SIM ۱ کابل بیانات USB ، ۱ دلیل أمان، ۱ دلیل سریع.

FCC Regulations:

This mobile phone complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) this device must accept any interference received, including interference that may cause undesired operation.

This mobile phone has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiated radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receive

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

When charging, please place the device in an environment that has a normal

room temperature and good ventilation. It is recommended to charge the device in an environment with temperature ranging from 5°C~35°C. How to reboot the phone

Press and hold the Power Button and Volume Up Button at the same time until the realme boot animation is displayed to reboot the phone How to Transfer Old Mobile Content to a New Mobile You can use realme Clone Phone to easily transfer photos, videos, music, contacts, messages, apps, etc from your old phone to the new one. 1. If you have an old Android phone, first scan the QR code below, then





2. If you have an old iPhone, open Clone Phone on the new phone directly, and follow on-screen instructions to sign in to iCloud account and sync the files. Standard accessories

You are provided with the following standard accessories:

1 Phone, 1 Charger, 1 USB data cable, 1 Safety Guide, 1 Quick Guide, 1 SIM Ejector Tool.

خالص التحيات من الهتف المحمول reaime

سيظهر لك هذا الدليل كيفية استخدام الهاتف ووظائفه الهامة. يمكنك أيضًا زيارة موقع الويب الرسمي للهاتف realme للحصول على مزيد من المعلومات حول الهاتف.

pros.com/download



🛆 تحذير :

◄ لا تضع الهاتف أو البطارية بالقرب من أجهزة التسخين أو الطبخ أو الأواني ذات الضغط العالي أو بداخلها (على سبيل المثال أفران الميكروويف والموقد الذي يعمل بالحث والفرن الكهربائي والسخان والموقد الذي يعمل بالضغط وسخان المياه وموقد الغاز، وما إلى ذلك) وذلك لمنع سخونة البطارية بدرجة مفرطة مما قد يتسبب في حدوث انفجار.

> يُنصح باستخدام الشاحن والبطارية وكابل البيانات الأصليين. فقد تتسبب الشواحن أو كابلات البيانات أو البطاريات غير المعتمدة من الشركة المصنعة في حدوث صدمة كهربائية أو حريق أو انفجار أو مخاطر أخرى. الغطاء الخلفي لا يمكن نز عه.

FCC Note:

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF Exposure Information (SAR)

This phone is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the United States

During SAR testing, this device was set to transmit at its highest certified power level in all tested frequency bands, and placed in positions that simulate RF exposure in usage against the head with no separation, and near the body with the separation of 1.5 mm. Although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output.

The exposure standard for wireless devices employing a unit of measurement is known as the Specific Absorption Rate, or SAR.

The SAR limit set by the FCC is 1.6W/kg.

realme

RMX3581/RMX3506 Product Main screen parameter 16.5cm(6.5") Dimension 164.1×75.6×8.5(mm) 4890mAh/18.92Wh(Min) Battery 5000mAh/19.35Wh(Typ) 8Megapixels Front Camera 5Megapixels Rear Operating temperature 0°C-35°C 0.73W/kg(Head)

0.33W/kg(Body)

Frequency

850MHz

900MHz

1800MHz

1900MHz

Bands 1/5/8

Bands 2/4

Bands 1/2/3/4/66

Band 7

Bands 5/8/13/20/28

Bands 38/41

2.4-2.4835GHz

2 4-2 4835GHz

FCC SAR

Specification

SAR Values

Max. Output Power

33 5dBm

33.5dBm

30.5dBm

30.5dBm

24.5dBm

24.0dBm

24 0dBm

23.5dBm

24.5dBm

24.0dBm

14.0dBm(EIRP)

21 5dBm(FIRP)

Radio Waves Specifications

	-	
Radio	Frequency	Max. Output Power
GSM	850MHz	33.5dBm
	900MHz	33.5dBm
	1800MHz	30.5dBm
	1900MHz	30.5dBm
WCDMA	Bands 1/5/8	24.5dBm
	Bands 2/4	24.0dBm
LTE FDD	Bands 1/2/3/4/66	24.0dBm
	Band 7	23.5dBm
	Bands 5/8/13/20/28	24.5dBm
LTE TDD	Bands 38/41	24.0dBm
Bluetooth	2.4-2.4835GHz	14.0dBm(EIRP)
2.4G Wi-Fi	2.4-2.4835GHz	21.5dBm(EIRP)

مو اصفات الموجات اللاسلكية

Radio

GSM

WCDMA

LTE FDD

LTE TDD

Bluetooth

2.4G Wi-Fi

المواصفات القنية		
طراز المنتج	RMX3581/RMX3506	
خصائص شاشة العرض الرئيسية	16.5 سم (6.5 بوصة)	
الابعاد	164.1×75.6×8.5 (ملليمتر)	
البطارية	4890mAh/18.92Wh(Min) 5000mAh/19.35Wh(Typ)	
الكاميرا	8 میجابکسل خلفیة 5 میجابکسل أمامیة	
درجة حرارة التشغيل	0°C-35°C	
فيم FCC SAR SAR	(رأس) 0.73W/kg (جسم) 0.33W/kg	

This device is complied with SAR for general population /uncontrolled exposure limits in ANSI/IEEE C95.1-1992 and had been tested in accordance with the measurement methods and procedures specified in IEEE1528.

The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of www.fcc.gov/oet/ea/fccid after searching on ECC ID: 2AUYERMX3581

For this device, the highest reported SAR value for usage against the head is 0.73W/kg, fo usage near the body is 0.33 W/kg.

While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirements.

SAR compliance for body-worn operation is based on a separation distance of 15 mm between the unit and the human body. Carry this device at least 15 mm away from your body to ensure RF exposure level compliant or lower to the reported level. To support body-worn operation, choose the belt clips or holsters, which do not contain metallic components, to maintain a separation of 15 mm between this device and your body.

RF exposure compliance with any body-worn accessory, which contains metal, was not tested and certified, and use such body-worn accessory should be avoided.

Steps to search E-label : Go to Settings - About Phone - Certificate Information.

Regulatory

RMX3581 Quick Guide RMX3506 realme