






1_Reference_Level_NVNT_ANT1_3-DH5_2402_00




2_Spurious_Emissions_NVNT_ANT1_3-DH5_2402_00




1_Reference_Level_NVNT_ANT1_3-DH5_2441_00



2_Spurious_Emissions_NVNT_ANT1_3-DH5_2441_00



1_Reference_Level_NVNT_ANT1_3-DH5_2480_00



2_Spurious_Emissions_NVNT_ANT1_3-DH5_2480_00



Shenzhen Anbotek Compliance Laboratory Limited

Address: Sogood Industrial Zone Laboratory & 1/F. of Building D, Sogood Science and Technology Park,
Sanwei Community, Hangcheng Subdistrict, Bao'an District, Shenzhen, Guangdong, China
Tel: (86) 0755-26066440 Email: service@anbotek.com



Hotline
400-003-0500
www.anbotek.com


Appendix G: Bandedge

Condition	Antenna	Modulation	TX Mode	Ref_level(dBm)	Bandedge MAX.Value	Limit	Result
NVNT	ANT1	1-DH5	2402.00	-1.092	-50.004	-21.092	Pass
NVNT	ANT1	1-DH5	Hopping_LCH	-0.419	-49.002	-20.419	Pass
NVNT	ANT1	1-DH5	2480.00	-0.483	-56.093	-20.483	Pass
NVNT	ANT1	1-DH5	Hopping_HCH	-0.794	-48.416	-20.794	Pass
NVNT	ANT1	2-DH5	2402.00	-5.558	-59.346	-25.558	Pass
NVNT	ANT1	2-DH5	Hopping_LCH	-2.029	-57.021	-22.029	Pass
NVNT	ANT1	2-DH5	2480.00	-0.502	-55.972	-20.502	Pass
NVNT	ANT1	2-DH5	Hopping_HCH	-0.720	-50.336	-20.720	Pass
NVNT	ANT1	3-DH5	2402.00	-5.032	-57.252	-25.032	Pass
NVNT	ANT1	3-DH5	Hopping_LCH	-3.541	-57.377	-23.541	Pass
NVNT	ANT1	3-DH5	2480.00	-0.497	-56.136	-20.497	Pass
NVNT	ANT1	3-DH5	Hopping_HCH	-1.065	-48.872	-21.065	Pass


1_Reference_Level_NVNT_ANT1_1-DH5_2402_00




2_Bandedge_NVNT_ANT1_1-DH5_2402_00




1_Reference_Level_Hopping_NVNT_ANT1_1-DH5_Hopping






1_Reference_Level_NVNT_ANT1_1-DH5_2480_00




2_Bandedge_NVNT_ANT1_1-DH5_2480_00







1_Reference_Level_Hopping_NVNT_ANT1_1-DH5_Hopping




2_Band_Edge_(Hopping)_NVNT_ANT1_1-DH5_Hopping




1_Reference_Level_NVNT_ANT1_2-DH5_2402_00



2_Bandedge_NVNT_ANT1_2-DH5_2402_00




1_Reference_Level_Hopping_NVNT_ANT1_2-DH5_Hopping




2_Band_Edge_(Hopping)_NVNT_ANT1_2-DH5_Hopping






1_Reference_Level_NVNT_ANT1_2-DH5_2480_00




2_Bandedge_NVNT_ANT1_2-DH5_2480_00








1_Reference_Level_Hopping_NVNT_ANT1_2-DH5_Hopping




2_Band_Edge_(Hopping)_NVNT_ANT1_2-DH5_Hopping






1_Reference_Level_Hopping_NVNT_ANT1_3-DH5_Hopping




2_Band_Edge_(Hopping)_NVNT_ANT1_3-DH5_Hopping







1_Reference_Level_NVNT_ANT1_3-DH5_2480_00




2_Bandedge_NVNT_ANT1_3-DH5_2480_00



1_Reference_Level_Hopping_NVNT_ANT1_3-DH5_Hopping



2_Band_Edge_(Hopping)_NVNT_ANT1_3-DH5_Hopping



Shenzhen Anbotek Compliance Laboratory Limited

Address: Sogood Industrial Zone Laboratory & 1/F. of Building D, Sogood Science and Technology Park,
Sanwei Community, Hangcheng Subdistrict, Bao'an District, Shenzhen, Guangdong, China
Tel: (86) 0755-26066440 Email: service@anbotek.com



Hotline
400-003-0500
www.anbotek.com


Appendix H: Carrier Frequencies Separation (Hopping)

Condition	Antenna	Modulation	Frequency(MHz)	Hopping NO.0 (MHz)	Hopping NO.1 (MHz)	Carrier Frequencies Separation(MHz)	Limit(MHz)	Result
NVNT	ANT1	1-DH5	2441.00	2440.864	2441.833	0.97	0.694	Pass
NVNT	ANT1	2-DH5	2441.00	2440.879	2441.875	1.00	0.888	Pass
NVNT	ANT1	3-DH5	2441.00	2440.945	2442.031	1.09	0.872	Pass


Carrier_Frequencies_Separation_(Hopping)_NVNT_ANT1_1-DH5_Hopping



Carrier_Frequencies_Separation_(Hopping)_NVNT_ANT1_2-DH5_Hopping



Carrier_Frequencies_Separation_(Hopping)_NVNT_ANT1_3-DH5_Hopping



Shenzhen Anbotek Compliance Laboratory Limited


Address: Sogood Industrial Zone Laboratory & 1/F. of Building D, Sogood Science and Technology Park,
Sanwei Community, Hangcheng Subdistrict, Bao'an District, Shenzhen, Guangdong, China
Tel: (86) 0755-26066440 Email: service@anbotek.com

Hotline
400-003-0500
www.anbotek.com


Appendix I: Number of Hopping Channel (Hopping)


Condition	Antenna	Modulation	Hopping Num	Limit	Result
NVNT	ANT1	1-DH5	79	15	Pass
NVNT	ANT1	2-DH5	79	15	Pass
NVNT	ANT1	3-DH5	79	15	Pass

Number_of_Hopping_Channel_(Hopping)_NVNT_ANT1_1-DH5_Hopping



Number_of_Hopping_Channel_(Hopping)_NVNT_ANT1_2-DH5_Hopping





Shenzhen Anbotek Compliance Laboratory Limited


Address: Sogood Industrial Zone Laboratory & 1/F. of Building D, Sogood Science and Technology Park,
Sanwei Community, Hangcheng Subdistrict, Bao'an District, Shenzhen, Guangdong, China
Tel: (86) 0755-26066440 Email: service@anbotek.com

Hotline
400-003-0500
www.anbotek.com


Appendix J: Dwell Time (Hopping)

Condition	Antenna	Packet Type	Pulse Time(ms)	Hops	Dwell Time(ms)	Limit(s)	Result
NVNT	ANT1	1-DH5	2.890	117.00	338.130	0.40	Pass
NVNT	ANT1	2-DH5	2.900	114.00	330.600	0.40	Pass
NVNT	ANT1	3-DH5	2.900	114.00	330.600	0.40	Pass
NVNT	ANT1	1-DH1	0.390	320.00	124.800	0.40	Pass
NVNT	ANT1	1-DH3	1.650	163.00	268.950	0.40	Pass
NVNT	ANT1	2-DH1	0.400	319.00	127.600	0.40	Pass
NVNT	ANT1	2-DH3	1.650	163.00	268.950	0.40	Pass
NVNT	ANT1	3-DH1	0.400	318.00	127.200	0.40	Pass
NVNT	ANT1	3-DH3	1.650	154.00	254.100	0.40	Pass


Dwell_Time_(Hopping)_NVNT_ANT1_1-DH5_2441_00_One_Burst_Time




Dwell_Time_(Hopping)_NVNT_ANT1_1-DH5_2441_00_Accumulated




Dwell_Time_(Hopping)_NVNT_ANT1_2-DH5_2441_00_One_Burst_Time




Dwell_Time_(Hopping)_NVNT_ANT1_2-DH5_2441_00_Accumulated




Dwell_Time_(Hopping)_NVNT_ANT1_3-DH5_2441_00_One_Burst_Time




Dwell_Time_(Hopping)_NVNT_ANT1_3-DH5_2441_00_Accumulated




Dwell_Time_(Hopping)_NVNT_ANT1_1-DH1_2441_00_One_Burst_Time



Dwell_Time_(Hopping)_NVNT_ANT1_1-DH1_2441_00_Accumulated




Dwell_Time_(Hopping)_NVNT_ANT1_1-DH3_2441_00_One_Burst_Time




Dwell_Time_(Hopping)_NVNT_ANT1_1-DH3_2441_00_Accumulated







Dwell_Time_(Hopping)_NVNT_ANT1_2-DH1_2441_00_One_Burst_Time




Dwell_Time_(Hopping)_NVNT_ANT1_2-DH1_2441_00_Accumulated




Dwell_Time_(Hopping)_NVNT_ANT1_2-DH3_2441_00_One_Burst_Time




Dwell_Time_(Hopping)_NVNT_ANT1_2-DH3_2441_00_Accumulated




Dwell_Time_(Hopping)_NVNT_ANT1_3-DH1_2441_00_One_Burst_Time




Dwell_Time_(Hopping)_NVNT_ANT1_3-DH1_2441_00_Accumulated



Dwell_Time_(Hopping)_NVNT_ANT1_3-DH3_2441_00_One_Burst_Time



Dwell_Time_(Hopping)_NVNT_ANT1_3-DH3_2441_00_Accumulated



---END---

Shenzhen Anbotek Compliance Laboratory Limited

Address: Sogood Industrial Zone Laboratory & 1/F. of Building D, Sogood Science and Technology Park, Sanwei Community, Hangcheng Subdistrict, Bao'an District, Shenzhen, Guangdong, China
Tel:(86)0755-26066440 Email:service@anbotek.com

Hotline
400-003-0500
www.anbotek.com