

# Contents

<b>Basic Information.....</b>	<b>2</b>
<i>Brief Introduction .....</i>	<i>2</i>
<i>Safety Notice .....</i>	<i>2</i>
<i>Cleaning and Maintaining .....</i>	<i>2</i>
<b>Before Using .....</b>	<b>2</b>
<i>SIM .....</i>	<i>2</i>
<i>Phone Unlock .....</i>	<i>3</i>
<i>SIM Unlock.....</i>	<i>3</i>
<b>Function menu Introduction .....</b>	<b>3</b>
<i>Contacts.....</i>	<i>3</i>
<i>Call logs .....</i>	<i>4</i>
<i>Messaging.....</i>	<i>5</i>
Write message .....	5
Inbox.....	5
Outbox.....	5
Drafts.....	5
Sentbox.....	5
SMS templates.....	5
Security inbox.....	5
SMS settings.....	5
<i>Bluetooth.....</i>	<i>6</i>
<i>Multimedia.....</i>	<i>6</i>
Camera .....	6
Image viewer .....	6
Video recorder .....	7
Audio player .....	7
video player .....	7
FM radio.....	7
Recorder .....	8
<i>File manager .....</i>	<i>8</i>

*Tools* .....8

    Torch .....8

    Clock .....8

    Ebook .....9

    Unit conversion .....9

    Sim Toolkits .....9

*Calculator*.....9

*Calendar*.....9

*Settings* .....9

    Use Profiles .....9

    Phone settings.....10

    Call settings .....11

    Security settings .....12

    Network settings.....13

    Restore settings.....13

*Extras*.....13

*Internet* .....13

*Game* .....13

## Basic Information

---

### Brief Introduction

---

Thank you for choosing **MEGA W51** mobile phone. You can read the manual, a comprehensive understanding of the use of mobile phones and enjoy its perfect functionality and simple method of operation.

supports two SIM cards function. In addition to basic call functions, but also to provide you with phone book, personalized ring tones, alarm, camera, image viewer, video recorder, One Memory Card (T-Flash card), calculator, calendar etc. A variety of practical features to facilitate your work and leisure activities, in addition, interface with personalized mobile phone design, its perfect functionality to meet your needs.

Our Company reserves without any prior notice the contents of this manual under the right to make changes.

### Safety Notice

---

If your phone is lost or stolen, immediately notify the telecommunications sector, or its outlet, to disable the SIM. This will allow you to take phone calls from other economic loss arising. To make you more secure use of mobile phones, please take precautionary measures, such as:

- Set up mobile phone SIM card PIN password, PIN password to prevent your SIM is unauthorized use by others.

### Cleaning and Maintaining

---

Do not use the bathroom where high humidity, cell phone, battery and charger, the same should also avoid the rain. Use a soft, dry cloth to clean the phone, battery and charger. Dirt outlet will lead to poor contact, power-down, which does not charge, regular cleaning.

### Before Using

---

#### SIM

---

---

Before using your phone you must insert a valid SIM (Subscriber Identity Module) card. SIM card provide by the network provider.

**Warning:** Be sure to remove the SIM phone off before. There is absolutely prohibited in the case of an external power supply connected to insert or remove the SIM, or SIM card and mobile phone may be damaged.

## Phone Unlock

---

In order to prevent illegal use, your phone can set the phone lock password protected. Use this function,you must enter the phone lock password so that you can unlock the phone into the normal use state.

Enter the phone lock password, press the LSK to confirm. For example, if the phone lock password is set to **1234**, then the following input: **1234**.

## SIM Unlock

---

In order to prevent illegal use of your SIM with PIN (Personal Identification Number) password encryption protection. Use this function, if you have set the PIN password protection, every time you must enter the PIN password at boot time, so that you can unlock the SIM card and phone to normal use. Enter the PIN password, press the LSK to confirm. For example, if the PIN is set to 1234, then the following input: 1234.If there consecutive incorrect, your SIM will be network locked, the phone will ask for PUK password.

## Function menu Introduction

---

### Contacts

---

You can use the contacts to store records, can store the following: name and phone number.In the contacts list, select a record, to make a call when you press the dial keys.Select a record in the contacts, you can do the following:

- View**      View the contact details or edit record.
- Send text message**      Send text message to this number.
- Call**      Make a call to the number.
- Edit**      Can edit and save record.
- Delete**      Delete the record.
- Copy**      Copy the current record to Phone/SIM.
- Delete multiple**      You can delete multiple records.

---

**-Import/Export contacts**    You can Import/Export contacts from phone to phone.

**-Contacts settings:**

**-Speed dial**    Open speed dial. If you long press number keys on the dialing interface, you can call up.

**-Own number**    View local SIM card number.

**-Service number**    You can call the service number.

**-Memory status**    View the usage and total **Contacts** capacity information.

## Call logs

---

### Missed calls

---

Enter the missed calls menu, will display the missed calls list. Select missed call records, press the Options key:

- **View**    View the details.
- **Call**    Call the record number.
- **Send text message**    Send text message to record number.
- **Add to Contacts**    Save the number to the phone or SIM card.
- **Add to Blacklist**    Save the number to call blacklist number.
- **Delete**    Delete the number.

### Dialed calls

---

Enter the dialed calls menu to display the current record of outgoing phone list of phone numbers. Please refer to missed calls for details.

### Received calls

---

Enter the received calls menu to display the current record has been received mobile phone number list. Please refer to missed calls for details.

### Rejected calls

---

Enter the rejected calls menu to display the current record has been rejected mobile phone number list. Please refer to missed calls for details.

---

## Delete call logs

---

Press the LSK to select "OK" to delete call records.

## Call timers

---

See SIM 1 and SIM 2 call timers.

## Messaging

---

Make sure that the information in writing before the message center number is set correctly. Access to an information menu, you can edit the SMS message.

## Write message

---

Edit SMS message contents.

## Inbox

---

Messages which are received.

## Outbox

---

Storage location when sending SMS.

## Drafts

---

Draft messages.

## Sentbox

---

Sent messages.

## SMS templates

---

SMS template content.

## Security inbox

---

After moving important messages to the security inbox, a password is required to view them.

## SMS settings

---

**SIM1\SIM2:** This menu can set **SMS validity period**、delivery report、

---

reply path、 Save sent messages、 Export SMS and Auto signature.

**Memory status:** View the SIM and Phone capacity information.

**Text msg. counter:** Received message counter of SIM1/SIM2.

**Preferred storage:** Can set preferred storage as SIM or phone.

**Voice mail server:** can set a voice service number.

## Bluetooth

---

**Power:** Turn on bluetooth or not.

**Visibility:** You can set it on/off.

**My device:** You can search for nearby bluetooth devices and pair them.

**My name:** Bluetooth device name which can be renamed.

**Storage:** To receive the file will be automatically transferred to the specified path, the path can be set as phone or memory card.

## Multimedia

---

### Camera

---

The phone includes high-definition camera, you can take pictures anytime, anywhere, and to save the photos to your phone or memory card.

State in the preview, press the LSK to enter "Options" you can do this to conduct a more detailed set of parameters.

**Switch to video recorder:** Switch to the video recorder.

**Photos:** Photo album shows the current list of files.

**Camera settings:** Including banding,shutter sound,Auto save,Brightness,Contrast,Exposure bias,Frame,Cont.shot,White balance,Delay.

**Image settings:** Include the image size and image quality.

**Effect settings:** You can set effect.

**Storage:** Storage location can be set as Phone, Memory card

### Image viewer

---

Select an album sub-menu, you can easily view stored in the camera album picture list, and press the LSK to enter to "Options" to choose the pictures to do the View, Send, Use as, Rename, Delete and check Image information operations. View pictures, by pressing on the left and right

---

navigation buttons to switch pictures.

## Video recorder

---

**Switch to camera:** Switch to the camera.

**Video settings:** Video size,banding,Audio,format,Brightness,Contrast.

**Effect settings:** You can set effect.

**Storage:** Storage location can be set Phone and Memory card, video records will be saved to the specified location.

## Audio player

---

You can play local music in the memory card/phone storage.By selecting the music submenu, you can easily view the music stored in the list, then press LSK to enter "Options", choose music to play, add, use as, loop, and perform random operations.

## video player

---

By selecting the video player submenu, you can easily view the video players saved in the video list. Press LSK to enter "Options" and select the video files to play.

## FM radio

---

FM interface, press the OK key to turn on FM, press the back key to exit FM, press up key and down key to adjust the FM playing volume. Press the left soft key "Options" can show FM options menu, the contents as follow:

**Channel list:** Shows FM channel list.

**Manual search:** Can be their own editors to manually enter the channel frequency, the effective value of 87.5 ~ 108.0.

**Auto search and save:** Auto search FM channels in the channel list and save them.

**Record:** Record the channel that is playing.

**Timing record:** Turn on/off timing record.You can customize the recording start time, recording duration, recording channel, and repeat mode.

**File list:** Recording file list.

**Storage:** The storage location can be set to the phone and memory card, and FM recordings will be saved to the specified location.



---

## Recorder

---

Press "Options" on the tape recorder interface to display the recording items.

Start a new record. If you press stop, you can save it. If you press pause and continue recording.

The list displays the sounds you have recorded and saved.

You can set storage and audio quality settings.

---

## File manager

---

Into the File manager menu, the menu display **Phone** and **Memory card**. Root directory, select "**Phone**", press the **LSK** to enter "**Options**" can be as follows:

- **Open**      Open the root directory lists the directories and files.

- **Format**      Format the memory card, this action will remove all current flash memory data.

Root directory, select "**Memory Card**", press the **LSK** to enter "**Options**" can be as follows:

- **Open**      Open the root directory lists the directories and files.

- **Format**      Format the memory card, this action will remove all current flash memory data.

- **Details**      more information you can view, such as Name, Total size, free size.

- **Search**      You can search for all files in the file manager.

You can view Photo, copy/move/delete files, rename files and so on. You can send the file through bluetooth.

---

## Tools

---

---

### Torch

---

Select the on or off state to turn on/off the torch light.

---

### Clock

---

- **Alarm**      Select and edit an alarm clock: You can set the setting of alarm on / off, Time, Repeat and Alarm tone. You can choose to set to repeat: Once, Everyday, Custom.

- **World clock**      View local time in different time zones around the

---

world.

**-Stopwatch** You can set a stopwatch for timing.

**-Timer** You can set a countdown timer.

## Ebook

---

You can open the Ebook on your phone or Memory Card to read it. It is a powerful unit converter

## Unit conversion

---

It is a powerful unit converter.

## Sim Toolkits

---

Insert the SIM card, will show STK, if not insert the SIM card does not display this menu.

## Calculator

---

Your phone provides you with the basic arithmetic operations. Press the left soft key "Clear", Press the right softkey "Back" to exit the calculator.

## Calendar

---

Press the up, down, left, and right navigation keys to switch dates. Press the "OK" key to create a calendar reminder, and the calendar information on the screen will be updated accordingly. Press the "Options" option on the left soft key to display the calendar menu.

## Settings

---

### Use Profiles

---

Profiles including General、Silent、Meeting、**Indoor** and Outdoor. First, based on the current scene, select a different profile, then you only need a personal profile can be set and activated.

**General:** General environment.

**Silent:** For Silent environment.

**Meeting:** Vibrate mode.

**Indoor:** Indoor mode.

**Outdoor:** outdoor outdoor.

---

Press the left soft key "Ok":

**Activate:** Enable the selected profile.

**Customize:**

**Ring type:** Ring only/Ring. Only/Vib. **Only/silent.** and ring/Vib.  
**Vib/ring.**

**Ringtone:** According to their own preferences set ringtones, can also be set from the memory card custom ringtones

**Ringtone volume:** In the volume control interface, you can volume up and down navigation keys on the set. Volume level is divided into **nine.**

**Message:** According to their own preferences set ringtones.

**Message volume:** In the volume control interface, you can volume up and down navigation keys on the set. Volume level is divided into **nine.**

**Keypad:** You can set keypad as silent and tone.

**Power ringtone:** You can set power on/off ringtone.

**System alert:** Set it on or off.

---

## Phone settings

Into the phone settings sub-menu, you can make the following settings:

---

### Time and Date

In this menu, you can change the phone time and date settings.

---

### Language

Phone supports many kinds of language for you to select. Set the current language type, then menu and interface refresh for the corresponding language.

---

### Dedicated keys

Set up,down,left and right key for shortcuts.

---

### Auto power on/off

**Set the auto power on/off time.**

---

### Display

**Wallpaper:** Set wallpaper.

**Screen saver settings:** You can set Screen saver.

---

**LCD backlight:** You can set brightness and time.

**Keypad backlight:** Set button off time.

**Auto lock:** Set the screen auto lock time.

## Call settings

---

### Dual SIM settings

---

Dual SIM open

Only SIM1 open

Only SIM2 open

### Flight mode

---

Switch between normal mode and flight mode.

### Call waiting

---

Open this feature, during the call if the new call, the network will notify you. Specific use with your network provider.

- **Activate** launch the function.
- **Deactivate** Close the function.
- **Check status** Check the function's status.

### Call divert

---

Network Call Transfer service allows you to call a business case in a default transferred to a phone number you specify. The features include: Divert all voice calls, Divert if unreachable, Divert if no answer, Divert if busy, Divert all data calls.

### Call barring

---

Into the "Call barring" sub-menu, you can set the following call barring any combination to improve security. Some network providers may not provide this service call restrictions, specific use, please contact your network provider. Network provider will provide a four password so that you can enable call restrictions.

Change the password to enter the old call barring password, set new restrictions on the password.

---

## Advanced settings

---

### Auto redial:

Through on / off settings, to activate or disable the feature. Turned on and when your phone call after another failed attempt to connect up to redial 10 times. This feature can save you the trouble of repeated calls.

### Call time reminder:

**Off:** Close the function.

**Periodic:** Enter any number between 1-60 (sec) , from the input time (in seconds), remind for periodic.

### Reject by SMS:

Turn on this feature, you can choose to reject the SMS when you receive the call.

**Auto record voice call:** Automatic recording during calls.

---

## Security settings

---

Into the "Security Settings" menu, you can set the phone's security options, mobile phone or SIM card to avoid unauthorized use.

### SIM security

---

**PIN lock:** You can set PIN lock on or off by inputting SIM PIN. And you can change PIN and PIN2.

### Phone security

---

**Phone lock:** You can set it on/off.

### Change password:

Change the phone password, enter the old password and then enter a new password. Phone default password is 1234.

## Privacy

---

Encrypt and protect personal data such as contacts, text messages, and photos to ensure that sensitive information will not be leaked even if the device is lost or accessed by others.

### Blacklist:

---

**Reject numbers in blacklist:** You can select on or off.

---

**Blacklist numbers:** You can add blacklist numbers.

---

## Network settings

### SIM1/SIM2:

Network selection(Automatic/Manual)

Data service(on/off data services)

Network type(Switch data type)

---

## Restore settings

In this menu, enter the password, once determined, the phone automatically reboot the phone after the relevant parameters can be set to return to default settings. The default password is 1234.

## Extras

---

### Internet

Browsing web pages through mobile data.

---

## Game

### Snake

Press the OK button to start or pause the game; Press the up, down, left, and right keys to move the direction.

#### 15.19 Labeling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### 15.21 Information to user.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### 15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### Absorption Rate (SAR) information:

This mobile phone meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health. FCC RF Exposure Information and Statement The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. This device was tested for typical body-worn operations with the back of the handset kept 1.0cm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 1.0cm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

#### Body-worn Operation

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 1.0 cm must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.