

MAXIMUM HEAT!

TYCO R/C 6.0V JET TURBO

Change Photo

OWNER'S MANUAL

PLEASE READ THOROUGHLY BEFORE OPERATING YOUR VEHICLE

6.0V JET TURBO

New Beetle

TYCO R/C SERVICE CENTER



WE CARE!

If you have questions or difficulty operating this vehicle,

DO NOT RETURN IT TO THE STORE!

Call Toll-Free **1-888-557-TYCO (1-888-557-8926)** (US only)

Freephone: **0800 212751** (UK only)

for technical help, or **RAPID** parts and service assistance.

30648-1920



Model No. 32848 (Blue-27MHz) (U.S.A. only)



Model No. 30712 (Black-49MHz) (U.S.A. only)



Model No. 36510 (Blue-27MHz) (U.K. only)

FEATURES

- 8 functions
- Available in 2 frequencies: 27 MHz and 49 MHz (27 MHz only in U.K.)
- Water-spitting, transforming snake-head
- Range up to 65 feet (20 m)

CONTENTS




(1) Transmitter




(1) 6.0V Jet Turbo PYTHON Vehicle

BOTTOM VIEW



TRANSMITTER

NOTE: Your transmitter is equipped with a special automatic "ON" battery-saving feature. Just turn your vehicle "ON." Then push either transmitter stick and you will be able to run and control your vehicle.



Refer to label on transmitter and vehicle for frequency. Do not race vehicles with the same frequency.