



Bluetooth Speaker Model:M52

Warning

- 1. Do NOT expose product to extreme temperatures, moisture or electric shock.
- 2. Do NOT attempt to open the unit for any reason. Do NOT attempt to manipulate any electrical components in the unit.
- 3. Do NOT attempt to use if internal components have been exposed to liquid.

Package includes

1x Bluetooth Speaker 1x Micro Charging Cable
1x User Manual Output power: 3.5W*2 Bluetooth chip: CSR4.0 8635 Frequency response: 90Hz~20kHz Impedance: 4OHM Sensitive: 80dB±2dB S/NRation: ≥80dB Distortion: ≤0.3% Input power: USB 5V 2000mAh lithium battery Size:155*50*50mm

Product Features

Specifications:

- Advanced Waterproof (IPX6) Protection
 Clear hands-free functionality via built-in
- Aux-in function. Bass radiation system for powerful sound
- performance
 LED indicator light for easy pairing
 Built-in 18650 1800mAh Lion battery.

Power On/Off function

The ON/OFF button is on the right of speaker. You can power on/off the speaker by pressing it for 2 seconds.

Pairing the Device:

- Power on the Bluetooth speaker; you will hear a "beep" sound with the blue LED flashing quickly. Then you can start to pair
- flashing quickly. Then you can start to pair with other BT devices.

 2. Use your mobile phone or other BT devices to search the speaker name "Ruggex." After a successful connection, the blue LED light will begin to flash more slowly. The product is then fully paired.

 3. Short Press ">>" to skip to next song.

 4. Short Press "<<" to go back to last song.

 5. Long Press "+" to increase the volume.

 6. Long Press"-" to decrease the volume.
- 6. Long Press"-" to decrease the volume.
 7. Press "*" to pause the music; press it

Hands-free Function:

again to play.

When you receive a phone call, you can press the "*" button to pick up the phone call, and then press it for several seconds to hang

Charging Function:

NOTE: Our Ruggex speaker includes a battery monitoring function.

- When you hear an intermittent "beep" sound, it means the battery is low and it needs to be charged immediately by using the USB cable charger, 5V adapter or
- ψ Please turn off the speaker unit when not
- maximum volume for an extended period of

Frequently Asked Questions

- Failure to connect to a Bluetooth-enabled device can be caused by: Other Bluetooth devices are in pairing or sync mode and are interfering with your connection. Please remove other devices from the vicinity or turn them off.
- Static or muffled sound can be caused by
- any of the following:

 1. There are major Bluetooth
 obstructions between your device
- and the speaker.

 2. You have extended the Bluetooth speaker beyond the recommended distance between devices.

Product Warranty

This product comes with a limited one year warranty from date of purchase. This warranty covers any product failures and offers a replacement guarantee. All warranties are handled by the authorized reseller. Please contact your authorized reseller with receipt to process a replacement.

This replacement.

This replacement guarantee does not imply any liability for any product-related damages.

Please use responsibly.

For product related inquiries, please email us at info@francoisetmimi.com with proof of purplesse.

FCC NOTE:

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference. including interference that may cause undesired

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS OR CHANGE TO THIS EQUIPMENT. SUCH MODIFICATIONS OR CHANGE COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.