

User's Manual

Mobile Phone K373 Bmobile

Dear customer:

Thank you for choosing this mobile phone. This mobile phone incorporates the latest world advanced functions, enabling simple and convenient operation, satisfying your special requirements.

The mobile phone supports T-FLASH (memory) card and two SIM standby. It integrates the following available functions: SMS, MP3, MP4, Camera, FM radio, Video recorder and Calendar, enabling you arranging your work, study and life freely; with long standby duration, as well as Alarm and Calculator, your communication will be easier and smoother; powerful File manager allows you managing the files conveniently. In addition, the chord ringtone allows you selecting music to set as ringtone; the personalized appearance also can satisfy your selection.

Note: *User's Manual is just to guide the user about the functionality of the phone. Some functions may vary due to*

modifications and up gradations of software or due to print mistake.

Contents

Keys functions.....	1
Call	2
Phonebook.....	3
Call center	4
Multimedia	5
Messages	6
File Manager	7
Tools.....	8
Games.....	9
Services	10
Settings.....	11
Profiles	12
SAFETY PRECAUTIONS	13

Keys functions

Keys	Functions
Left soft key	Press this key to enter the main menu under standby mode; Press this key to confirm the function you choose; Press this key to answer a call
Right soft key	Press this key to enter phonebook list under standby mode; Press this key to go back to previous menu; Press this key to reject a call.
Call key	Press this key to call out; Press to pick up phone when there is an incoming call; Press to enter call logs under standby mode.
End key	Power Off: Long press to power off under standby mode; Power On: Long press to power on if the phone is power off; Press this key to go back to standby screen.
Navigation keys	Press them to scroll the options when browsing a function list. In edit state, press direction keys to navigate. Under standby mode, press a direction key to enter the specified function page. You can also customize direction keys to match the desired functions. In conversation status, press up or down direction key to tune the sound volume.
OK key	Press OK key to confirm and enter main menu. Under standby mode, long press this key to open/close the torch.
Number keys	Dial numbers under standby mode and enter numbers and characters in editing mode.
* key	Under standby mode, press * key twice to display “+” to call international numbers ”P” and “W” to call extension numbers. Help to lock the keypad with pressing left soft key first. Under players and FM mode, press * key to decrease volume.
# key	Under standby mode, press and hold this key to switch between current profile, silent profile. Under players and FM mode, press # key to increase volume.

Call

Under standby interface, input a phone number and press Call key to make a call. To end or reject a receiving call, press the End key.

Phonebook

Phone contact can store up to 300 phone numbers, while SIM cards contact capacity depends on the network operator, please consult the local operator.

Call center

In the main menu, you can enter call logs to view missed calls/dialed calls/received calls/all calls/delete call logs. You can also press call key to enter call logs.

Multimedia

◆ Camera

Camera supports photographing function. you can take pictures

with the embedded camera and adjust the camera settings. The camera lens is in the rear side of the mobile phone and the screen is the viewfinder window. The pictures are taken in JPG format. After downloading to PC, please view with appropriate software. If the mobile phone memory is insufficient, please delete certain pictures or other files in “File manager”.

◆ **Image viewer**

With this function, you can select any picture and press left soft key to perform the following operations: View, Use as, Rename, Delete and Image information.

◆ **Video recorder**

Press OK key to start video recording. The recording time depends on the time limit and the capacity of the memory card. Enter options to perform the following settings: Switch to camera, Camcorder setting, Video settings.

◆ **Video player**

Enter Video player. Press left soft key to enter options: Play, Rename and Delete.

◆ **Sound recorder**

Enter Sound Recorder, Enter Sound recorder. press left soft key and you can do: New record, List.

◆ **FM radio**

To use the FM Radio, please insert the earphone first and then listen to it. You can perform the followings operations as your need: Channel list, Manual input, Auto search, Settings.

Messages

Enter this menu, you can view: Write message, Inbox, Drafts, Outbox, Sent messages and SMS settings. The capacity of messages is due to maximum storage capacity built in mobile phone and external SIM cards. And you can check the Memory status of the SIM cards or mobile phone.

File Manager

File Manager explores the files in phone and external memory card. In this menu, you can manage the pictures, MP3 files and other folders etc in this menu.

- ❖ Audio – Audio folder
- ❖ Photos – Photo folder

- ❖ Videos – Video folder
- ❖ My Music – MP3 folder

Tools

This function provides different kinds of services kinds of services including Calendar, Alarm, Calculator, Torch. It is convenient and good for you to arrange your life orderly every day and make your life become lively and beautiful.

Games

The mobile phone provides one inbuilt game: Snake.

Please refer to instructions in the game for details.

Services

Use this function after you insert SIM, enter from menu screen, there are 2 options: Internet service and present SIM information (depends on operator).

Settings

- ◆ Phone settings: In this menu, you can perform: Time and date; Language; Pref.input method; Display; Dedicated keys ; Flight mode ; Misc settings.
- ◆ Network settings: You can set network in settings menu.
- ◆ Security settings: To protect personal privacy, you can set the SIM security, Phone security, Privacy protection, Auto keypad lock and Mobile tracker.
- ◆ Connectivity: You can set Network parameters in settings menu.
- ◆ Restore factory settings: To reset the factory setting, please input the password '1122'.

Profiles

Profiles: This mobile phone is provided with several profiles. You can customize the ringtone according to events and environment. You can customize a profile and activate it. Available options are:

- ❖ General
- ❖ Silent

- ❖ Meeting
- ❖ Outdoor

SAFETY PRECAUTIONS

Please read the following safety guidelines before using the device.

1. Do not use the phone while you are driving.
2. Do not place magnetic storage media near your phone.
Radiation from the phone may erase the information stored on them.
3. Keep your phone and its accessories away from children.
4. Mobile phones can interfere with the functioning of medical devices such as hearing aids or pacemakers.
5. People having active medical implants should keep their cell phone at least 15 cm away from the implant.
6. Permanent hearing loss may occur if you use earphones or headphones at high volume.

This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance

could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Specific Absorption Rate (SAR) information:

This Mobile Phone meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health.

FCC RF Exposure Information and Statement The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: **K373** (FCC ID: ZSW-10-019) has also

been tested against this SAR limit. The highest SAR value reported under this standard during product certification for use at the ear is 1.377W/kg and when properly worn on the body is 0.674W/kg. This device was tested for typical body-worn operations with the back of the handset kept 10mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 10mm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

Body-worn Operation

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 10mm must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.