




EVC156-1 & EVC156-2
www.evooproducts.com

Start Here

01

Plug Power Adapter Into Wall Outlet




02

Plug Power Adapter Into Laptop



03



Plug Power Adapter Into Laptop



04

Follow the on screen Windows prompts to finish setting up

Exterior Features



- | | |
|------------------|--------------------|
| 1 Power Button | 7 USB 3.0 |
| 2 LCD Screen | 8 USB 3.0 |
| 3 Camera | 9 Power Connector |
| 4 Touchpad | 10 HDMI Output |
| 5 Micro SD Slot | 11 Kensington Lock |
| 6 Headphone Port | |

What's in the box

- | | |
|-----------------|---------------------|
| 1 Laptop | 3 Warranty Book |
| 2 Power Adapter | 4 Quick Start Guide |

Caution: The AC adapter included with your PC was specifically designed and approved for your model. Utilization of an after-market adapter may damage either the notebook or other devices connected to it. If damage is determined to have been caused by utilization of an unauthorized power supply, it will not be protected under warranty.

EVOO customer service center directly at CustomerService@evooproducts.com or call (888) 999-1682.



Note: The grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. Such modifications could void the user's authority to operate the equipment.

EVC156-1 & EVC156-2
www.evooproducts.com