




Label and Label Location

Label on the EUT:



E-label:

Go to **Settings** and touch **System** > **Certification logos** to view more information on certification logos for your product.



Label Location:

Bottom side marked red as below

