

User's manual  
Gebrauchsanweisung  
Manual para el usuario



*SoyMomo*

Space 3.0





ENGLISH



DEUTSCH



ESPAÑOL



ENGLISH



Space 3.0

Welcome



## English instructions

Thank you for choosing SoyMomo. We look forward to accompanying you on your safe journey through the **world of technology**.

# First steps




## 1 Charge your SoyMomo Space 3.0 for 4 hours.

Connect the charging station to the mains and place the clock module. Make sure the magnetic charger sits firmly on the device. A battery charging animation will appear on the screen of your SoyMomo Space 3.0.



## 2 Activate your NanoSIM card from your mobile, following the instructions of your telephone line.

Write down and save the phone number, you can occupy our SoyMomo SIM included in the box.



**3**


### Open the SIM holder that is on the side of the device

With the screwdriver included in the package, open the SIM cover (1). Use the spudger to remove the SIM tray (2). Insert the nano SIM into the slot (3) and insert it into the device (4). Finally, screw the cover back on.

**4**

### Insert the tray with the activated NanoSIM card into the SoyMoom Space 3.0, in the indicated position:

SoyMomo Space 3.0 must be turned off when inserting the NanoSIM, otherwise it will not detect it. (SoyMomo Space 3.0 watch: settings > Turn off)



Verify that it is well sealed against water and splashes.

**5**

### Insert the cell phone or watch module into the strap

With the SIM well in place, you can now use the shock strap of your SoyMomo.

6

## Download the parental control App SoyMomo- app for parents

From your app store, this step is important to control your Space 3.0.



Android ≥ 5.0

iOS ≥ 14.1

Google play

App Store

QR app:



7

## Link the watch to the app with the IMEI code

Enter the Application, log in and follow the steps to pair your SoyMoo Space 3.0 using the IMEI code on the back of the device.



IMEI: 869609039951586

IMEI:  
15-Digit code

8

## Turn on your SoyMomo Space 3.0

Confirm that your SoyMomo Space 3.0 has detected the NanoSIM, checking that the 4G connection icon appears.

SoyMomo Space 3.0 works with a balance of minutes to make calls and data (megs) to fulfill other functions such as: chat, send the GPS position to your phone and receive settings you make from the Parent App.



## Device



Loading port

## Charging dock



Charger  
magnetic

**You can remove the charging cable  
from the charging station**

# Icons Space 3.0



Sound



Silence



Vibration



% battery



Charging



No signal



Sign



No SIM



Alarm



No GPS



GPS signal



WiFi



No Wifi















## How to turn the device on and off?

It can be turned on from the SoyMomo Space 3.0 (SOS) button and turned off from "Settings". In case you want to turn off the SoyMomo Space 3.0 remotely you can go to the APP > Settings Turn off.

## How to send an SOS alert?

Press and hold the SOS button of your SoyMomo Space 3.0 for 5 seconds and a help notification will be sent to the linked users. If you have configured the SOS contact, an automatic call to the contact will also be generated.

## Why is the GPS location not correct? What is the precision?

To see the location at all times, the NanoSIM needs to have data balance. The device obtains the location in different ways:

- 1 By GPS module. It works when you are outdoors and has an accuracy of 20m.**
- 2 Triangulation of cellular and WiFi networks. This method has an accuracy of up to 150m.**

**Remember that every location is referential and is subject to a range of error.**









## Maker

### **SoyMomo Inc.**

304 Palermo Ave | Coral Gables, Florida | 33134  
[www.soymomo.com](http://www.soymomo.com) | [contact@soymomo.com](mailto:contact@soymomo.com)

### **SoyMomo S.L.**

Rambla Catalunya 77, SA 2, 08007, Barcelona, Spain  
[www.soymomo.com](http://www.soymomo.com) | [contacto@soymomo.com](mailto:contacto@soymomo.com)

### **SoyMomo S.A.**

Ricardo Lyon 1688, Providencia, Santiago  
[www.soymomo.com](http://www.soymomo.com) | [contacto@soymomo.com](mailto:contacto@soymomo.com)

## FCC Caution

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.





*SoyMomo*

✦ Space 3.0 ✦

DEUTSCH



Space 3.0

Willkommen



## Deutsch lehrreich

Vielen Dank, dass Sie sich für SoyMomo entschieden haben. Wir freuen uns darauf, Sie auf Ihrer sicheren Reise durch die Welt der Technik zu begleiten.











# Weltraumsymbole 3.0



Klang



Schweigen



Vibration



% Batterie



Aufladen



Kein Signal



Zeichen



Keine Sim



Alarm



KEIN GPS



GPS-Signal



WiFi



kein WLAN



























*SoyMomo*

✦ Space 3.0 ✦







































