


Test positions for body:

According to the antenna position, the Body SAR is tested at the following 10 test positions between the EUT and the phantom bottom :



Toward Phantom (5mm)



Toward Ground (5mm)




Toward Left (5mm)



Toward Right (5mm)



Toward Top (5mm)




Toward Phantom (0mm)



Toward Ground (0mm)



Toward Left (0mm)



Toward Right (0mm)



Toward Top (0mm)