






NTNV-n77(3450-3550)-PC2-30-60-H-CP-QPSK-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-60-H-CP-16QAM-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-60-H-CP-64QAM-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-60-H-CP-256QAM-Outer\_Full-Ant1-PASS









NTNV-n77(3450-3550)-PC2-30-70-L-CP-256QAM-  
Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-70-M-DFT-BPSK-  
Outer\_Full-Ant1-PASS





NTNV-n77(3450-3550)-PC2-30-70-M-DFT-QPSK-  
Outer\_Full-Ant1-PASS





NTNV-n77(3450-3550)-PC2-30-70-M-DFT-16QAM-  
Outer\_Full-Ant1-PASS




















NTNV-n77(3450-3550)-PC2-30-80-M-DFT-BPSK-  
Outer\_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-80-M-DFT-QPSK-  
Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-80-M-DFT-16QAM-  
Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-80-M-DFT-64QAM-  
Outer\_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-80-M-DFT-256QAM-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-80-M-CP-QPSK-Outer\_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-80-M-CP-16QAM-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-80-M-CP-64QAM-Outer\_Full-Ant1-PASS







NTNV-n77(3450-3550)-PC2-30-80-H-DFT-64QAM-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-80-H-DFT-256QAM-Outer\_Full-Ant1-PASS





NTNV-n77(3450-3550)-PC2-30-80-H-CP-QPSK-Outer\_Full-Ant1-PASS





NTNV-n77(3450-3550)-PC2-30-80-H-CP-16QAM-Outer\_Full-Ant1-PASS














NTNV-n77(3450-3550)-PC2-30-90-H-DFT-BPSK-  
Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-90-H-DFT-QPSK-  
Outer\_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-90-H-DFT-16QAM-  
Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-90-H-DFT-64QAM-  
Outer\_Full-Ant1-PASS





NTNV-n77(3450-3550)-PC2-30-90-H-CP-256QAM-  
Outer\_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-100-L-DFT-BPSK-  
Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-100-L-DFT-QPSK-  
Outer\_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-100-L-DFT-16QAM-  
Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-100-L-DFT-64QAM-  
Outer\_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-100-L-DFT-256QAM-  
Outer\_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-100-L-CP-QPSK-  
Outer\_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-100-L-CP-16QAM-  
Outer\_Full-Ant1-PASS

