

Wireless Microphone

H16

User Manual

ID Diagram

- ① Microphone lid
- ② Power on/off button
- ③ Charging lamp
- ④ Connection indicator light
- ⑤ Noise reduction indicator light
- ⑥ Noise reduction indicator light
- ⑦ Noise indicator light
- ⑧ Charging indicator
- ⑨ Indicator 1"
- ⑩ Indicator 1"
- ⑪ Charging indicator
- ⑫ Indicator 1"
- ⑬ Indicator 1"
- ⑭ Indicator 1"

- ⑮ Indicator 1"
- ⑯ Charging indicator
- ⑰ Indicator 1"
- ⑱ Indicator 1"
- ⑲ Indicator 1"
- ⑳ Indicator 1"
- ㉑ Indicator 1"
- ㉒ Indicator 1"
- ㉓ Indicator 1"
- ㉔ Indicator 1"
- ㉕ Indicator 1"
- ㉖ Indicator 1"
- ㉗ Indicator 1"
- ㉘ Indicator 1"
- ㉙ Indicator 1"

ID Diagram

Step 1: Long press the power button on the microphone, and the connection indicator light will light up, indicating successful power on. Step 2: Connect one end of the receiving end to the phone receiver. Step 3: The indicator light for the connection between the receiver and transmitter turns on, indicating a successful connection. Open the camera lens, position up on your phone and use the microphone in turn.

About UI

Microphone Transmitter

State	Operation	LED
Power on	Automatic startup after opening the microphone and hold the power button for 3 seconds to start up	The green light in the connection indicator is flashing
Power off	Automatic shutdown after pressing the power button for 3 seconds to start up	All lights off
Not connected	Automatic shutdown after pressing the power button for 3 seconds to start up	The green light in the connection indicator is flashing
Connection established	Automatic shutdown after pressing the power button for 3 seconds to start up	The green light in the connection indicator is flashing
Noise reduction	Click the noise reduction button to turn on/off noise reduction. The green light in the noise reduction indicator is flashing. Double-click the noise reduction button to turn on/off noise reduction. The green light in the noise reduction indicator is flashing.	The green light in the noise reduction indicator is flashing. The green light in the noise reduction indicator is flashing.
Microphone	Click the microphone button to turn on/off microphone. The green light in the microphone indicator is flashing.	The green light in the microphone indicator is flashing.
Mode	Click the mode button	The green light in the mode indicator is flashing.
Charge		The red light in the charging indicator is flashing.
Full charged		The red light in the charging indicator is off.
Low battery		The red light in the charging indicator is flashing.

Note: Noise reduction will remove function, requiring the machine will remember the settings before the last shutdown.

About UI

Receiver

State	Operation	LED
Power on	Automatic startup after opening the receiver and hold the power button for 3 seconds to start up	The green light in the connection indicator is flashing.
Power off	Automatic shutdown after pressing the power button for 3 seconds to start up	All lights off
Not connected	Automatic shutdown after pressing the power button for 3 seconds to start up	The green light in the connection indicator is flashing.
Connection established	Automatic shutdown after pressing the power button for 3 seconds to start up	The green light in the connection indicator is flashing.

Packing List

Content of packing

- ① Microphone transmitter
- ② Receiver
- ③ Charging cable
- ④ Charging cable
- ⑤ User Manual

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

If this equipment does cause harmful interference to radio or television reception,

- Reorient or relocate the receiving antenna.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

The device has been evaluated to meet general RF exposure requirements.