



## 802.11ax-HE20 – Ant 2

## Channel 105 (6475MHz) RU26/4

## The Reference Level



## The Mask Data




## Channel 105 (6475MHz) RU52/38

## The Reference Level




## The Mask Data




## Channel 105 (6475MHz) RU106/53

## The Reference Level




## The Mask Data




## 802.11ax-HE20 – Ant 2

## Channel 113 (6515MHz) RU26/8

## The Reference Level




## The Mask Data




## Channel 113 (6515MHz) RU52/40

## The Reference Level




## The Mask Data




## Channel 113 (6515MHz) RU106/54

## The Reference Level




## The Mask Data




## 802.11ax-HE20 – Ant 2

## Channel 117 (6535MHz) RU26/0

## The Reference Level




## The Mask Data




## Channel 117 (6535MHz) RU52/37

## The Reference Level




## The Mask Data




## Channel 117 (6535MHz) RU106/53

## The Reference Level




## The Mask Data




## 802.11ax-HE20 – Ant 2

## Channel 149 (6695MHz) RU26/4

## The Reference Level




## The Mask Data




## Channel 149 (6695MHz) RU52/38

## The Reference Level




## The Mask Data




## Channel 149 (6695MHz) RU106/53

## The Reference Level



## The Mask Data




## 802.11ax-HE20 – Ant 2

## Channel 181 (6855MHz) RU26/8

## The Reference Level




## The Mask Data




## Channel 181 (6855MHz) RU52/40

## The Reference Level




## The Mask Data




## Channel 181 (6855MHz) RU106/54

## The Reference Level




## The Mask Data




## 802.11ax-HE20 – Ant 2

## Channel 185 (6875MHz) RU26/8

## The Reference Level




## The Mask Data




## Channel 185 (6875MHz) RU52/40

## The Reference Level




## The Mask Data




## Channel 185 (6875MHz) RU106/54

## The Reference Level




## The Mask Data




## 802.11ax-HE20 – Ant 2

## Channel 189 (6895MHz) RU26/0

## The Reference Level




## The Mask Data




## Channel 189 (6895MHz) RU52/37

## The Reference Level




## The Mask Data




## Channel 189 (6895MHz) RU106/53

## The Reference Level




## The Mask Data




## 802.11ax-HE20 – Ant 2

## Channel 209 (6995MHz) RU26/4

## The Reference Level




## The Mask Data




## Channel 209 (6995MHz) RU52/38

## The Reference Level




## The Mask Data




## Channel 209 (6995MHz) RU106/53

## The Reference Level




## The Mask Data




## 802.11ax-HE20 – Ant 2

## Channel 233 (7115MHz) RU26/8

## The Reference Level




## The Mask Data




## Channel 233 (7115MHz) RU52/40

## The Reference Level




## The Mask Data




## Channel 233 (7115MHz) RU106/54

## The Reference Level




## The Mask Data




## 802.11ax-HE40 – Ant 2

## Channel 3 (5965MHz) RU242/61

## The Reference Level




## The Mask Data




## Channel 51 (6205MHz) RU242/61

## The Reference Level




## The Mask Data




## 802.11ax-HE40 – Ant 2

## Channel 91 (6405MHz) RU242/62

## The Reference Level




## The Mask Data




## Channel 99 (6445MHz) RU242/61

## The Reference Level




## The Mask Data



## Channel 107 (6485MHz) RU242/62

## The Reference Level



## The Mask Data

