

Please read the instructions before use

1. Take out the earbuds (Earbuds auto power on)

2. After open the phone Bluetooth, Click the **<N19>** to Pairing

**Reset**

If earbuds has any connection or function problems,  
please reset the earbuds

1. In the power-on state, quickly press the MFB button 5 times.
2. Turn off the headset after hearing the "Power off".
3. The reset will be successful after rebooting.

(If the above operation does not work, please try again)

The diagram shows the side button and Digital Crown of an Apple Watch. The side button is a small, rectangular button on the right side of the watch case. The Digital Crown is a larger, circular button on the top of the watch case. The functions for each are as follows:

- Side Button:**
  - X2:** Play / Pause
  - X3:** Voice Assistant (Siri)
  - X1:** Answer
  - 2S:** Reject Call / Hang up
  - 5S:** Power on/off
- Digital Crown:**
  - 5S:** Power on/off

Switch Song      Adjust Volume

<b>X1:</b> Click Once	<b>Ⓛ2S:</b> Press and hold for 2 seconds
<b>X2:</b> Click 2 times	<b>Ⓛ3S:</b> Press and hold for 3 seconds

- 1 **Can be connected but there is no sound:**  
Click the headset to increase the volume.
- 2 **Headset cannot be charge:**  
Clean the charging contact of the headset and the charging case.
- 3 **Headset cannot be connected:**  
Reset the headset.

### Activation & Warranty

Permanent replacement of damaged, defective item or missing components. Please activate via email below within 15 days.

1. Keep the product away from extremely hot and cold environments, it will damage the battery and circuit.
2. Avoid liquid immersion into the product.
3. Do not disassemble the product.
4. Do not use concentrated chemical products or detergents to clean the product.
5. Use only 5V/1A power supply. Connecting the power supply voltage too high may cause serious damage.
6. Do not randomly discard or place the product near fire or high temperature to avoid the danger of explosion.









**warning:**

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions :  
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**FCC Statement:**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures :

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to a power outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.