


SP-0215 Wireless Speaker Manual


20DEC22

Size: H: 100mm x W: 387mm




Instruction Manual

Thank you for purchasing the Vocal+ Wireless Karaoke Speaker. This manual provides more information about this wireless speaker, please read the instructions before using.



Product Overview



1 On/Off switch
2 Micro USB Charging port
3 Mode Button
4 Microphone Aux-in ports

Package Contents

1(One) Wireless Speaker 12.5in. x 9.44in. x 4.5in. (31.9cm x 24cm x 11.5cm)
2(Two) Wired Microphones 74.4in. (189cm) Full Length
1(One) Micro-USB Charging Cable 19.7in. (50cm)
1(One) Instruction Manual

Power ON/OFF

Power on
Slide the ON/OFF switch to the "ON" position.

Power off
Slide the ON/OFF switch to the "OFF" position.


Pair Wireless speaker with your mobile device

1. Keep the distance between your wireless speaker and mobile phone (or other devices) within 32.8 Feet.
2. Power on the wireless speaker.
3. Activate the Bluetooth function on your phone within range and select "BT VOCAL SPEAKER" from the list shown.
4. You will hear a beep sound when pairing is successful.

Reconnect Wireless speaker to your mobile device


When powered on, the wireless speaker will automatically connect with the last successfully paired device.

Microphone Hanger Installation



Install the microphone hanger to the left and right panel

Microphone Installation



Plug the 6.5mm jack of the microphones to the Mic Aux-in ports

Technical Specification

Driver Diameter : 102 mm
Impedance : 4 Ohms
Playing Time : 3.5 - 4 Hours
Charging Time : 2 - 2.5 Hours
Power Supply : Li-Ion Battery 3.7V 1200 mAh
Bluetooth Range : 32.8 feet

Mic Aux-in Port : 6.5 mm x 2
Wired Mic Cable Length : 6.2 feet
Micro USB Charging Cable Included

TWS Connection

(Need 2pcs Vocal+ Wireless Karaoke Speaker to perform this function.)

1. Make sure all Vocal+ Wireless Karaoke Speaker are unpaired from Bluetooth devices.
2. Turn off both Vocal+ Wireless Karaoke Speaker.
3. Turn on both Vocal+ Wireless Karaoke Speaker, both Speakers' LED indicator will flash in Blue.
4. Vocal+ Wireless Karaoke Speaker will automatically connect each other in 30 seconds with a tone. One of the LED indicator will stop flash.
5. The Vocal+ Wireless Karaoke Speaker with a flashing Blue LED is Host Speaker, only Host speaker will connect with Bluetooth devices.
6. Follow "Pair Wireless speaker with your mobile device" to pair Vocal+ Wireless Karaoke Speaker.

FM Radio Mode

Switch to FM mode

- Press and hold the Mode button until the speaker responded with a tone.
- Press and hold again will back to Bluetooth mode.

Next Channel

- Short press the Mode button once.

Auto Scan

- Short press the Mode button twice.

Volume Up

- Short press the Mode button three times.

Volume Down


- Short press the Mode button four times.

Charging your Wireless speaker

1. Use the Micro USB charging cable provided with this wireless speaker.
2. Connect the Micro USB plug to Micro USB charging port on the speaker, then connect the USB plug to a USB port on a computer or wall adapter to begin charging.
3. The light will turn red while charging and will turn off once fully charged.

NOTE:

- You must select a qualified charger from a regular manufacturer.
- You must charge the Wireless speaker if it has been used for more than 6 months.



FAQ

- ◆ **If the Wireless speaker cannot be paired with your device, please try the following:**
Ensure that your speaker is in pairing mode or reconnection mode.
Ensure that Bluetooth search function of your mobile device is activated.
- ◆ **If the Wireless speaker cannot be recharged:**
If you use a power outlet, ensure that the power supply is connected securely and the outlet works. If you use a computer, ensure that it is connected and the USB port is powered.

⚠ Safety instructions for the lithium battery and charging the product

- The input voltage to the product is DC 5V 1A.
- In order to charge the product in safe manner and reliable conditions, please only adopt certified appropriate charger/ adapter for charging the product.
- Only charge the product at ambient temperatures between 10 deg °C/ 50 deg °F and 40 deg °C/ 104 deg °F.
- Do not heat above 70 deg °C/ 158 deg °F, eg. Do not expose to sunlight or throw into fire.
- Switch off the product after use.
- Please note that we won't take any responsibility for any wrong operation (eg. Voltage higher than 5V) as this may result in severe injury or loss of property, and we cannot control the operating process during the time the user using this product.
- In extreme cases, abuse or misuse of Lithium battery pack can lead to explosion, heat generation, fire development or smoke development.

FCC STATEMENT


1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:
The device has been evaluated to meet general RF exposure requirement. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.



FCC ID: 2ADM5-SP-0215

Item# SP-0215

Class 1 LED product

Keep All Relevant Information for Future Reference

Distributed by 1616 Holdings, Inc.
701 Market Street, Suite 200
Philadelphia, PA 19106