Read the manual before use

If you have any questions, please contact the customer service to deal with them immediately Please do not make negative comments at will. Our service is up to your satisfaction

Important: Plug in the charging wire for charging at the first time after receiving the goods, and use it after fully charging, which can make the Bluetooth headset last longer

Important: Do not use super fast charging with current above 2A to avoid damaging the circuit chip due to excessive current



Open the lid and take out the two headphones. The headphones flash alternately from blue and white to blue and white alternately and slowly. The pairing is successful





When the connection to the mobile phone is successful, the two headphone lights go of

Headphone touch control position inside red circle



If there is a delay in the course of the game, you can quickly touch four times to switch to game mode to reduce the delay

If only one earphone has sound, contact customer service to send you an operation tutorial, which will not be refunded for free

mportant: Plug in the charging wire for charging at the first time after receiving the goods, an use it after fully charging, which can make the Bluetooth headset last longer

Important: Do not use super fast charging with current above 2A to avoid damaging the circuchip due to excessive current

The connection steps are as follows:

Take two headphones out of the charging box. The headset will automatically switch on the power supply and pair, wait for the pairing of two headphones to flash alternately, and the pairing successfully turns into a blue and white light alternately slow, then you can turn on your mobile phone Bluetooth search for "SP23" and click on the connection.

Touch function

- 1. Click on the headphone touch area: pause/play
- Double-click the headphone touch area: add/ subtract volume
- 3. Triple tap headphone touch area: Up/Next song. 4. Four-tap headphone touch zone: switch game/
- Four-tap headphone touch zone: switch game music mode
- 5. Long 2 seconds touch zone: summon Siri

Headphone touch control position



Charging method:

Plug in the cable we sent, and be sure to plug it in to the bottom. There are four white lights at the bottom, each representing 25% of the power. When charging, the corresponding white light flashes slowly. When charging, one light is always on, increase the power by 25%, until the four lights are fully on, then it is full.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 -Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

If you find that you do not like or will not use the goods, remember to contact the store customer service to teach you how to use them. If you do not like to return the goods and remember to choose another reason for returning, this is very important to us. Thank you.

If you find that you do not like or will not use the goods, remember to contact the store customer service to teach you how to use them. If you do not like to return the goods and remember to choose another reason for returning, this is very important to us. Thank you.