































SM3S3S-707A

CASIO

R34	C9	R35	R44
R31	R33	R32	R45
C18	R36	C24	R46

IC1

C101 C102
C26 C20
C19 C25

RAM2

NEC JAPAN
D30122F1
VR4122
0020K3901

WJE122BA
K4S281632B-NL1L
SAMSUNG 028

X1 C10 R3 R41

intel
E28F128
J3A150
A0330087B
© © 1999

Flash

A2

R9 C15 R8 C16 R13 R18 R25 R28
R10 R14 R17
R16 R43
TP1 R10 TP2
R28 R19 R29 R24
C3
A9 001
A9 001
C23 C28
R40 C6

C17 R37
R39 R38

CECL 5VC ROM2



