

FLASHRACERS™

LIGHT SPINNER™


AGES 5+
51615 RST 1



CAUTION:

Hair entanglement may result if child's hair comes in contact with moving parts of toy. Adult supervision is required.

Battery Requirements
LIGHT SPINNER™:
 Six (6) "AAA"
 LR03 / UM4 / 1.5V B.C.
 batteries (not included)
 Six (6) "AA"
 LR6 / UM3 / 1.5V B.C.
 batteries (not included)
Transmitter:
 Six (6) "AA" / LR6 / UM3 / 1.5V B.C.
 batteries (not included)



TRANSMITTER



LIGHT SPINNER™

OPERATING PRECAUTIONS


Adults, to ensure that the child's play is both safe and fun, please review operating instructions and the following safety rules before operating vehicle.

- Do not pick up vehicle while in motion.
 - Keep fingers, hair and loose clothing away from the tires and the wheel hubs while the vehicle is in operation.
 - To avoid accidental operation, remove batteries when not in use.
1. Radio interference is caused by the presence of another radio-controlled vehicle operating on the same frequency as your vehicle.
 2. Radio interference can be caused by the operation of your vehicle near high voltage electrical wires, large steel reinforced concrete buildings and passing trucks with CB radios.
 3. DO NOT operate your vehicle over wet surfaces. Water can damage the internal electronic assemblies.
 4. DO NOT drive your remote control vehicle into people.
 5. For best results, hold antenna up, not pointed down toward the R/C vehicle. Too far away from the transmitter, your signal strength will become weak and the vehicle will not function properly.

BATTERY REQUIREMENTS & INSTALLATION

Vehicle and Transmitter

1. Remove the battery compartments cover using a Phillips / crosshead screwdriver (not included) as shown.
2. Insert 3 x "AAA" (not included), 6 x "AA" batteries (not included) and 1 x "9V" battery (not included) as shown in diagram, making sure to match the polarity direction.
3. Replace the battery covers.



CAUTION:

- * As with all small batteries, the batteries used with this toy should be kept away from small children who will put things in their mouths. If they are swallowed, promptly see a doctor and, in Canada, have the doctor call your provincial Poison Control Centre.
- * Make sure the batteries are inserted correctly and always follow the toy and battery manufacturers' instructions.
- * Do not mix old batteries and new batteries or alkaline, standard (carbon zinc) or rechargeable (nickel-cadmium) batteries.

IMPORTANT: BATTERY INFORMATION

Please retain this information for future reference. Batteries should be replaced by an adult.



CAUTION:

1. Always follow the instructions carefully. Use only batteries specified and be sure to insert them correctly by matching the + and - polarity markings.
2. Do not mix old batteries and new batteries or standard (carbon-zinc) with alkaline batteries.
3. Recharge recharged or dead batteries from the product.
4. Remove batteries if product is not to be played with for a long time.
5. Do not short circuit the supply terminals.
6. Should this product cause, or be affected by, local electrical interference, move it away from other electrical equipment. Press the switching off and back on again or removing and re-inserting batteries if necessary.
7. RECHARGEABLE BATTERIES: Do not mix these with any other types of battery. Always remove from the product before recharging. Recharge batteries under adult supervision. DO NOT RECHARGE OTHER TYPES OF BATTERIES.
8. As with all small items, these batteries should be kept away from children. If swallowed, seek medical attention immediately.

NOTE:


- * The 3 "AAA" battery compartment in the vehicle powers the lights on the car. If the lights become weak, replace with fresh batteries.
- * The 6 "AA" battery compartment in the vehicle powers the motors of the car. If the quality of control becomes less, replace with fresh batteries.

STEP 1 - QUICK START

1. Install fresh batteries in the vehicle and transmitter, see BATTERY REQUIREMENTS & INSTALLATION.
2. Turn vehicle and transmitter to ON.
3. When you are finished playing, turn vehicle and transmitter to OFF.


STEP 2 - DRIVING

1. FORWARD




• Press and hold this button.

2. REVERSE




• Press and hold this button.

3. LEFT TURN




• Press both buttons.

4. RIGHT TURN




• Press both buttons.

5. 360° LEFT SPIN



• Press and hold this button.

6. 360° RIGHT SPIN



• Press and hold this button.

STEP 3 - DRIVING TIPS

1. Practice racing at different speeds • press and hold the forward / reverse button for full speed and tap button for slower speeds.
2. How long you press the wheel buttons affects how much the car turns.
3. When the vehicle is coming towards you, the steering is opposite to the way you turn. Try to imagine that you are in the driver's seat and this will help you turn the way you want.

AUTO POWER SHUT OFF

This vehicle will Auto Power Shut Off if you stop playing for more than approximately 8 minutes. To re-activate, turn power OFF then back ON.

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Drive in any direction for awesome light effects!



WILD LIGHT-UP WHEELS!

Manufactured and distributed by
© 2003 WowWee Ltd.
All Rights Reserved.
MADE IN CHINA.

WowWee (Asia Office)
Unit 301A-C, 82 Granville Rd.,
T.S.T. Sze, Hong Kong
WowWee (North America Office)
6480 Cedar Lake, Suite 300,
T.R.U. Quebec, H4N 2H1, Canada
Consumer Hotline: (514) 444-1286
www.wowwee.com

WowWee

EL51615U001

Keep these instructions as they contain important information.