Kit contents:

1x EloView Engine with mounting brackets attached 1x 12v DC power brick 2x AC plug adaptors



www.elotouch.com

Quick Installation Guide

EloView Engine

Revision A P/N E214674

Elo Touch Solutions Technical Support

Online self-help: www.support.elotouch.com

North America

800-ELO-TOUCH Tel +1 408 597 8000 Fax +1 408 597 8050 EloSales.NA@elotouch.com

Europe

Tel +32 (0)16 70 45 00 Fax +32 (0)16 70 45 49 elosales@elotouch.com

Asia-Pacific

Tel +86 (21) 3329 1385 Fax +86 (21) 3329 1400 EloAsia@elotouch.com

Latin America

Tel 786-923-0251 Fax 305-931-0124 EloSales.LATAM@elotouch.com

The information in this document is subject to change without notice. Elo Touch Solutions, Inc. and its Affiliates (collectively "Elo") makes no representations or warranties with respect to the contents herein, and specifically disclaims any implied warranties of merchantability or fitness for a particular purpose. Elo reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of Elo to notify any person of such revisions or changes.

No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, including, but not limited to, electronic, magnetic, optical, chemical, manual, or otherwise without prior written permission of Elo Touch Solutions, Inc.

Elo (logo) and Elo Touch Solutions are trademarks of Elo and its Affiliates.








- 1. Connect 12V DC Power cable
- 2. Connect USB cable from Elo TouchMonitor to one of the USB Type A connections
- 3. Connect HDMI cable between Elo TouchMonitor and HDMI Out connection
- 4. Press the power button to power on the EloView Engine

The included mounting brackets can be removed for use with other brackets included with accessory bracket kit P/N E802593, available separately.





You need the following items to install the switch on a wall:

- One pair of wall mount brackets
- Four screws (M5 type)to attach the brackets to a wall Driving the Screws through the Holes

Position brackets on the equipment and drive screws through the holes to attach the brackets on the wall

