

10.1" TABLET
MODEL: M1015GR
USER MANUAL

Preface

Thank you for buying the MID. We wish you enjoy using it.

Please read and retain all the operating instructions before operating the unit, we do not assume any liability arising out of improper operation or incidental damages.

For better services, the content of this operation manual may be changed.

If the actual setup and usage of the unit are different from this operation manual, please view

the website of our company to inquire about the latest product information.

Do not allow water or foreign objects to enter the unit.


I. Note:

1. Avoid the unit being dropped. Avoid the display been shake seriously, or the display will be damaged or unusual.
2. Do not use metal object to touch the device to prevent it from short circuit.
3. Please backup your data in case your important data is lost, especially before you upgrade the firmware. The company will not take charge in any loss that caused by lost of data.
4. Do not disassemble. Do not wipe the surface of the unit by alcohol, thinner or benzene.
5. Do not disconnect the unit while it is formatting or uploading/downloading, or the procedures may lead to errors
6. We do not take responsibility to the flash damage caused by product broken, repair or other reasons. Please operate strictly as per the user guide.

7. Avoid water or foreign objects enter the unit.
8. Do not use the unit in places that are extremely hot, cold, dusty, or humid.
9. Avoid the unit being dropped. Avoid the display been shake seriously, or the display will be damaged or unusual.
10. Specifications are subject to change and improvement without notice

II. Introduction of cover:

1. Power on/off/Vol +/Vol –
2. Front Camera
3. HDMI
4. Micro USB OTG
5. Earphone Jack
6. Micro USB Host
7. Back Camera
8. Loudspeaker



III. Operation Instruction

1. Basic Operation

1.1. SIM card installed

Power off, open the bottom shell, the SIM card into the SIM card slot in the direction indicated by and Installation Bottom.

1.2. Power on/Power off

Power on:

Press and hold the power switch for 5 seconds; the unit displays the start-up logo and enters the working mode.

Power off:

Press and hold the power switch for 3 seconds to turn the unit off.

Sleep:

While the device is at working status, press the power switch, it enters the sleeping mode, and the screen will be off then. Press the power switch again, it shift to the normal mode. You may use this function when you don't use the device temporary to save power.


1.3. Charging

When the device prompts low battery, please charge it by provided charger.


Note:


To improve the longevity of the battery, you may charge for another 30 minutes after it prompts the battery is full.

1.4. Main menu

Click the  icon in the main interface, the main menu is appeared. It including the system setting, music playback, video playback, web browser and other applications you installed in the main menu.

2. Settings

Click  in the main interface to enter the setting interface. Click the corresponding setting items to operate.



2.1. Date and Time Setting

Click “Date & Time” in the setting interface to set the date and time. You may set the date, time zone, time, time format and date format etc. in the menu.




2.2. Brightness

Select “Display” in the setting interface. Click “Brightness” to enter, and slide the bar to adjust the brightness.



3. Wi-Fi connection


Click “Settings” in the main interface and click “Wireless & network” to enter the wireless and network setting interface. Click Wi-Fi to turn on the WIFI. Click Wi-Fi setting to set and manage wireless access.



Click “Network Notification”, it lists the open network it searched. Click the name of the network; it pops up the setting window. You may connect it to WIFI according to the prompts. You need to input the user name and password if networks are encrypted.

4. Bluetooth

Turn on the Bluetooth, Click Bluetooth setting to set and manage Bluetooth Devices access. Click “SEARCH FOR DEVICES”, it lists the open devices. Click the name of the devices; it pops up the setting window. Choose the device, pairing it, then you can transfer pictures, movies, music etc with it.



5. Install, Uninstall and Run applications

5.1 Install

There are many ways to install applications under Android, such as via USB, by third party program. We introduce installation by Apps Installer here.

Click the “File Manager” in the main interface.

Select the APK file you want and enter the application installation interface. Click “Install” to install the application automatically. After installation, it prompts “Open” and “Finish”. Click “Open” to open the application. Click “Finish” to exit.


5.2 Uninstall


You may use the corresponding third party software management tool or the installed application management software of the device to install applications.

Select “Setting/Apps” to select the installed applications and check the attribute of it or uninstall it.

6. Connect to internet

6.1. After connecting with WIFI, open the browser and input the web address, you can browse the web then.


6.2. Click the  icon to enter the bookmark to view the browse history. Click the web page you want to open it.

To save the web page into bookmark, you may click  to enter and click “add” to save it.

7. Audio and video playback


8.1. Audio playback

Click the “Music” in the main menu to enter the audio playback interface. It lists the audio files in the device, and you may click the file name to play it. in the audio playing interface, click the icons to play/pause/ FF/ REW....



7.2. Video Playback

Click the “Video” in the main menu to enter the video playback interface. It lists the video files in the device, and you may click the file name to play it. in the video playing interface, touch the screen to pop-up the operation icons and click the icons to play/pause/ increase volume/ decrease volume/ skip to next file/skip to previous file....



8. Picture viewing

Click “Gallery” in the main menu to enter the picture folder list. Select and click

the folder you want to enter, it displays the . click the thumbnail of the picture to view it.
Touch the screen to pop-up the operation icons while viewing the picture, you may zoom in/zoom out/ skip to next picture/skip to previous picture/ rotate/ delete the picture...







9. Camera

Click “Camera” in the main interface.

9.1 Camera


Click  to take picture.

Click  to set the scene mode, Picture size, Picture quality, and color effect.

Click  to select back or front camera.

9.2 DV



Click  to take picture.


Click  to set the color effect or restore to default settings.

10. 3G calling

Please plug/unplug the SIM card when the device is power off, or the system can't recognize the SIM card.

10.1 phone



On power off status, insert the SIM card, and then turn on the device. It appears the 2G/3G network signal icon  after entering the system. Click  to enter the “phone” function. There are 3 options:


phone: input the phone number and then click  to dial.

Call log: check the call history in the call list and dial the number again.

Contacts: click the name of the contact to dial.



10.2 People



Click  to enter the “People” function, click  icon to Add an account,

click  icon to pop up 7 options: Delete contact, Contacts to display,

Import/Export, Groups, Accounts, Settings, Share visible contacts. You may make the corresponding setups based on your requirement.


10.3 Messaging

Click  to enter the “Messaging” function, click  icon to Edit a new

message,click  icon to Search messaging,click  icon to pop 2 options:

Settings,Wappush messages. You may make the corresponding setups based on your requirment.

10.4 3G Network

Under power off status, insert the SIM card, and then turn on the device. It appears the 2G/3G network signal icon  after entering the system. Since you can only choose either 2G/3G or WIFI, you have to turn off WIFI first. You may select settings → Wireless&networks→ Mobile networks to setup.

11. Connect with external device

11.1. Connect with PC

Connect the device and the PC, with the USB cable to the Micro USB OTG port of the device to connect with the PC. My computer will be a new media device, after opening will see two disks, one is the TF card, and the other is the built-in flash.

Note: when the USB OTG is connected to the PC, the USB Host is not used at the same time.

11.2. Use of OTG and SD card

It supports the movable device with FAT32 format, such as U disk and MP3.

Connect the movable device to the MID. (Note: OTG and Host could support USB mouse and keyboard)

 Home





USB storage

Available 2.33 GB

Total space 3.96 GB



SD card

Available 7.27 GB

Total space 7.27 GB



External USB storage

Available 3.11 GB

Total space 7.3 GB

12.GPS

Click “Settings” in the main interface and click “Location access” to enter the Location access setting interface. Click Access to my location , open the GPS satellites.



IV. Troubleshooting

1. What if the device is abnormal during operation?

Answer: 1). Reboot the device to see if it works OK.

2). Charge the device by the charger to activate the battery. Make sure it has power before you operate it.

3). It is suggested to upgrade the OS of the device by professional.

2. Why the standby time is so short sometimes?

Answer: the use time of the battery is all depend on the temperature and use instance. If the temperature is too high or too low, the use time of the battery might be effected. It is suggest using the device in normal temperature.

The using time is also affected by increased volume and frequently operation.

VI. Specifications

Item	M1015GR
Dimension	261*161*10 mm
Display	10.1" TFT touch panel
OS	Android 5.1 or up
Input method	Soft keypad
Capacity	XXGB (Take the object as the standard)
External Capacity	TF card, up to 16GB
Audio	WAV,MP3,MP2,AAC,AMR-NB,AMR-WB,MIDI,Vorbis,APE,AAC-plus v1,AAC-plus-v2,FLAC,WMA,ADPCM
Video	MPEG4,H.264,H.263,VP8,DIVX,VC-1:1080p @ 30fps
E-book	Support
Wireless network	Support WIFI
Language	Multi-language
USB	USB2.0 high speed
OTG	Support
Temperature	-20℃ to 40℃
Power supply	AC 100~240V 50/60Hz; DC 5V/1.5A
Battery	7000mAh poly-lithium battery

Note: The pictures list in the manual are for reference only!

The design and the specification of the unit are subject to change without notice.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following

measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This Tablet PC meets the government's requirements for exposure to radio waves.

This phone is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government. The exposure standard for Tablet PC employs a unit of measurement

The SAR limit set by the FCC is 1.6W/kg. *Tests for SAR are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output.

31

Body - worn: 1.148W/kg

Hotspot: 1.148W/kg

Simultaneous Transmission: 1.148W/kg

(Measurements differ among phone models, depending upon available accessories and FCC requirements.)

While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirement.

The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of www.fcc.gov/oet/ea/fccid after searching on

For body worn operation, this Tablet

PC has been tested and meets the FCC RF exposure guidelines for use with an accessory that contains no metal and the positions the handset a minimum of 1.0 cm from the body. Use of other accessories may not ensure compliance with FCC RF exposure guidelines. If you do not use a body-worn accessory and are not holding the phone at the ear, position the handset a minimum of 1.0 cm from your body when the phone is switched on.