


3.1

ACCESSORIES:
QUICK GUIDE / USER MANUAL

LOGIC TW7

QUICK GUIDE | GUÍA RÁPIDA

PRODUCT INFORMATION



It Includes:

- Bluetooth earphone
- Endurance charging box
- Micro 5 pin charging cable
- User's manual
- Earplug silicone

PRODUCT SPECIFICATIONS

- Bluetooth V5.3+BR+EDR
- Battery: Headset 3.7V/30mAh | Charging box 3.7V/200mAh
- Support mode: a2dp/avctp/avdtp/avrcp/hfp/spp/smp/att/gap/gatt/rfcomm/sdp/L2cap
- Sensitivity: +96dBm
- Transmission distance: >10 meters (in an ideal environment without any major obstacles)
- Play time: About 2 hours
- Call time: About 2 hours
- Standby time: About 80 hours
- Charging time: Charge the charging case for about 1.5 hours and charge the headset for about 1 hour

FUNCTIONAL OPERATION INSTRUCTIONS

1. POWER ON

Taking the headset out of the charging case will automatically turn it on or press and hold the left and right headset multifunction button for 2 seconds to turn it on.

2. POWER OFF

Put the headset into the charging box will turn it off automatically or press and hold the left and right headset multifunction button for 3 seconds to shut down.

3. REBOOT

When the pairing is successful, the Bluetooth headset preferentially enters the connected state the second time is turned on and automatically connects back to the connected device.

4. PLAY / PAUSE

In the Standby mode, pick the button of left or right earphones to play or pause music.

5. SWITCH SONGS/VOLUME UP/DOWN/ENABLE SIRI: While playing music, press the left earphone two seconds long to the previous track and press the right earphone for two seconds long to the next track. For Volume+ press left earphone two times, and Volume- press right earphone two times. Right earphone press three times to enable Siri and press left earphone three times to last number redial.

6. ANSWER THE CALL

When the phone calls incoming, pick the left or right earphone multi-function keys to pick up the call.

7. HANG UP THE CALL

When the phone is in a calling press the left and right earphone multi-function keys to hang up the call.

8. CALL REJECT

When the phone call incoming, long press the left or right earphone multi-function keys for 2 seconds to reject the call.

9. LOW BATTERY PROMPT

When the battery of the Bluetooth headset is low, a low battery tone will be played every 30 seconds until the headset is powered off.

Basic Function

Play/Pause	L&R : Click 1 time
Answer call	L&R : Click 1 time
Hang up call	L&R : Click 1 time
Reject call	L&R : Press & hold for 2 seconds
Incoming call voice	Synchronous with phone ringtone
Previous Song	L : Long press 2 seconds
Next Song	R : Long press 2 seconds
Volume +	L : Click 2 times
Volume -	R : Click 2 times
Last Number Redial	L : Click 3 times
SIRI / Voice Assistant	R : Click 3 times

PAIRING METHOD

Start the Bluetooth function of the mobile phone or other devices. If it is an Android mobile phone or device, please select the "Search for Bluetooth device" option. If it is the IOS system mobile phone or device, it will automatically search for the device. After that, select the earphones to enter the pairing when the pairing is successful, the main (right) earphone will make a prompt to connect successfully, and the left and right earphones will turn to green and red flash slowly, and enter the connection standby state.

CHARGING OPERATION

1. To charge, connect the MICRO USB cable to the charging case and connect to the power.
2. Earpiece: Placing the earphones in the charge box starts the automatic charge, the charge box will flash a white light. When the charge box is on full charge it will show a solid bright white light, when the earbuds are fully charge the lights will go off.

PRECAUTIONS

1. Charge the device in a safe environment, avoid humid places.
2. When playing music, please adjust the music to the appropriate level to avoid hearing damage and avoid high volume for a long time.

3. Try to avoid using the headset in a place with interference sources, otherwise it may affect the headphone signal.

4. Try to avoid using this headset in a corrosive environment to avoid affecting the function of the headset.

Tips:

- When you use this Bluetooth headset to listen to music or talk, please pay attention and adjust the volume properly, so it will not affect the hearing for excessive volume!

Logic keeps the right to make modifications to any of the content in this user guide without public announcement, in advance. The content of this manual may vary from the actual content displayed in the device. In such a case, the latter shall govern.

LOGIC

Warranty Certificate

Terms and Conditions

LOGIC warrants that their Products will be free from defects in material and workmanship. The warranty period is one (1) year for the products and three (3) months for the accessories with one part of the original package and only the warranty. The warranty period begins the date of purchase by the End-User who and present in the case of a purchase receipt when requesting warranty service otherwise the warranty period will begin from the date of manufacture of the product. LOGIC will make a product without cost to the customer if it presents a manufacturing defect or defect in workmanship during the warranty period and if the defect occurred under normal conditions of use in accordance with the instructions and specifications stated in the user's manual.

For additional information about the terms and conditions of LOGIC's Limited Warranty or to obtain warranty service information please visit the support section at: logicmobi.com

Garantía de Servicio

Términos y Condiciones

LOGIC garantiza que sus productos estarán libres de defectos de material y mano de obra. El período de garantía es de un (1) año para los productos y de tres (3) meses para los accesorios que formen parte del paquete original y presente la garantía. El período de garantía comienza la fecha de compra por el usuario final y solo en el caso de una compra con recibo de compra, de lo contrario el período de garantía comenzará a partir de la fecha de fabricación del producto. LOGIC reparará o reemplazará sin costo para el cliente el producto si presenta un defecto de fabricación o un defecto de mano de obra durante el período de garantía y si el defecto se produjo en condiciones normales de uso de acuerdo con las instrucciones y especificaciones indicadas en el manual de usuario.

Para más detalles de la Garantía, Límites de LOGIC y para obtener información de servicio de garantía, por favor visite la sección de soporte en nuestra sitio web: logicmobi.com


logicmobi.com

Hecho en China 中国制造

Copyright Design, Inc. 2019



INFORMACIÓN DE PRODUCTO



Incluye:

- Auriculares inalámbricos
- Estuche de carga
- Cable de carga Micro 5 pin
- Manual de usuario
- Gomas para oídos

ESPECIFICACIONES DEL PRODUCTO

Bluetooth V5.3+BR+BLE
Batería: Auricular 3.7V/30mAh | Caja de carga 3.7V/200mAh
Modo de soporte: a2dp/avctp/avdtp/avrcp/hfp/spp/smp/att/gap/gatt/rfcomm/sdp/L2cap

• Sensibilidad: +96dBm
• Distancia de transmisión: >10 metros (en un entorno ideal sin grandes obstáculos)
• Tiempo de reproducción: 2 Horas aprox.
• Tiempo de llamada: 2 Horas aprox.
• Tiempo de espera: 80 Horas aprox.
• Tiempo de carga: Cargue el estuche de carga durante aproximadamente 1.5 horas y cargue los auriculares durante aproximadamente 1 hora.

INSTRUCCIONES DE OPERACIÓN FUNCIONAL

1. ENCENDIDO

Si saca el auricular del estuche de carga lo encenderá automáticamente o mantenga presionado el botón multifunción izquierdo y derecho de los auriculares durante 3 segundos para encenderlos.

2. APAGADO

Cuando los auriculares en la caja de carga las apagará automáticamente o mantenga presionado el botón multifunción izquierdo y derecho de los auriculares durante 5 segundos para apagarlos.

3. RECHAZAR

Cuando el emparejamiento es exitoso los auriculares

Bluetooth ingresará preferentemente al estado conectado cuando se encienden por segunda vez y se conectan automáticamente al teléfono móvil conectado.

4. REPRODUCIR/PAUSAR

En el modo de espera, pulse el botón de los auriculares izquierdo o derecho para reproducir o pausar la música.

5. CAMBIAR CANCIONES/SIRI/BAJAR VOLUMEN/ACTIVAR SIRI: Al reproducir música, presione el auricular izquierdo durante dos segundos para ir a la pista anterior y presione el auricular derecho durante dos segundos para ir a la pista siguiente. Para Volumen+ presione el auricular izquierdo dos veces y para Volumen- presione el auricular derecho dos veces. Presione el auricular derecho tres veces para habilitar Siri y presione el auricular izquierdo tres veces para volver a marcar el último número.

6. RESPONDA LA LLAMADA

Cuando el teléfono reciba una llamada presione el botón multifunción del auricular izquierdo o derecho para contestar la llamada.

7. COLGAR LA LLAMADA

Cuando esté en una llamada, presione los botones multifunción del auricular izquierdo y derecho para colgar la llamada.

8. RECHAZAR LA LLAMADA

Cuando el teléfono reciba una llamada, mantenga presionado los botones multifunción del auricular izquierdo o derecho por dos segundos para rechazar la llamada.

9. INDICACIÓN DE BATERÍA BAJA

Cuando la batería de los auriculares Bluetooth está baja, se reproducirá un tono de batería baja cada 30 segundos hasta que los auriculares se apaguen.

Funciones básicas

Reproducir/Pausa	L&R : Toque 1 vez
Contestar llamada	L&R : Toque 1 vez
Colgar llamada	L&R : Toque 1 vez
Rechazar llamada	L&R : Pulse y mantenga durante 2 segundos
Voz de llamada entrante	Sincronizado con el tono de llamada del teléfono
Canción anterior	L : Mantener pulsado 2 segundos
Canción siguiente	R : Mantener pulsado 2 segundos
Volumen +	L : Toque 2 veces
Volumen -	R : Toque 2 veces
Redialado al último número	L : Toque 3 veces
SIRI / Asistente de voz	R : Toque 3 veces

MÉTODO DE SINCRONIZACIÓN

Inicie la función Bluetooth del teléfono móvil u otros dispositivos. Si se trata de un teléfono móvil a dispositivo Android, seleccione la opción "Buscar dispositivo Bluetooth". Si es el teléfono móvil a dispositivo con sistema IOS, este buscará automáticamente el dispositivo. Después de eso, seleccione los auriculares para ingresar al emparejamiento: cuando el emparejamiento sea exitoso, el auricular principal (derecho) le indicará que se conectó exitosamente, y los auriculares izquierdo y derecho se mostrarán luces verdes y el rojo que parpadearán lentamente e ingresará al estado de espera.

CARGA DE LOS AURICULARES

1. Para la carga conecte el cable MICRO USB a estuche de carga y conecte a la corriente.
2. Auricular: Al colocar los auriculares en la caja de carga se inicia la carga automática y parpadeará una luz blanca. Cuando la caja de carga esté completamente cargada, mostrará una luz blanca brillante fija; cuando los auriculares están completamente cargados, las luces se apagarán.

PRECAUCIONES

1. Cargue el dispositivo en un ambiente seguro, evite lugares húmedos.
2. Cuando reproduzca música, ajuste la música al volumen adecuado para evitar daños auditivos. Evite un volumen alto durante mucho tiempo.
3. Trate de evitar usar los auriculares en un lugar con fuentes de interferencia, de lo contrario puede afectar la señal.
4. Trate de evitar usar estos auriculares en un ambiente corrosivo para evitar afectar la función de los mismos.

Tips:

- Cuando utilice estos auriculares Bluetooth para escuchar música o hablar, preste atención para ajustar el volumen correctamente, para no afectar la audición con el volumen excesivo!

Logic se reserva el derecho de realizar modificaciones en cualquiera de los contenidos de esta guía de usuario sin previo aviso público. El contenido de este manual puede variar del contenido real que se muestra en el dispositivo. En tal caso, prevalecerá éste último.



FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance (cm) between the radiator and your body.

LOGIC

