






TEST REPORT
2444, 2445, 2446, 2447, 2448 & 2449
0
5
Centimeters

TS100

TELETEST
Reports 2444, 2447, 2448 & 2449
0
Centimeters
5







TAH2444 TAH2447
TAH2448 TAH2449

Caution
Do not touch the
output terminals or
the output stage
when the unit is
powered on.

TELTEST
Reports 2444, 2447, 2448 & 2449

0 5
Centimetres

TARF2444 TARF2447
TARF2448 TARF2449


18022804
100900822
380-520 MHz
TBA90H0-0000


Caution
Do not remove or
switch load while
transmitting.
This may damage
the output stage.


TELTEST
Reports 2444, 2447, 2448 & 2449

0 Centimetres











TELTEST
Reports 2444, 2447, 2448 & 2449

0
Centimetres
5









2444, 2445, 2446, 2447, 2448 & 2449

TELTEST Reports

0

Centimetres

5