EXHIBIT C - EUT INTERNAL PHOTOGRAPHS

EUT – Uncover View



EUT – Uncover View





EUT – Uncover View




EUT – Uncover View









EUT – Mainboard Uncover View



EUT – Subboard Top View



EUT – Subboard Bottom View



EUT – 2.4G&5.8G TX ANT View







EUT – BLE ANT View




EUT – BLE Chip View




EUT – 2.4G&5.8G Chip View



EUT – Control Board Top View




EUT – Control Board Bottom View




EUT – Control Board Top View




EUT – Control Board Bottom View






EUT – GPS Board Bottom View



EUT – GPS ANT View



EUT – Battery Top(small) View







EUT – Battery Bottom(big) View

86 87 88 89 90 91 92 93 94 8 9 22 01 2 3 4 5 6 7 8 9 23 01 2 3 4 5 6 7 8 9



EUT - Battery Label(big) View

WARNING SA

In the Comment of the sign and comment of the Battery of the Battery