

Important Safety Information

Explanation of Attention Words and Symbols Used in this Guide



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

⚠ WARNING

WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.

⚠ CAUTION

CAUTION, used with the safety alert symbol, indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

CAUTION

CAUTION, used without the safety alert symbol, indicates a hazardous situation which, if not avoided, could result in harm to your pet.

⚠ WARNING

- Do not short circuit, dispose of in fire, or expose to water. When batteries are stored or disposed, they must be protected from shorting. Dispose of used batteries properly.
- Not for use with aggressive dogs. Do not use this product if your dog is prone to aggressive behavior. Aggressive dogs can cause severe injury or death to their owners and others. If you are not sure that this product is right for your dog, please talk to your veterinarian or a certified trainer.


⚠ CAUTION

- Safety during on-leash training. It is vitally important that you and your dog remain safe while learning during on-leash training. Your dog should be on a strong leash, long enough for him to attempt to chase an object, but short enough for him not to reach a road or other unsafe area. You must also be physically strong enough to restrain your dog when he tries to chase.
- This pet training device is not a toy, keep away from children.

CAUTION

- Risk of skin damage. Please read and follow the instructions in this guide. Proper fit of the collar is important. A collar worn for too long or made too tight on the pet's neck may cause skin damage. Ranging from redness to pressure ulcers; this condition is commonly known as bed sores.
- Avoid leaving the collar on the dog for more than 12 hours per day.
- When possible reposition the collar on the pet's neck every 1 to 2 hours.
- Check the fit to prevent excessive pressure; follow the instructions in this manual.
- Never connect a leash to the electronic collar; it will cause excessive pressure on the contacts.
- When using a separate collar for a leash, don't put pressure on the electronic collar.
- Wash the dog's neck area and the contacts of the collar weekly with a damp cloth.
- Examine the contact area daily for signs of a rash or a sore.
- If a rash or sore is found, discontinue use of the collar until the skin has healed.
- If the condition persists beyond 48 hours, see your veterinarian.
- For additional information on bed sores and pressure necrosis, please visit our website.

In The Box



Features

- 3 Training modes: Tone/Vibration/Shock
 - Up to 330 yd. Range
 - Digital Screen
 - Two Dog Capability
 - 1 – 99 Shock Levels
-

How it works

- **Tone:** beeps to get your dog's attention or mark a behavior, similar to a clicker
 - **Vibration:** vibrates the receiver collar
 - **Shock:** administers a shock with up to 99 levels of intensity
1. Plug in and fully charge the remote and receiver collar. The battery icon on the remote will cycle while charging and then remain solid when it is fully charged. The collar's LED will be solid red when charging and will turn off when the collar is fully charged.
 2. To pair the remote and receiver collar, select Dog 1 or Dog 2 on the remote. With the collar turned off, press and hold the on/off button. Continue to hold the on/off button as the collar light will turn on and then back off after about 5 seconds. Then press the red, action button on the remote.
 3. If you would like to test the shock level on yourself, select Dog 1 or Dog 2 on the remote, select shock and press the red action button. Both contact points must touch skin to emit a shock.
 4. To assure a proper fit, please follow these steps:
 - a. Start with the collar turned off and your dog standing comfortably, not sitting.
 - b. Place the training collar on your dog's neck with the contact points touching the skin.
 - c. Insert one finger between the collar and your dog's neck to check the tightness. The fit should be snug but not constricting.
 - d. Allow your dog to wear the training collar for several minutes then recheck the fit. Check the fit again as your dog becomes more comfortable with the training collar.

NOTE: It is sometimes necessary to trim the hair around the contact points to make sure that contact is consistent. However, you should never shave your pet's neck as this may increase risk of skin irritation.
 5. The remote has a power-save feature that will put it into standby after 15 minutes without use. Press any button on the remote to reactivate. Note that pressing any of the correction buttons will simultaneously reactivate the remote and send a correction to the receiver collar.
 6. For your dog's safety, the remote will automatically time-out after 10 seconds of shock. You will have to release and repress the action button to administer another shock.
 7. The remote can be paired with two collars, labeled as Dog 1 and Dog 2. Make sure to choose the correct one when pairing a second collar, and follow the steps above.
 8. The 330-yard range is based on a straight-line distance between the remote and the receiver collar without obstacles. Interferences in the air, obstacles in the area and other factors could alter the range, so actual distances may vary.
-

Warranty

This product comes with a 1 year warranty. Should this product mechanically fail within 1 year of purchase, please contact us.

Telephone: (877) 455-7387

Web: www.freepiritpetproducts.com

IC - Canada

This device (FS-TRN) complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

FCC - USA

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.