

## REMOTE CONTROL PROGRAMMING INSTRUCTIONS

### GDR-23

1. Press then release the “Learn Code” button on the OPENER hanging in your garage, LED will blink rapidly. (on certain openers you will have to remove the light lens cover to access the learn button)
2. Immediately press the button you wish to program on the remote transmitter(LED will stop blinking)
3. Immediately press the same button on the remote transmitter again (the LED will go out)
4. Press the same button on the remote one more time. The garage door will open indicating successful programming.

\*\*Repeat the steps above if you wish to program multiple remotes (or a multi-button remote to multiple doors). If a remote loses it's “program” repeat the steps above.

#### FCC Statement

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

## **WARNING**

In order to prevent possible **SERIOUS INJURY or DEATH** from a moving gate or garage door:

- Keep remote controls out of the reach of children.
- Only use the remote control when the gate/garage door can be seen clearly, is properly adjusted, and there are no obstructions to door travel.
- Keep the gate/garage door in sight until it is completely closed. Do not allow anyone to cross paths with the gate/garage door while moving or operating the remote control.