

Appearance Description



◆ Schematic Diagram of Charging

Operate in strict accordance with the following figures: 1.Please use the product-specific magnetic charging cable to charge by aligning it with the charging contacts on the back of the watch. 2.Do not use a power adapter with a voltage exceeding 5V and an output current exceeding 1A for charging, as this may cause charging failure and damage to the magnetic charging cable or the device.



◆Introduction to Watch Function

- 1, Brightness setting
- 2. Power saving mode
- 3. Do not disturb mode switch 4. Bluetooth switch for calls
- 5. Flashlight
- 6. System information
- Find your phone (must be connected to AP 8. Settings
- 9 Turn on/off key
- 10. Click to extinguish the screen, long press to enter the sport mode, you can customize the settings.
























Message: The watch can receive phone calls, Twitter, WhatsApp. Facebook WeChat and other notification alerts from the phone This function needs to allow the APP to get the corresponding permission and open the push item reminder, and keep the connection with the phone.



Music: After connecting the APP, the watch can control the nobile phone player to play/pause/switch to the previous song and the next song. This function must be opened on the mobile phone player before it can be controlled on the watch. This function requires staying connected to your phone and turning on the notification push permission.



Breath training: Click the start icon and follow the watch cues for





Stopwatch: Click on the icon to start the function, and click Start for timing, pause or reset. Slide right to leave.



 Search: Click this icon, your phone will been to indicate the orientation of your phone, this function requires your phone to stay connected with the watch APP. No alert on the phone in



Settings: Click the icon to enter the function, you can set the menu style, screen display, language, restore factory settings and view the watch and other information.

♦ Watch APP Installation and Connection Instructions

As a Bluetooth product, most of the functions of this product need to be connected to a special APP for normal use, such as time display, call alert, and message alert. For Android phones, please do not use Bluetooth to connect and pair with the watch directly. Please scan the following QR code to select the version suitable for your mobile phone system or enter main application markets to download and install FitCloudPro.



◆ Device Connection

Before using the APP, please turn on the mobile phone Bluetooth and mobile phone GPS positioning to obtain the mobile phone positioning permission. After the connection is successful, it will prompt "To pair with: S81 " , please select pairing.

The watch connection operates as follows:

Rluetooth: S81

Connection succeeded

1. For Android users, the APP

should obtain permissions and

run backstage, otherwise it will

connecting in the APP, you

the second time in the

can make calls, play

Bluetooth settings of the

need to connect to the S81 for

mobile phone, and then you

multimedia music and other

D. If the watch is not used for a long time, the Bluetooth will go into a dormant state. Please turn off the Bluetooth of the watch and the phone. reopen it after about 1 minute, and try to search the connection in the APP

affect the user experience. 2. For systems below iPhone iOS 13, after

Precautions

poor charging contact.

1.No charging with water stains.

and the measurement data is for reference only.

4.Please charge with the matching charging cable.

cannot synchronize with the time of the phone.

E. The watch must be connected to the APP otherwise, the steps, sleep. time, and other function will not work properly.

B. Users need to open the APP to obtain positioning permission

2. This product is an electronic monitoring product, not for medical use.

5.Please keep the charging port on the back of the watch clean to avoid

1. Problems such as the watch cannot be searched in the APP, or the watch

C. If the watch has already been paired with a Bluetooth connection in the

phone, please cancel the pairing first and then search for the connection

A. Make sure your phone's Bluetooth and phone GPS positioning are on

3.It is not recommended to wear in hot water baths and longtime

2. There is no alert function on the watch.

Answer: For first time use:

before using it for the first time.

(Phone Settings - Applications).

For Android users: Please operate according to the page prompt, or open the information reminder function in the APP, and open the APP

notification permission according to the prompt. For Apple users: After the watch is connected to the APP, the phone will pop up a pairing request, please choose to allow pairing and turn on the switch of the application reminder that you need to use in the APP. Please open the "Notification Center" in the application you need to use via Phone Settings - Notification.

3. The reminder switch is turned on, but there is no reminder on the watch, or the reminder is sporadic.

If the phone turns on the message notification and the corresponding notification permission according to the above tips, the Bluetooth is kept on, and the APP and the watch are kept connected, maybe the system authorized APP alert function is not working, and the user needs to re-check the message push function.

4. Android's phone Bluetooth often disconnects or has no message alert after a period of connection.

applications or applications that consume more power for smooth system operation. If the APP is not set to allow backstage running, it will be easily cleaned by the system and the Bluetooth will drop out. Different Android phones have different methods for APP backstage running settings. As in the Huawei nova 8 SE: Settings - Battery - Power Consumption Ranking APP - Application Launch Management - Manually manage to turn on backstage running.

5. The watch cannot measure, or the data is not accurate.

Android will from time to time clean up the phone's backstage

A. Sit down before the measurement and put your body in a relaxed state with your arms level with your chest position.

B. Adjust the tightness of the watch. The back of the watch should be close

to the skin to prevent light leakage from the photoelectric sensor. C. Keep your body calm during the measurement, Talking/coughing/ sneezing and other movements will affect the accuracy of the

measurement results.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate

This device complies with Part 15 of the FCC Rules. Operation is subject

to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the ECC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no quarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or

more of the following measures: - Regrient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to

which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

Smart Watch User Manual