Quick Manual Poweron the camera.turn on the device.it will send*system starting up wait be configered. Waitfor the connection please configure the network according to the Instructions"prompt after several seconds. If the camera does not have a prompt sound for a long time you can press and hold the camera Reset button until you hear the prompt*Restore factory settings please do not power off "and release it to restore the camera to factory settings and then configure the network. If you need local storage please install the memory card firstly. and then power on the device (the memory card does not support hot swapping please plug and unplug the memory card when the device is powered off).Cloud storage is recommended,whichis safe and convenient. Details See "Step 4" for operation

Quick Operation Guide Tips two:Search "iCSee"inthe App store and download Step 2 Turn on the power

Step 1 Download and install the App

configuration, please configure it as follows. 1.Connect your phone to WiFinetwork and turn on Bluetooth. 2.0pen the ICSee app, register an account and login(Figure 1). Figure 1 280.64回1352

Step 3 Configure the network of the camera

Note:If the device supports Bluetooth network

Bluetooth network configuration

Login Username A29 Password Password

5 Enter the wireless router password and click"Confirm"(Figure 4) of the screen (Figure 2). 4 Click onthe main interface to search for found devices(Figure 3 (if the camera is not searched please turn the phone Bluetooth off for 5 seconds and turn it back on then search again or long press the camera Reset button to reset Search again).

3 After successful login Clickthe"+"button in the top right come

Figure 2 Figure 3 AddDavice



6. Wait for the camera network configuration, when the camera emits the voice message connecting please wait connect router successfully the network configuration is successful

Confirm

Figure 5 ④04画135 00 SekctaW-Fwith atbleand stongspool,GI in the

name(Figure 6).

Figure 6

CameraName

Nameyour days

LMng Raom Bedroom Guest Room

7 After the network configuration is successful set the camera Note:If the device does not support Bluetooth netwo please configure it as follows.

8. Follow the APP interface to guide you through the setup. After the configuration is completed the device's displayed in the device list interface Click to open the real-time preview screen 1.Connect your phone to WiFinetwork and carry out relevant operations and settings(Figure 7). Figure 7

SmartDevicew

Ewerts Seast Alam Saing

n NL cour

21 ogin toiCSee App click "+"to add devices(Figure 8) and sele "WiFi Camera"(Figure 9) 3.Set network configurationaccording to the camera's voice prompts and the APP interface step-by-step guide. When the that the camera has successfully configured the network. SmartDevice Add Davice



Other ways to pair and add derice

4 After the network configuration is successful follow the instructions on the APP interface to set the camera password and configuration or Bluetooth network configuration fails.

list interface(Figure 11),and follow the guidanceof theapp 5 After the configuration is completed the device is displayed interface to understand and open the cloud storage package with the device list interface. Click to open the real-time preview a variety of packages available. screen, and carry out relevant operations and settings (Figure 10).

State Street B

Figure 10



2 2 3

Steps to open cloud storage click the "cloud"icon in the device

Figure 11

Step 4 Cloud Storage

Q:How do cameras store video? A:1.Local TF card storage.maximum support up to 128G TF card after full automatically delete earlier video overwrite

Q:ls 5g router supported ?

2.Cloud storage Q:How to do if the camera is not connected or offline?

A:If you use 5g router,5G and 2.4G use the same connection

hotspot(that is,SSID is the same),you can connect directly.If 50

and 2.4G are not thesame connectionhotspot (that is SSID is

different generally SSID of 2.4G is xxxxx-2.4G,SSID of 5G

of xxxxx-2.4G of router before configuring camera

is xxXXx-5G) please connect WiFi ofmobile phone to hotspot

A:1.Check if the camera power or networkof routernormally. 2.Plug the camera power to restart camera. 3 Restore the camera tofactory settings

rections

accessible to children

1 Please refer to the actual product the manual is for

1.Please change the user password while using this product to

2.Do not install the device in a place that is damp,dusty,or

3 Please use and store within the allowable temperature and

humidity range, and do not disassemble the equipment at will.

avoid being misappropriated by criminals.

reference only

2. The APP and product firmware will be updated from time to time. You can upgrade to the latest firmware online by yourself without notice. The manual is for reference only. 3 The manual may contain technically inaccurate parts or parts

that are inconsistent withproductfunctions or printed errors. Please refer to our company's final interpretation

including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party

responsible for compliance could void the user's authority to operate the

for a Class B digital device, pursuant to Part 15 of the FCC Rules, Thes

NOTE: This equipment has been tested and found to comply with the limits

This device complies with part 15 of the FCC Rules. Operation is subject to

the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference receive

particular installation

This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the

supplied antenna.

limits are designed to provide reasonable protection against

harmful interference in a residential installation. This equipment

generates, uses and can radiate radio frequency energy and, if

not installed and used in accordance with the instructions, may

cause harmful interference to radio communications. However

there is no quarantee that interference will not occur in a

If this equipment does cause harmful interference to radio or

television reception which can be determined by turning the

interference by one or more of the following measures:

equipment off and on, the user is encouraged to try to correct the

-- Increase the separation between the equipment and receiver

-- Connect the equipment into an outlet on a circuit different

from that to which the receiver is connected.

-- Reorient or relocate the receiving antenna.

-- Consult the dealer or an experienced radio/TV technician for To maintain compliance with FCC's RF Exposure guidelines.

Product Name Purchase Date Cause

Purchase Store

Warranty period:one year.
This warranty card is only for our company's products.