

Linkind

Smart LED Bulb (Tunable White Light) User Guide

- 1 -

Model: WL100010004
FCC ID: 2ASHKWL100010004

CAUTIONS

To avoid personal injury and/or possible product damage, the following cautions must be followed:

1. Risk of electrical shock. Disconnect power at fuse or circuit breaker before installing or servicing.
2. To prevent early lamp failure, lamp should only be installed in operating environments ranging between: -20°C and +40°C (-4°F and +104°F).
3. Suitable for damp locations.
4. Not for use with dimmers.
5. Lamp dims via wireless control and will not operate with a dimmer switch.
6. Not for use in totally enclosed luminaires.
7. Not for use in emergency light fixtures or exit signs.
8. Ensure fixture can support the added weight of the lamp/bulb.

- 2 -

Warning

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.
NOTE: The grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. Such modifications or changes could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular

- 3 -

installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body.


- 4 -

Quick Start Guide

1. Get the Linkind app from App Store or Google Play.
Linkind app is applicable for IOS 8 or higher, Android 4.1 or higher.



2. Create an account and sign in.
3. Press '+' button to add the light bulb.



4. Follow the instructions on App.

- 5 -

Contact Us

LINKIND TECHNOLOGY CO.,LIMITED

FLAT/RM 19C LOCKHART CENTRE 301-307
LOCKHART ROAD WAN CHAI HONGKONG

Phone: 1-855-999-6677
Website: www.linkind.com
Email: service@linkind.com

- 6 -