

Size: 212.3x75.5mm  
材质: 108g铜板纸, 正反面印刷  
DOUBLE SIDE PRINT

### xxVibe QUICK START GUIDE

#### Mobile Bass LED Wireless Speaker

##### CHARGING THE SPEAKER

⚡ Charge the speaker before using it for the first time.

⌚ Plug in the cable to the micro USB port and charge for 2 hours.

Connect the charging cable to charging port.



### xxVibe QUICK START GUIDE

#### Mobile Bass LED Wireless Speaker



##### FEATURES/PARTS

1. Press to switch modes: Bluetooth / USB / TF Card / AUX / FM.
2. (-) Press for previous song. Press and hold to reduce volume.
3. Press to play / pause music / scan.
4. (+) Press for next song. Press and hold to increase volume.

### xxVibe QUICK START GUIDE

#### Mobile Bass LED Wireless Speaker

##### PAIRING YOUR SPEAKER

Your speaker will work best if it is within 30 ft. of your smart device. You may experience sound briefly cutting off if you are out of range or if your wireless connection is weak. Make sure Bluetooth is enabled on your smart phone or tablet before starting the pairing process.

1



Turn on the speaker by flipping the Power Switch to the "On" position. The speaker will "beep" when it is ready to connect.

2



From your smart phone or tablet, find a list of nearby devices and choose "DG-SQST". Enter "0000" if asked. The speaker will "beep" again when pairing is complete!

### xxVibe QUICK START GUIDE

#### Mobile Bass LED Wireless Speaker

##### SPECIFICATIONS

BLUETOOTH VERSION: V5.1  
OUTPUT POWER: 5W  
IMPEDANCE: 3Ω  
FREQUENCY RESPONSE: 100Hz-20KHz  
WIRELESS RANGE: 10m  
PLAY TIME: UP TO 2 HOURS  
STANDBY TIME: UP TO 8 HOURS  
CHARGING TIME: ~ 2 HOURS  
BATTERY CAPACITY: 1200 MAH  
BT ID: D044460  
FCC ID: 2AANZ- BTS21  
SKU:DG-SQST-BT21

##### WARNING

Keep away from water and moisture.  
Keep away from heat sources.  
Do not disassemble.

### xxVibe QUICK START GUIDE

#### Mobile Bass LED Wireless Speaker

##### FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Please note that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

##### FCC INSTRUCTIONS FOR A CLASS B DIGITAL DEVICE OR PERIPHERAL

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and

### xxVibe QUICK START GUIDE

#### Mobile Bass LED Wireless Speaker

used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- RF warning statement
- The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.