



# Quick Start Guide



# **Hello there!**

Welcome to the Storypod family!  
We're thrilled to have you :)

Discover how to:

1. Set Up Your Storypod
2. Listen to Crafties & Books
3. Record Onto iCrafties
4. Change Storypod's Sleeve
5. Put a Lanyard on Storypod

# 1. Set Up Your Storypod

---

- 1 Charge Storypod with the USB cable supplied.




- 2 Install the Storypod app on your phone and create an account.



Point your camera at me!

- 3 Follow the in-app instructions to connect your Storypod to Wi-Fi.




## 2. Listen to Crafties & Books

---

Turn Storypod on/off by holding the Play button for 2 seconds.

Then place a Craftie or Read-Along Audiobook on Storypod to trigger their audio!



See Status Light meanings at:  
[www.storypod.com/statuslight](http://www.storypod.com/statuslight)

### 3. Record Onto iCrafties

---

With your Storypod turned on and connected to the internet, place an iCraftie on Storypod. Then log in to the Storypod app and click on the iCraftie.

Using the Storypod app, you'll be able to record or upload audio onto the iCraftie. The next time you place the iCraftie on Storypod, your recordings will play!



## 4. Change Storypod's Sleeve

---

Storypod has interchangeable sleeves for your little ones to customize their Storypod with their favorite designs!

To remove a sleeve, simply pinch it by its top edge and pull it off the Storypod. To put a new sleeve on, use two hands to lower it onto Storypod while stretching it open (like a sock).

Sleeves are machine washable!  
Wash cold, dry with delicates.



Shop sleeves at [www.storypod.com/sleeves](http://www.storypod.com/sleeves)

## 5. Put a Lanyard on Storypod

---

Storypod has interchangeable lanyard straps with fun designs to easily carry Storypod around.

To put a lanyard on Storypod:

1. Thread its loop under Storypod's top-side metal bar.
2. Hold the loop open and thread the lanyard through it.
3. Pull the lanyard until it is tight and secure on the bar.



# Troubleshooting

To reset your Storypod to Factory Settings, insert a paperclip through the pinhole on its bottom side and hold for 3 seconds.

For detailed support articles  
please visit:

[www.storypod.com/help](http://www.storypod.com/help)

Or contact us at:

[help@storypod.com](mailto:help@storypod.com)



## **Safety Information**

### CAUTION - ELECTRIC TOY:

Not recommended for children under 3 years of age. As with all electric products, precautions should be observed during handling and use to prevent electric shock.

**IMPORTANT: Please read all safety instructions in this guide before starting to use Storypod and store it for future reference.**



FCC ID: 2AXQ6-STORYPOD1

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## **FCC NOTICE TO USERS**

This product conforms to Safety Requirements of ASTM F963.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the Storypod and receiver.
- Connect the Storypod into an outlet on a circuit different from that to which the receiver is connected.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

**WARNING:** Not suitable for children under 3 years. Small parts. Choking hazard. Long cord. Lanyard strap. Strangulation hazard.

**WARNING:** Headphones cannot be used while device is charging. Risk of electric shock.

**WARNING:** All Crafties contain strong, non-removable magnets. Please keep them away from medical equipment such as defibrillators, shunts, and pacemakers, as well as any products sensitive to magnets. Do not remove! Swallowed magnets can stick together across intestines causing serious infections and death. Seek immediate medical attention if magnet(s) are swallowed or inhaled.

## **INSTRUCTIONS FOR SAFE USE**

Though Storypod's design is robust to withstand rough treatment by kids, its internal components are not unbreakable so treat with as much care as possible. Specifically:

- Do not attempt to operate if damaged.
- Keep Storypod out of direct sunlight.
- Operate Storypod in room temperature and keep it away from any heat sources.
- Do not purposely drop Storypod on hard surfaces.
- Do not immerse Storypod in water and avoid exposing it to excess moisture. Storypod is not waterproof nor water-resistant.
- Do not tamper with screws or take apart Storypod in any way.