

FRONT

BACK

# GOJOY BLAST



for use with  
Bluetooth  
enabled devices

USER  
MANUAL

# GOJOY

Quest USA CORP  
495 Flatbush Ave.  
Brooklyn, NY 11225

© Gojoy & UJOY are registered trademarks of Quest USA Corp. All other trademarks and trade names are property of their respective owners. Designed by GOJOY & UJOY in New York. All rights reserved. Limited lifetime warranty. To activate your product warranty, go to our website [www.gojoy.com](http://www.gojoy.com) & register this product.

Made in China.

## •YOUR UJOY PRODUCT

Thank you for purchasing and using the "UJOY BLAST" wireless Bluetooth® speaker. This product can provide a high quality listening experience for your mobile phone, computer and other media devices. Before using this product, carefully read this manual to correctly operate this device. Please ask your local dealer if you have any questions.

UJOY BLAST Bluetooth® Speaker X 1  
Aux Cable X 1  
USB to Micro Charging Cable X 1  
User Manual X 1

## •SPECS

Bluetooth®: SBC (High speed) (EDR and BDR)  
RMS: 12W  
Frequency response: 100Hz-18KHz  
S/N: >=80dB  
THD: <=10%  
Battery: 2400 mAh rechargeable battery  
Horn: 6.5" x 2" magnetic resistant 3 ohms  
LED Mode: One mode (Auto quick flash)  
LED Colors: Red/Green/Blue  
Play time based on 80% volume: 1-1.5 hours  
Charging time: 3-4 hours

## •BATTERY CAUTION

The battery used in this device may present a risk of fire, explosion or chemical burn if used incorrectly. Never use or charge the battery if it appears to be leaking, discolored, deformed or in any way abnormal. Never disassemble the unit or attempt to remove the battery as that could cause leakage of alkaline solution or other electrolytic substances. Never expose the battery to any liquid. Never expose the battery to excessive heat such as direct light or fire. Always keep the battery out of the reach of infants and small children.

## •BATTERY DISPOSAL

Please do not attempt to change the battery yourself. If the battery has died, you should follow the disposal instructions listed here. Never dispose of used batteries/electronics with ordinary solid wastes. Always dispose of used batteries/electronics in accordance with the prevailing community regulations that apply to the disposal of batteries/electronics. If there are no local regulations concerning battery/electronics disposal, please dispose of the device in a waste bin for electronic devices. Many electronics retailers now recycle batteries and other electronic components at no charge.

## •DEVICE FUNCTIONS

### FUNCTIONS

- ON/OFF button: Swipe the button to turn on or off.
- MODE button: Press to switch among Bluetooth®, FM, AUX, USB, TF modes. Press and hold to turn on/off LED light.
- Press the button to play/ pause music.
- About the button: Press once to play previous song under Bluetooth®/TF/USB/AUX modes, or play the previous radio station under FM mode. Press and hold to backtrack under TF/FM/USB modes.
- About the button: Press once to play next song under Bluetooth®/TF/USB/AUX modes, or play the next radio station under FM mode. Press and hold to fast forward under TF/FM/USB modes.

- Play music from a USB stick by inserting a USB stick into the USB port. Supports MP3 format.
- Play music from a TF card by inserting a TF card into the TF card port. Supports MP3 format.
- FM scan function: Press and hold button under FM mode. UJOY BLAST will auto-search and store channels. (BLAST will go back to the channel it was previously on.)
- Charging cable is Micro DCSV.

## •OTHER IMPORTANT SAFETY INFORMATION

To avoid danger of choking, please keep cables away from babies and children. This product is not a toy. Do not treat this product as household waste. Dispose of this device properly by handing it over to local collection services for recycling of electronic equipment. By ensuring that this product is properly disposed of, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling. For more detailed information about this product, please contact your local household waste disposal service or the shop where you purchased this item.



## •INSTRUCTIONS

### PAIRING THE DEVICE

- The speaker will automatically enter pairing mode when turned on. Enable Bluetooth® on the device you want to connect the speaker to and connect your device to UJOY BLAST. BLAST will automatically reconnect with a device it was previously connected to within 10 seconds.

### TRUE WIRELESS STEREO FUNCTION (requires 2 BLAST)

- TWS allows you to sync 2 BLAST. Make sure neither BLAST are connected to any device. Power on both and make sure they are in Bluetooth® mode. Double click . An audio indicator will confirm the speakers have connected with each other. Enable Bluetooth® on the device you want to connect the speaker to and connect your device to UJOY BLAST. Double click again to cancel TWS.

### CHARGING

- Connect the USB Charging Cable with the speaker and an appropriate charging source.

## •LIMITED LIFETIME WARRANTY

Our product is warranted for a limited lifetime warranty from the date of purchase. The warranty is provided on all material defects and workmanship. Guarantee of 24 months does not apply to decrease in the effective capacity caused by its use or age. WE RESERVE THE RIGHT TO CHANGE TECHNICAL SPECIFICATIONS. For more information please visit, [www.gojoy.com](http://www.gojoy.com).

PLEASE FOLD ON THE GREEN LINES AND PRINT DOUBLE SIDED. DO NOT PRINT GREEN LINES

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This equipment should be installed and operated with minimum distance 20cm between the radiator& your body.