

# TK2703 RF Keyboard Specification

## 1. Electronic Specification

TK2703 Wireless is located in the wireless multimedia keyboard.

RF Link	
Carrier	Channel : 27.145MHz
mode	Shared channel for keyboard
Distance	Keyboard: 2 Meters ; It is based on wooden table and open site. The receiver should be out of your computer and monitor for more than 20 cm.
Bandwidth	10KHz±1kHz
Broadcast mode	Single way
Modulation	FSK
Channel Separation	50KHz
ID code	256 sets ID code
Transmitter	
● Keyboard	Features
keypad	The 99-keytop of keyboard with 16 hot keys
Power	3.0V , AA*2
Voltage range	2.4V~3.2V
Current Consumption	Run mode: 7mA ; Sleep mode: 13uA
Channel	One Channel
Suspend Timeout	Keystroke wakeup
Peak power level	<80dBuV
Low Battery	2.4±0.5V approximate
ID Button	Tack switch

### **Keyboard Hardware Installation**

1. Always turn off your computer you connected or disconnect your keyboard.
2. Plug the keyboard connector firmly into the AT/PS2 port on the computer.
3. Turn on your PC.

### **Software Installation**

1. Make sure the keyboard is connected to the computer.
2. Put the Setup disk (or CD) into the disk drive.
3. From Windows95/98,click on **Start/Run** .
4. Specify the disk drive and type **setup**. For example, type **e:\setup** if you are using drive E.
5. Follow the instructions on the screen to finish the software installation.

### **Internet & Multimedia hot keys**

1. Track rewind: Previous track of audio or video CD' s
2. Play & Pause: Play and Pause of audio or video CD' s
3. Stop: Stop play of audio or video CD' s
4. Track forward: Next track of audio or video CD' s
5. Power : Turn system off into power mode
6. Vol.-&+: decrease or increase volume
7. Mute: Mute volume
8. Favorite : open my favorite mode
9. E-mail: Open mail folder
10. Back: See last page when viewing the Internet
11. www: Open browser in Netscape or IE
12. Forward: Go to next page when viewing the Internet
13. Sleep: Turn system into sleep mode