




GFSK-Ant2-2440-0~Reference-PASS




GFSK-Ant2-2440-30~1000-PASS



GFSK-Ant2-2440-1000~26500-PASS



GFSK-Ant3-2440-0~Reference-PASS




GFSK-Ant3-2440-30~1000-PASS



GFSK-Ant3-2440-1000~26500-PASS



GFSK-Ant1-2480-0~Reference-PASS




GFSK-Ant1-2480-30~1000-PASS



GFSK-Ant1-2480-1000~26500-PASS



GFSK-Ant2-2480-0~Reference-PASS




GFSK-Ant2-2480-30~1000-PASS



GFSK-Ant2-2480-1000~26500-PASS



GFSK-Ant3-2480-0~Reference-PASS



GFSK-Ant3-2480-30~1000-PASS




GFSK-Ant3-2480-1000~26500-PASS

AppendixG: Duty Cycle

Test Result

Test Mode	Antenna	Frequency[MHz]	ON Time [ms]	Period [ms]	Duty Cycle [%]	Duty Cycle Factor[dB]
GFSK	Ant1	2401	0.00	0.00	100	--
GFSK	Ant2	2401	0.00	0.00	100	--
GFSK	Ant3	2401	0.00	0.00	100	--
GFSK	Ant2	2402	0.00	0.00	100	--
GFSK	Ant1	2440	0.00	0.00	100	--
GFSK	Ant2	2440	0.00	0.00	100	--
GFSK	Ant3	2440	0.00	0.00	100	--
GFSK	Ant1	2480	0.00	0.00	100	--
GFSK	Ant2	2480	0.00	0.00	100	--
GFSK	Ant3	2480	0.00	0.00	100	--

Test Graphs






NTNV-GFSK-Ant1-2440



NTNV-GFSK-Ant2-2440




NTNV-GFSK-Ant3-2440



NTNV-GFSK-Ant1-2480



NTNV-GFSK-Ant2-2480



NTNV-GFSK-Ant3-2480

-----End-----