

LEGRAND MODEL 067695 LABEL LOCATION (SEE NOTES BELOW PICTURE)



NOTES:

1) FCC and IC markings as shown above to be permanently laser etched to inside of back cover. 1.2mm minimum text height

(This is documented in the Legrand Model 067695 Label Drawing REV1)

2) The ID and HVIN numbers listed below can be found on the inside of the back cover of the device. To locate the IDs, remove the back cover screw as shown in step 3 of the battery replacement diagram. Turn the cover over to find the ID and HVIN laser etchings centered on the inner left side of the back cover. The device will not operate with the back cover removed.

(This is documented in the Legrand Model 067695 Users Manual REV1)