



1. External Photograph of EUT

Brand Name: Zebra / Model Name: TC58B1

Sample 1













Sample 2















Sample 3















2. Photograph of Accessory

Brand Name: Zebra / Model Name: TC58B1

Specification of Accessories				
Adapter	Brand Name	Zebra	Part Number	PWR-WUA5V12W0US
Battery 1X	Brand Name	Zebra	Part Number	BT-000442-0020
Battery 1.5X	Brand Name	Zebra	Part Number	BT-000442-0820
USB TYPE A to TYPE C cable	Brand Name	Zebra	Part Number	CBL-TC5X-USBC2A-01
USB TYPE C to 3.5mm audio connector	Brand Name	Zebra	Part Number	ADP-USBC-35MM1-01
3.5mm Earphone	Brand Name	Zebra	Part Number	HDST-35MM-PTVP-01
USB TYPE C Earphone	Brand Name	Zebra	Part Number	HPST-USBC-PTT1-01
Headset Jumper	Brand Name	Zebra	Part Number	CBL-TC51-HDST35-01
Trigger Handle	Brand Name	Zebra	Part Number	TRG-NGTC5-ELEC-01
Soft Holster	Brand Name	Zebra	Part Number	SG-NGTC5TC7-HLSTR-01
TC53/TC58 RUGGED BOOT	Brand Name	Zebra	Part Number	SG-NGTC5EXO1-01

Remark: For accessories equipped with this EUT, please refer to the following photos.



A photograph of a Zebra MC9000 handheld barcode scanner and its accessories. The scanner is black with a yellow trigger. It is shown next to a black charging dock with the Zebra logo. Two Zebra batteries are visible, one in the dock and one next to it. A USB cable and a coiled cable are also present. A small circular device is attached to the coiled cable. A ruler is placed at the bottom for scale.

Adapter



Battery 1 (1X)



Battery 2 (1.5X)

