
# K26 Car dashcam

This product adopts high performance chipset to provide high definition video with seamless motion picture. It has passed the strict certification of CE and Rohs, supports FHD 1080P and K26 video recording. Please read this manual carefully before use and keep it in a safe place, we hope this product can meet your needs and serve you for a long time.

# I. Appearance and Button description

(Following pictures are for reference only, please check the real product)



- 13. TF slot
- 10. OK 14. MIC

3. HOILEI	4. 50
7. Menu	8. Up
11. Cabin lens	12. Res
15. Front lens	

# **Power button**

1. Switch On/Off

In the off state, long press [Power button] for 3 seconds to turn on the power of the dashcam, it will start recording video automatically.

In the power on state, long press [Power button] for 3 seconds to shut down, it will save the video file and settings automatically.

# 2. Turn off the screen

In the power on state, press [Power button] to turn off the screen, press again to turn on the screen.

## Menu

- 1. Short press to open menu
- 2. Long press to enter into playback mode

### UP

- 1. In System setting mode, short press to switch the settings
- 2. In video mode, short press to switch the lens real-time view
- 3. In playback mode, short press to choose the file which you want to playback
- 4. Long press to turn on / off WIFI

#### Down

- 1. In System setting mode, short press to switch the settings
- 2. In playback mode, short press to choose the file which you want to playback
- 3. In video mode, short press to turn on / off audio

#### ОК


- 1. Short press to start / stop recording
- 2. In System setting mode, short press to confirm your settings

# **II. Function interface**

#### **Recording video**



#### System setting



- •Loop Recording: 1 MIN、2 MINS、3MINS
- •Record Audio: OFF、ON
- •G-Sensor: OFF、Low、Middle、High
- •Parking Guard: OFF、Low、Middle、High
- •Date Stamp: OFF、ON
- •GPS Stamp: OFF、ON
- •Back mirror: OFF、ON
- •License: OFF、ON
- •Screen Saver: OFF、10S、30S、60S
- •Key Voice: OFF、ON
- •Speaker: OFF、Low、Middle、High
- •Boot Sound: OFF、ON
- •Language: English, Chinese, French, Italian, etc

- •Date Time: System date and time setting
- •GPS Test: Show GPS latitude / longitude information
- •Time zone: Time zone selections
- •Speed Calibration: -6、-4、-2、0、2、4、6。
- •Speed Setting: OFF、Auto。
- •Speed Unit: KM/H、MPH。
- •Warning Switch: OFF、ON。
- •Wi-Fi APP: OFF、ON。
- •Fill Light: OFF、ON、Auto。
- •Format: Confirm、Cancel。

Note: Formatting will delete all the files (including locked files) in the memory card, after formatting , the files will not be recoverable, please copy important files before format.

•Default: Confirm, Cancel. Selecting "Confirm" will restore the system defaults

•Version: Version information

Playb	ack
-------	-----

File Management					
DIRECTO RY	٨	/IDEO	VIDEO_ROCK	рното	
FRONT		20240110_182157_f.ts		6 î	
INSDE	20240110_181557_f.ts			f 🗍	
REAR		20240	110_181449_f.ts	f î	

# III. APP code



Please download the APP with your mobile phone for the first time to use the dashcam.

1. Start the car to make the dashcam into working state, in the mobile phone to settings to find the WIFI name "FHCam - \*\*\*\*\*\*\*", enter the password 12345678 to connect.

2. After the connection is completed, enter the APP, the time of dashcam will be synchronised with the time of your mobile phone, and the video files and photos on the TF card will also be synchronised to the APP, you can playback and delete the files. Whether you need to format the TF card on APP, you need to check if the files have been saved into TF card.

3. Be sure to format the TF card on dashcam for the first time you use it, and format it once or twice a month regularly.

Note: When formatting TF card, please copy the important files to avoid losing files.

## **APP function introduction**

1. APP interface



#### 2. Setting interface

e.	Camera Settinge	#114800
Saural Res	priling	
Spinister 10	Autore .	-
Long Barry	they Owatken	-
line.		a principal a
Time Stars		
Res Minte	ç.	
Confector Sa	ning.	
Rest Vote		
Yook Gert	et .	•
-	Constant Property in	
And a cost	ntor Collision Detects	<b>at</b>
Time-tique	Video FPS	Ren (41

- Sound recording: On, Off
- Speaker Volume: Off, Low, Medium, High, Maximum
- Loop recording Duration: 1 mins, 2 mins, 3 mins

• Time stamp: On, Off (On: video & Photo with time watermark; Off: Video & Photo without watermark)

- Rear Mirror: On, Off
- Collision sensing: Off, Low, Medium, High
- Boot voice: On, Off
- Voice control: On, Off
- Parking monitor collision detection: Off, Low, Medium, High

• Time-Lapse video FPS: Off, 1 Seconds, 2 Seconds, 3 Seconds (the length of video file is set to 1 minute, and the time-lapse recording frames is set to 1 second, which is equivalent to recording a 1-minute video, and the actual recording time is 30 minutes)

• WIFI name: Wifi name can be modified (the dashcam will reset back to the default WIFI name after restoring the factory settings)


• WIFI password: Can manually set to WIFI password (the dashcam will reset back to the default password 12345678 after restoring the factory settings)

- Firmware version: Dashcam software version
- Format: Format card (recommended to format once or twice per month)
- Restore factory settings: Rest settings function

#### 3. APP Playback interface



## IV. Installation guide



- 1. Stop the car engine
- 2. Insert TF card into the card slot

Note: Please use high speed TF card (Class 10 or above)

3. Install the dashcam on the front windshield

Note: When wiring, you can lay the charging cable along the edge of the

windshield of the car

- Install the rear lens at the back of the vehicle, pay attention to the direction when installing, the wiring can be laid along the roof of the vehicle. After the installation is completed, connect the rear plug to the rear lens port of the dashcam.
- 5. Adjust the position of the lens to ensure that the lens is level with the ground.
- 6. Start the engine and check whether the dashcam has been turned on and installed correctly.

Note: When the dashcam is installed correctly, the indicator light will turn on; dashcam start recording, the indicator light is flashing. Please check screen display is working, if it is inverted image, please contact us in time.

# **FCC Warning**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.