
Order delivery date to be confirmed after proof sheet approved


MODEL: NSP-0282 QTY: 400 pcs

### Face-changing Speaker



正面

反面



### **Function Guide**

- (1) Power On&Off/ Play &Pause/ Incoming Call Receiver
- (2) Light On/Off/RGB Light Mode
- (3) USB Charger Jack
- (4) Microphone Position
- (5) Audio Release Speaker Net

### • Product manual

Welcome to buy our patent design "Face-Changing Speaker" our company reserves the final interpretation of the manual. This product is subject to change without notice. The user should do the important data backup, The Company shall not be liable for any loss resulting from loss of data. Please read the operating instructions carefully before use and use the original supplied accessories

### Product Features Description

- \* This product is a portable robot type speaker that use Bluetooth wireless technology. The Bluetooth device to be connected to this system needs to support A2DP (Advanced Voice Delivery Configuration Protocol).
- imes 3W Amplifier and enhanced bass (passive diaphragm) make the sound more robust.

### Technical Spefications:

- $\ensuremath{\mathbb{X}}$  Charging time: Around 2.5 hours to finish charging. X Lithium battery specifications: 3.7V / 400MA capacity
- X Working Time: Up to 4 hours at normal volume 60%. X Maximum power distortion 7%.
- X Speaker Specifications (ø36MM unit./4ohms/3.W bandwidth. [70HZ- - 20KHZ] sensitivity; 1K (85dB).
- X Speaker rated power output 3W.
- X Signal to noise ratio: 90HZ-20K / 65dB.
- X Follow the Bluetooth V5.4
- X Compatible with A2DP \ AVRCP high-quality stereo audio transmission and remote control protocol
- X Support hands-free Bluetooth hands-free (HFP protocol)
- X Bluetooth work in the world-wide 2.4GHz ISM, the use of band (2.4000GHZ - 2.4835GHZ).
- \* Wireless effective transmission distance of up to 10 meters
- X Support for TWS interconnection X Unit Size:6.80\*6.03\*8.00CM.

# Operating Instructions

### **X Bluetooth Connection**

- 1. Press the [Power] button for 2 seconds, release the button after turning on ,The speaker light starts to blink quickly into the green light pairing state,The pairing of this system is named "Face-Changing Speaker"
- 2. A list of detected devices appears on the display on the
- Bluetooth stereo source device. The system displays "Face-Changing Robot" to select this device to perform pairing. Turn into muti-colors breathing light state after the beep sound, indicating that the pairing is successful.
- 3. The speaker remembers the last connected device and will automatically connect the last successful pairing device each time while the speaker is restarted.
- $\dot{\alpha}$  : If the connection is not successful, please turn off the speaker and reconnect with the device.

### **X TWS Interconnection for two speakers**


Please take two TWS speaker press and hold the [Power] button for 2 seconds at the same time to turn on the speaker, release the button after the beep sound.

# Sawoloľ

### **FACE-CHANGING SPEAKER**

- EQ Audio Changing Effects /RGB LED Lights

INSTRUCTION MANUAL





-The speaker will star blinking with a green light into TWS pairing state, two TWS speaker will match automatically with a beep

-Please select "Face-Changing Speaker" to pair your device the speaker system. Turn into muti-colors breathing lights state after the beep sound, this will indicate that the pairing is successful. Please Play the device into the music playing state.

### X Play Music

When the speaker is connected to the Bluetooth stereo source device. Press the [Play] button of the stereo source device. The system will enter into the music playing state. To pause the playing state, press the [Pause] button shortly.

### **X** Answer incoming calls

There is a call indication sound when the incoming call sound, short press [Play] button to answer the call.

# X Redial the phone number

When the speaker is switched on, press the [Play] button shortly twice and the system will automatically re-dial the last phone

**Cancel the telephone dialing**If the speaker is dialing a call, and needs to cancel the dialing. Press [Play] button shortly to cancel the dialing

**\*\* Hang up the phone or Reject Phone**During the call, if you want to hang up the phone call, press the [Play] button to automatically hang up the current phone call. Double press the [Play] button to reject incoming call.

### **X Light Switch**

- Long press the [Light] button for 2 seconds to turn into muti-colors breathing light state.
- Short press the [Light] button to fix single light state, Short press the [Light] button 6 times will switch into RGB Led Light state.

### **X** Power Charging

battery fully charged.

- Use the USB cable to connect to the speaker, when charging The charging cable a commerce to the speaker, when charging there is a red light, and while the red light goes out is fully charged.

  The charging cable can be used with regular USB 5V charger Car USB charger etc. And it is not compatible with fast charger,
- especially with 9V-12V and other chargers whose output voltage is higher than 5Voltage.

  Note: Please charge the battery in the off state to ensure the

# The allowable ambient temperature of charging the product is The allowable amblent temperature of charging the product within the range of 0°C-45°C. If the blue light is long when charging for it doesn't meet the charging range of the product. Please don't charge the unit speaker while it's working.

# Solution of the different situation

The speaker in use if you encounter the following conditions

### X Automatic turn-off

This may be the unit's power shortage, please re-charge the speaker, when it is fully charged and try to turn on again.

# ※ Can not be charged

Please try to change the USB charging cable

### X System halted or control failure

If the device system halted or out of control, please charge the device and then pull out the charging cable can be resume to

### X Can not be paired or connected

In your list of Bluetooth devices to delete the local system device name, then the speaker operation into the pairing mode, try again on the speaker pairing.

## WARNING!!!

THIS PRODUCT IS NOT A TOY AND IS NOT SUITABLE FOR CHILDREN UNDER THE AGE OF 3.

- Do not expose this product to water or fire, diluents or other Chemicals.

  - Do not stop the dancing motion of the speaker by hand with force
- to avoid damages.

- Do not use the speaker close to magnetic field and electricity.

   Do not use the speaker close to magnetic field and electricity.

   Do not use the speaker under direct sunlight or close to heating apparatus.
- -Do not try to disassemble, repair or close to heating apparatus -Do not use the speaker while driving in a car and/or riding a bike
  -Do not have the packing, batteries, and used electronic

components together When discarding please separate the different components before discarding.

File No: 2302004-05KIM

Designed by: kimmy

PI No.:

Handed by:Viola

Date: 2024-8-06