

Downloading the App


Scan the following QR code, download and install the /



Scan QR Code and Download

Charging and Active

Charging the device to active before the first time usi To charge your device, plug the charging cable into the adapter or USB port on your computer.



Pairing Open the App and set up your profile Go to the「Device」, Click「Add a De . se your device on the scanning lis you identify your d evice on the scanning list.










Messages

Menue

Smart Watch Features



Smart Watch Features



Smart Watch Features



Blood Pressure Test Tap on the blood pressure i o start measuring your blood In the blood pressure page. It c. show the blood pressure measured data of the last times.

Smart Watch Features










he Smart Watch could record eart rate all day You also could tap on the page to rt measuring heart rate.












Smart Watch Features

Remote Shutter After connecting the device, yo can remote contral the camera or

Smart Watch Features


Other Features Other features include stopwatch, alarm, timer, brightness, mute on/off, theater mode, factory reset, power off ind about.

Smart Watch Features



Theater Mode

Smart Watch Features





Getting to Know Your Device

1.Using in Wet Conditions

stant, which means it is rain-proc

2.Using Quick View

your wrist towards you and the time screen will appear few seconds

Player Shutter can remote contral the music play on your phone.

Stop Watch p the start button on stopwatc page to start timing, and tap the top button to stop timing.

General Info & Specifications


.Environmental Conditions perating temperature: 14🛛 to 122🖾 (-10🖾 to 50 on-operating temperature: -4🛛 to 140🖾 (-20🖾 to 60🖾)

3.Disposal and Recycling

pusehold waste, the Smart Bracelet unit is considered elec equipment collection facility.

For more information, please contact your local election equipment waste management authority or the retailer where you bought the product.






扫描下方二维码下载并安装手表客户端。



扫码下载手机客户端

手表充电与激活

首次使用手表之前需要充电激活; 使用配备的磁吸充电器吸附到手表背面的金属触点,3 另一端接入USB充电头或者电脑USB接口即可。






控制中心 下划 🛉 📘 上划



消息列表








遥控器。

连接手机后,手表可以作为手机

制页面点击即可触发手机相机



/ 🔘 📼

.

其他功能

手表的其他功能中包含秒表、闹钟、

时器、亮度调节、振动开关、影院模

恢复出厂设置、关机操作、关于。

点击秒表图标,进入秒表功能。

手表功能简介



常见问题与解答

血压数值为什么跟血压计有偏差?

压计测量时绑带使 分支流动: 血管紧张感增加, 将使上下血压测量值偏差会

为什么不能佩戴手表洗热水澡?

相的,其分子半径小,容易从手表的壳体空隙渗进去 短路,损伤手表电路板,进而损坏手表。

常见问题与解答

为什么手表接收不到消息推送?

手机客户端的通知开关)

(需要在手机设置中找到通知) 手机客户端的通知开关)

FCC Warnning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection againstharmful interference in a residential installation. This equipment generates, uses and can radiateradio frequency energy and, if not installed and used in accordance with the instructions, maycause harmful interference to radio communications. However, there is no guarantee thatinterference will not occur in a particular installation. If this equipment does cause harmfulinterference to radio or television reception, which can be determined by turning the equipmentoff and on, the user is encouraged to try to correct the interference by one or more of thefollowing measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.