

5. Speaker

diagrams. Pls refer to the actual device.

Basic Parameters

Product name: Dash Cam

Power supply: car charger

Items in the box:

8. Camera

Brand Name: KAWA

Image resolution: 2560\*1440

3. Holder 6. Micro SD card slot 9. Heat-resistant adhesive paper

only. Due to the upgrade of product, your device may be slightly different with the schematic

Basic Parameters -----

Items packed into the color box ----

Instructions for Use of Micro SD card

Due to the complexity of the sound environment in the car and the diversity of the

user's spoken language, sometimes the voice commands may lead to inaccurate or

This product can be used in conjunction with KAWA DVR App. Please search for "KAWA DVR"

in the App Market or scan the QR code below to download and install the KAWA DVR App.

Note: to connect the hotspot of the Dash Cam, the operating system of your phone should


Precautions before Installation ----

false triggering of functions.

Download KAWA DVR App

be Android5.0 or iOS8.0 and above.

User guide of Power Supply ----



As shown in the figure, route the power cord along the

top of the windshield, the A-pillar, and the storage box

corresponding to co-driver seat to the vicinity of the

above figure is provided for reference only.

achieve different functions.

cigarette lighter, connect the car charger, and then

Note: the location of the cigarette lighter may vary from vehicle to vehicle, and the

You can press/click the power button different times or for different lengths of time to

Status Operation Function

Power-off Press the power (the power supply is connected) Press the power button for 1s To turn on the Dash Cam

• Please insert an appropriate Micro SD card before using the Dash Cam.

to format the Micro SD card in the Dash Cam once a month.

• The default file partition format of the Micro SD card may be different from the format

supported by the Dash Cam. When the Micro SD card is inserted for the first time, please

• To prevent the decline of reading/writing speed after long-term use, it is recommended

• After repeated overwriting, the Micro SD card may be damaged or write at a lower speed,

Micro SD card immediately. The manufacturer shall not be held liable for any malfunction

which will affect its ability to save video and image files. If this happens, please replace the

Micro SD card. Please back up the important data to another device in advance.

format it in the Dash Cam before use. The formatting operation will delete all files from the

Operation Function

Click the power button To turn on/off Wi-Fi

Double-click the power To turn on/off audio

Click the power button
To format the Micro SD card

Click the power button
5 times

To reset to factory defaults

Press and hold the power To reset and restart the

button for 10s Dash Cam

button for 3s

3 times

When an authorization Click the power button To grant authorization

The laws of certain countries, states or provinces may prohibit or restrict the installation

and use of this product in your vehicle. Please comply with all applicable laws and

regulations regarding the use, installation and operation of this product. It is your

responsibility to comply with all applicable laws, rules, regulations and ordinances,

including passenger privacy, and not to use this product in any place where installation  $% \left( 1\right) =\left( 1\right) \left( 1\right)$ 

• To ensure correct installation, please use the supplied accessories in the specified manner.

request is received

Please use this product to the extent permitted by law.

Precautions before Installation

warning を低下させたりするような設置は

Function

Record emergency video

Process phase tasks

Wi-Fi is enabled.

Remains red

Flashes quickly in green

Flashes quickly in blue

Breathes

information loss or user operations of this product.

• DO NOT install this product in front of or near the dashboard, vehicle door or pillar

where one of the airbags may unfold. Please refer to the User Manual of your vehicle for

the unfolding area of the front airbag, in order to prevent product failure and personal injur

• This product is a driving assistance product intended to record what's going on around

your vehicle, not intended to help safe driving. The manufacturer shall not be held liable

for any driving accidents (and any losses incurred therefrom) caused by product failure,

• Due to differences in vehicle conditions, driving habit or driving environment, some

functions of this product may not work properly under certain circumstances. Such factors

することを保証するものではありません。軽度の衝突事故では衝突センサーを作動させることが

できないため、画像が指定のフォルダに記録されない場合があります。

video will contain sound.

video will contain image only (no sound).

Enable the Wi-Fi hotspot so as to connect the KAWA App on your phone.

Disable the Wi-Fi hotspot.

Disable the Wi-Fi hotspot.

• DO NOT use this product at a temperature higher than 60°C or lower than -10°C.

DO NOT subject this product to violent shocks or vibrations, so as to avoid product

• DO NOT use chemical solvents or detergents to clean this product.

If this product is kept idle for a long time, the battery power may be exhausted, and you

Turn off audio

Turn on WiFi

Turn on hotspot

damage, malfunction or functioning failure.

ウェブサイト:www.kawa-in.com

住所:FLAT A 21/F CHEUNG LEE IND BLDG 9 CHEUNG LEE ST CHAI WAN HONG KONG

Turn off hotspot

材质: 105G哑粉, 装订方式: 订装

・ドライブレコーダーは標準のMicro SDカードに対応しています。クラス10以上のデータレートで

16GB~128GBのMicro SDカードを使用してください。

Insert the Micro SD card into the Micro SD card slot with

the contact side down, until you hear a "click" sound.

Remove the protective film from the heat-resistant

adhesive paper on the base of the holder, and attach

the Dash Cam to the dashed box of the anti-static film.

Please press the base of the holder by hand to ensure

• The Dash Cam uses the car cigarette lighter as the power supply. To ensure a stable

power supply, please use the original car charger and power cord. The manufacturer shal

not be held liable for any loss caused by your using any power supply other than the car

duration of work of the Dash Cam may cause unnecessary power loss of the vehicle batter

If the parking surveillance function is not enabled, please turn off the Dash Cam manually

or disconnect the car charger from the vehicle after turning off the vehicle. Then you will

need to turn on the Dash Cam manually after the vehicle is started next time. The manufacturer

shall not be held liable for any loss caused by your failure to turn off the Dash Cam manually

cigarette lighter, or using any non-original car charger or power cord.

a tight fit between the heat-resistant adhesive paper

User guide of Power Supply

3. Attach the Dash Cam

and anti-static film.



爱培科产品包装图纸

图纸提供单位

## 深圳市爱培科技术股份有限公司

项目名称

CJ1005-XS21120140 -说明书

物料编号

物料编号: 1601007-1331-0

版本号

版本号码: V2

设计时间

设计日期: 2022-02-10

—Connect the equipment into an outlet on a circuit different from that to which the receiver

F exposure statement: The equipment complies with FCC radiation exposure limits set

forth for an uncontrolled environment. The equipment should be installed and operated

Address: FLAT A 21/F CHEUNG LEE IND BLDG 9 CHEUNG LEE ST CHAI WAN HONG KONG

with minimum distance 20cm between the radiator & your body.

is connected.

FCC ID:2AZWZ20221

Warranty: 12-month limited warranty

E-mail: support@kawa-in.com

Website: www.kawa-in.com

Manufacturer: KAWA ELECTRONICS COMPANY LIMITED

FCC RF Exposure Warning Statements:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following tw

conditions: (1) This device may not cause harmful interference, and (2) this device must

device, pursuant to part 15 of the FCC Rules. These limits are designed to provide

reasonable protection against harmful interference in a residential installation. This

used in accordance with the instructions, may cause harmful interference to radio

equipment generates, uses and can radiate radio frequency energy and, if not installed an

communications. However, there is no guarantee that interference will not occur in a

relevision reception, which can be determined by turning the equipment off and on, the

particular installation. If this equipment does cause harmful interference to radio or

user is encouraged to try to correct the interference by one or more of the following

For this device, Head SAR and Body SAR was performed with the device configured in

the positions according to EN62311, and Body SAR was performed with the device

For Adapter: Shall be installed near the equipment and shall be easily accessible.

batteries according to the instructions.

Only can use the adapter as below:

Rated Input & Output: 12V & 5V/2A

Model Name: AC01

Manufacturer: Stuff Electronics (Dong Guan) Limited

200mm from the phantom. Body SAR was also performed with the headset attached

For Battery: Risk of explosion battery is replaced by an incorrect type, dispose of used

责任设计师: 孙雯

材质工艺要求

尺寸: 110mmx95mm

所有材质符合RoHS/REACH/WEEE

工艺要求: 色相正确、印迹牢固、 套印准确、各色套印

不露杂色,套印误差≤ 0.1mm

模切走位≤±0.5mm

颜色及 专色:

纹理要求:

变更履历:

1.更新了APP名称

更新入力:本体5V=2A、增加保修时间

添加ios下载二维码

修改英文版机器名称

增加认证信息

增加安卓下载二维码

修改日规内容

增加认证注意事项,修改箭头颜色

比例 1:1 单位 mm