


French

Si la commande de la télécommande ne répond pas, remplacez le véhicule ou rechargez le véhicule ou remplacez/chargez la pile de la télécommande.


UNE FONCTION:



Spanish

Si la consola de la telecommande no responde, reemplaza el vehículo o recarga el vehículo o reemplaza/carga la pila de la telecommande.



FUNCIÓN



Italian

Quando il comando del controllo remoto non risponde, rimpiazzare il veicolo o ricaricare il veicolo o sostituire/caricare la batteria del controllo remoto.

FUNZIONE





CE

German

Wenn die Fernsteuerungsbefehl nicht reagiert, ersetzen Sie das Fahrzeug oder laden Sie das Auto auf oder austauschen/Laden Sie die Batterie der Fernsteuerung.


FUNKTION



English

When the remote control command does not respond, replace the vehicle or charge the car or replace/charge the remote control battery.

FUNCTION:



RC STUNT CAR

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications to this unit without express approval by the party responsible for compliance may void the user's authority to operate the equipment. FCC ID: 2A00000. The proposed key fob device and the device comply with the rules for a Class B digital device, pursuant to Part 15 of the FCC Rules. These rules are designed to provide maximum protection against harmful interference in a residential environment. This equipment does not use any radio waves with the existing energy level. It has been tested and found to comply with the requirements. It may cause harmful interference to other electronic equipment. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. - Connect the equipment to a different power outlet. - Consult the dealer or an experienced radio/TV technician for help. The device and its accessories must not be used in conjunction with any other wireless or wired equipment. Read the manual. The device has been evaluated to meet FCC Part 15 requirements for operation in the unlicensed radio frequency spectrum.



This toy is only to be connected to equipment bearing either of the following symbols.



BATTERY OPERATED PRODUCT
Suitable for ages 14+. As with all electric products, precautions should be observed during handling and use to prevent electric shock.