









<h1 style="text-align: center;">HAVIT</h1>  <p style="text-align: center;">TW002 TW002 Wireless STEREO EARBUDS</p> <h2 style="text-align: center;">USER'S MANUAL</h2>	<h3>Product and accessories</h3>  <p>Earbuds *2 Charging Case *1</p>  <p>Quick start card (1 set in the case)</p>  <p>User Manual *1</p>  <p>Warranty Card (2-year)*1</p>	<h3>Description of product structure</h3>  <ol style="list-style-type: none"> 1. MP3 button (Touch panel) 2. Microphone 3. Power LED indicator 4. Earbuds indicator 5. Charging port 6. Reset button <h3>Wearing method</h3> <p>Insert the earbuds into the ear then adjust the appropriate comfort.</p> 	<h3>Basic function</h3> <h4>01 Power on Bluetooth connection</h4> <p>Follow the steps: (Please confirm that your phone is in the Bluetooth function)</p> <ol style="list-style-type: none"> 1. Power on Open the charging case the earbuds will turn on automatically. The earbuds enter the pairing mode automatically while the indicator of the earbuds flashes while light the other don't flash light. 2. Turn on Bluetooth on your device and select "HAVIT TW002" referring to your phone instructions. The indicator of earbuds turns off if the earbuds successfully paired. Pairing mode can just last 100 seconds. If you miss the pairing time, you need to restart the device and operate follow the procedure above mentioned above. <h4>*Note:</h4> <p>a) HAVIT TW002 is convenient previously connected devices. When turned on, earbuds attempt to reconnect to previously connected devices.</p> <p>b) HAVIT TW002 will disconnect when sleeping.</p>	<p>the working range of Bluetooth. The earbuds will reconnect automatically if you come back to the range in 5 minutes.</p> <h4>02 Power off</h4> <p>Put the earbuds into the charging case and close the case, they will automatically shut off.</p> <h4>03 Answering incoming calls</h4> <p>Double tap the left or right MPB to answer incoming calls.</p> <h4>04 End the call</h4> <p>Double tap the left or right MPB to end the current call.</p> <h4>05 Skipped incoming call</h4> <p>Long press left or right MPB for 1s to reject a call.</p> <h4>06 One tap for voice assistant</h4> <p>Both earbuds work. Triple tap the left MPB to activate voice assistant. Single earbud work. Triple tap the MPB of working earbud.</p>
<h4>07 Switch on/Switch off Game mode</h4> <p>Triple tap the right MPB to switch on/off game mode.</p> <h4>08 Music playing</h4> <ol style="list-style-type: none"> 1. Play/Pause: Double tap the left or right MPB 2. Previous song/Long press the left MPB for 1s 3. Next song/Long press the right MPB for 1s <p>*Note: If only one earbud works, long press left or right MPB for 1s to switch to next song.</p> <h4>09 Charging Case</h4> <p>Charge the case using the Type-C cable connected to a computer or wall charger. When the case is charging, the orange light of the case is always on, and turns steady white after fully charged.</p> <h4>Earbuds</h4> <p>The earbuds make a warning tone to warn low power. Put the earbuds in the case to charge. When the earbud is charging, the white light of the earbud is always on, and turns off after fully charged.</p>	<h4>10 Mono mode (Take out any earbuds as a wireless Bluetooth earbud)</h4> <p>Enter single channel mode only needs to remove one of earbuds from the charging case. If two earbuds are removed before connection, the earbud will be used in TWS mode by default, and the TWS connection will be automatically restored.</p> <ol style="list-style-type: none"> 1. Take out one earbud from the charging case, the earbuds automatically turn on and reconnect to previous connected devices. 2. Switch from one earbud to the other earbud when playing music, taking out the other earbud from the charging case and Press two earbuds will connect automatically. Both earbuds will play music automatically and then put the earbud which do not need anymore into the charging case and the switching process completes. <p>*Note: Call mode is supported.</p> <p>1. Please refer to the TWS mode for more functions.</p> <h4>11 Restore factory settings</h4> <p>If the earbuds can't pair frequently, please restore the factory settings. Put both of the earbuds into charging case and close the</p>	<p>cover. Open the case again after 2 minutes, press the reset button for 5 seconds. The indicator of the case flashes for 5 times quickly. The earbuds will enter the pairing mode again. Search the "HAVIT TW002" Bluetooth pairing name with the mobile phone and connect again.</p> <h4>Specification</h4> <p>Wireless Version: V5.3 Wireless Working Range: 100m (without obstacles) Earbuds Battery: 40mAh Charging Case Battery: 300mAh Play Time: 14(30%) 14h Talk time: 10(30%) 10h Case Charging Time: 1.5h Speaker size: 10mm*2 Speaker Frequency: 20Hz-20KHz Input Voltage / Current: DC 3.7V 500mA WPC ID: 202001-10000</p>  <p>Model: TW002 V5.3</p>	<h4>Warnings</h4> <ol style="list-style-type: none"> 1. Please follow the instruction to operate. 2. Please charge the earbuds with input power below 5V/1A, in order to protect the battery. 3. Please don't use the earbuds in a harmful temperature environment. 4. Please do not use this product near the water. Do not increase the product in any liquid or splash any liquid on this product. 5. Please keep the earbuds from heat source, such as radiators, hot air regulators, stoves, or other heat generating instruments. As it is not safe high temperature. 6. Don't put the parts of the earbuds, such as charging port, LED port and microphone, etc. 7. In order to protect your hearing and extend the speaker service life, it is not recommended to adjust the volume to the maximum level for a long time. 8. Whenever leaving the earbuds, please feel free to contact our after-sales staff in time rather than repair by yourself. Otherwise, you will accept without after-sales service. 	<h4>Warranty</h4> <p>This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) The device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference to a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"> • Reorient or relocate the receiving antenna. • Increase the separation between the equipment and receiver. • Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. • Consult the dealer or an experienced radio/TV technician for help. <p>This equipment complies with FCC radiation exposure limits set forth for unlicensed radio frequency equipment.</p> <p>The maximum SAR for use by an individual in operating or carrying this device is as follows:</p>