

141mm

200mm

Open this card to get started.  
It's time to experience whole-home, uninterrupted WiFi coverage.

We're glad you're here.

**FCC RADIATION EXPOSURE STATEMENT:**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 42.5 cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

**FCC WARNING:**

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of FCC Rules. Operation is subject to the condition to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - Consult the dealer or an experienced radio/TV technician for help.
- FCC regulations restrict the operation of this device to indoor use only. The operation of this device is prohibited on oil platforms, cars, trains, boats, and aircraft, except that operation of this device is permitted in large aircraft while flying above 10,000 feet. Operation of transmitters in the 5.925-7.125 GHz band is prohibited for control of or communications with unmanned aircraft systems.

Your Wyze product is covered by a one-year limited warranty. You can view the limited warranty terms at <https://wyze.com/return-warranty-policy> or request a copy by contacting Wyze at +1 (206) 339-9646.

**NEED HELP?**

Contact our Support Team:  
<https://wyze.com/support>



Scan the QR code to learn more

**BESOIN D'AIDE?**

Contactez notre service d'assistance:  
<https://wyze.com/support>



Scannez le code QR pour en savoir plus

(材質):128g銅版紙

(顏色):CMYK

(上光方式):水性耐磨油

(成型方式):對折

(尺寸):200\*141mm

(公差):+-1mm

**SETUP**

- Download the Wyze app and sign in or create an account.




Apple logo and App Store are trademarks of Apple Inc., registered in the U.S. and other countries and regions. • Google Play and the Google Play logo are trademarks of Google LLC.

- Open the Wyze app and tap the + plus sign on the top left corner of the Home screen. Tap Add Device > Home > Wyze Mesh Router Pro.

- Follow the in-app instructions to finish setup.

**IN THE BOX**

Wyze Mesh Router Pro x 1  
3 Ethernet Cable x 1  
Power Adapter x 1  
Quick Start Guide x 1

**STATUS LIGHT GUIDE**

- |  |  |
|--|--|
|  | Solid green light<br>Power is on and functioning correctly       |
|  | Flashing green light<br>In pairing mode                          |
|  | Flashing blue light<br>Connecting to Bluetooth                   |
|  | Solid orange light<br>Internet connection lost                   |
|  | Flashing orange light<br>Router is performing a booting sequence |

**CONFIGURATION**

- Téléchargez l'application Wyze et connectez-vous ou créez un compte.




Le logo d'Apple et d'App Store sont des marques d'Apple Inc. déposées aux États-Unis et dans d'autres pays et régions. • Google et Google Play sont des marques de Google LLC.

- Ouvrez l'application Wyze et appuyez sur le signe + plus dans le coin supérieur gauche de l'écran d'accueil. Appuyez sur Add Device > Home > Wyze Mesh Router Pro.

- Suivez les instructions de l'application pour terminer la configuration.

**DANS LA BOÎTE**

Wyze Mesh Router Pro x 1  
Câble Ethernet 3' x 1  
Adaptateur secteur x 1  
Guide de démarrage rapide x 1

**GUIDE DES VOYANTS D'ÉTAT**

- |  |  |
|--|--|
|  | Lumi re verte fixe<br>L'alimentation est sous tension et fonctionne correctement |
|  | Lumi re verte clignotante<br>En mode d'appairage                                 |
|  | Lumi re bleue clignotante<br>Connexion  a Bluetooth                              |
|  | Lumi re orange solide<br>Connexion Internet perdue                               |
|  | Lumi re orange clignotante<br>Le routeur effectue une s rie d'amor age           |

A4	UNIT	SCALE	SHEET	MODEL No.	for WZ-Mesh6E 1pack		
	MM	NON	1(1)	PART NAME	QSG		
	APPROVED	CHECKED	DESIGNED	PART No.	515002057547	REV	A4
				QingQingLong			
				龙青青			
				2022-09-29			
				LITEON	光寶科技股份有限公司 LITE-ON TECHNOLOGY CORP.		