

尺寸：70*95mm

材质：80g书写纸

双面印刷

红线为分割线（不打印显示）




MINISO

PRODUCT MANUAL

Eye Mask Headset M82

PLEASE READ THIS MANUAL CAREFULLY BEFORE USING THE
PRODUCT AND KEEP IT IN A SAFE PLACE.




Welcome to MINISO Eye Mask Headset



Turn on and pair


When using for the first time, press and hold the power button for 3 seconds to turn on the device,

When the red and blue lights of the Eye Mask Headset flash, the Eye Mask Headset will enter pairing mode




Touch Operation

Connect with Bluetooth device



⑤

Open the Bluetooth settings option of the Bluetooth device to be paired, enter the options and find the Bluetooth pairing name of the Eye Mask Headset "MINISO-M82". Click the pairing name to pair.



Eye Mask Headset Charge The Instructions

There is a rechargeable battery inside the earphones, which must be fully charged before the first use

1.First open the charging cable provided by the Eye Mask Headset equipment manufacturer, and insert one end of the charging plug into the charging port on the upper end of the Eye Mask Headset . Plug the other end into a power socket. The Mask Headset shows a red lightwhen charging.

- Charge until the Eye Mask Headset indicator changes from red to blue
- It takes about 2 hours to fill.

2.Unplug the charging device configurator to complete the charging. Two, storage of Eye Mask Headset :

- When storing, turn off the power of the earphones and make sure they are properly protected.
 - Avoid high temperatures (above 40 degrees Celsius) such as in a hot carriage or in direct sunlight. (High temperatures can damage surfaces and reduce battery life)
- Basic operation:

Specification of Product

Model of Product: M82

Version: V5.4

Effective Distance: Approx. 10m

Speaker Diameter: $\phi 30\text{mm}$

Impedance: 32Ω

Frequency Respinse: 100Hz-18KHz

Microphone Sensitivity: $-40\text{dB}\pm 3\text{dB}$

Input: $5\text{V}\rightleftharpoons 200\text{mA}$

Battery Capacity: 200mAh

Usage Time: Approx. 10 H

Charging Time: Approx. 2 H

Operating Instruction of Product

Power On (NO.②, ③)

Long press the power button for 3 seconds, turn on the device, and prompt sound "Power on" will appear.

Shut Down (NO.②, ③,)

Long press the power button for 5 seconds turn it off, and prompt sound "Power off" will appear.

Note: After powering on, if it is not paired with a Bluetooth device for 3 minutes, it will automatically shut down; If it is not connected to a Bluetooth device after 3 minutes, it will automatically power off after 3 minutes.

Bluetooth Device Connection (NO.⑤)

a. For the first time, through the Bluetooth device setting option, search for the Bluetooth pairing name of the Eye Mask Headset "MINISO-M82", and tap to connect successfully.

b. For reusing, and automatically connect the Bluetooth device.

Note: The Android system shall be turned on: the volume of Bluetooth device is synchronized with the device

Function Operation (NO.①, ②, ③, ④)

Pause/Play: tap "②, ③" once

Volume Up: Long press "①" for 2 seconds

Volume Down: Long press "④" for 2 seconds

Previous Song: tap "④" once

Next Song: tap "①" once

Call Answer/End: tap "②, ③" once

Call Rejection: Long press the "②, ③" button for 2 seconds

Repeat the last call: click "②, ③" twice

Set automatic shutdown (No. ①)

Automatically shut down within one hour: Double click for the first time

Automatically shut down within two hours: Double click for the second time

Turn off automatic shutdown: Double click for the third time

Charging Cable Connection (No.⑥)

Connect the Earphone to the charger with the Type-C charging cable for charging.

Bluetooth device connection

Note: Bluetooth devices can only be paired one-on-one. Please make sure to disconnect from the previous Bluetooth device when connecting a new device

Washable Eye Mask Headset

The Eye Mask Headset is washable. (Hidden earphones can be removed from the sleep mask)

Indicator Light Display

Power On: The red and blue indicator lights are flashing.

Power Off: Red flashes and then goes out.

Successful Pairing: No light.

Bluetooth Disconnection: The red and blue indicator lights are flashing. Earphone charging: The red light stays on during charging, and turns blue when fully charged

Warranty statement

MINISO product warranty card

Product number			SN number	
User info	name		Purchase date	
	telephone			
	address			
	Invoice number			
Sales unit information	name	(stamp)		
	address			
	telephone			

FCC ID: 2BHJR-M82

FCC Warning:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.

*RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.

US REP

Company Name: Lucky Cowboy Global Services, LLC
Address: 2213 S. Braeswood Blvd. #12E Houston,
TX 77030 USA

Contact Name: Louie Liu

Telephone No: +1 (713) 992-3369

Email: info@luckycowboyglobalservices.com

The above guarantee does not apply to the following situations

1. The validity period of the three guarantees has exceeded;
2. Altering of the warranty cards and product code do not match the product itself;
3. Failure of damages caused by misuse, abuse or improper transportation, use, maintenance or storage;
4. Failure of damages caused by force majeure (such as earthquake, war, fire, etc.) or accident;
5. Zippers and tower buckles are damaged due to excessive force;
6. Off-line or tear caused by overloading;
7. Any damage caused by sharp objects;
8. Products with signs of burn damage or water logging;
9. Damage caused by unauthorized dismantling and modification;
10. Aging, discoloration, wear, cracking and other losses that occur during normal use of the product.
11. If the product's original logo or label is changed or damaged, this warranty will be invalid.

The completeness and appearance of the product and accompanying materials are not covered by the warranty. You should inspect the product on site when receiving it and raise objections to any discrepancies.

MINISO Product service policy

If you encounter a problem, please contact our customer service to solve it.

After-sales email: 7@hifi-earphone.com

Warranty Policy

Disclaimer:

This manual does not come with any form of warranty, position expression or other implication. The products, specifications and information mentioned in this manual are for reference only, and the content will be updated on the website at any time without prior notice.

Warranty statement:

The following guarantee is made for the products attached to this document:

If the product is damaged due to quality defects under normal use within twelve(12) months from the date of your purchase (the "Warranty Period"), and if it can be repaired, it will be repaired free of charge; If the manufacturer confirms that it cannot be repaired, it will be replaced free of charge; the repaired product will continue to be covered by the warranty for the remaining warranty period(a minimum of not less than 30 days). The purchase date shall be based on the sales invoice date; if the purchase date cannot be determined, the warranty period shall be calculated as thirteen(13) months from the product production date.

If you want to apply for warranty, please call the product service hotline first and follow our instructions. When applying for a warranty, you are required to provide a valid sales invoice that is accurate, complete and clearly filled out.

Guidelines for safe and effective use

Note: Please read this information first before using your Bluetooth headset. If the user makes modifications or modifications to this Bluetooth headset without permission, the user will lose the right to continue to enjoy the services included in the device

①Electromagnetic interference:

Electronic devices: To avoid the effects of electromagnetic interference or configuration incompatibility, please turn off your Bluetooth device in accordance with regulations in places with clear instructions.

Civil Aviation: After boarding the plane, please turn off your Bluetooth headset according to the flight attendant's instructions. It is strictly prohibited to use Bluetooth headsets during flight to avoid interference with the aircraft communication system.

②Safety matters:

Placement: It is recommended that when you are not using the Bluetooth headset, place it in a place where it will not be squeezed. Squeezing may cause damage to the product or personal injury.

Children: Do not let children play with Bluetooth headsets. Some of the small parts are detachable and may be swallowed and cause danger.



Important safety tips

● Except for the operation methods specifically marked in the manual, please do not attempt to disassemble or replace any parts in the product.


● This product contains a built-in rechargeable battery. It is prohibited to hit, squeeze, Puncture, or short-circuit the battery. If there are abnormal phenomena such as excessive temperature, deformation, bulging, or leakage, please stop using it. Do not expose the battery to open flames or sunlight. Do not use the battery after it has been immersed in water or in high-temperature or high-pressure environments such as the sun, heaters, or stoves. After using the earphones, do not place the earphones in a humid, dusty, oily smoke, steam, direct sunlight or other high-temperature and high-pressure environment to avoid damage to the earphones and battery. The battery can be charged and discharged for a limited number of times and will eventually age. If the battery is used abnormally, it can be replaced with a new one. However, do not replace the battery by yourself. If the battery is not replaced properly, there is a risk of explosion. It can only be replaced by an after-sales service provider of the same or equivalent type. battery usage.

● After the product is used and scrapped, do not throw the product into a fire. The waste should be disposed of in strict accordance with the garbage classification. Please use this product reasonably and correctly to avoid causing certain injuries and environmental damage.

● During the use of headphones, due to long distances, obstacles in the middle, or a series of interferences such as other radio signals, Bluetooth signals, WIFI signals, etc., the headphones are used when listening to music, watching videos, playing games, etc., there will be occasional lags, voice out-of-sync or disconnection. If this happens, please reconnect the headphones or stay away from interference.

● When charging, please use a charging device with an output voltage of DC 5V/1A. You must choose a charging device from a regular manufacturer that has obtained CCC safety certification. Do not use a fast-charging charger to avoid excessive battery load, which may cause the battery is damaged. Do not charge continuously for longer than the specified charging time. Do not use it while charging to avoid damage.

Enjoy the company of MINISO



Copyright©2024 MINISO Group affiliated
companies and its licensors. All rights reserved

Creating sound
to live with