

## Wireless Karaoke Bluetooth Speaker User Manual

Thank you for your choose this product, Your recognition has always been our driving force.



### 1: Instruction:


Before using this product pls carefully read the instruction first, to avoid any confused.

1): Firstly please press the swich on/off button of this product. Then open your smart devices to connect the Bluetooth name"RSSIDOL H08", successfully connected you will hearing the "Connected" voice prompt for paring.

2): After connected the bluetooth, you can play any music on your smart devices anytime anywhere then.

### 2: How to using:

Follows picture for the product buttons instruction.



**1: Volume down/Previous song button.**

- 1) Long press will be change to previous song.
- 2) Short press will be volume down.

**2: Volume up/Next song button.**

- 1) Long press will be change to next song.
- 2) Short press will be volume up.

**3: Switch On/Off button.**

- 1) Long press of 3 second for Switch on/off.
- 2) Short press for Play/Pause. Short press for answer/hang up calls for phone.
- 3) Dual press for connect/disconnect previous connected smart devices.
- 4) Long press 1 second for reject coming calls.
- 5) Long press 8 second to get reset speaker.

**4: Mode button.**

- 1) Short press for mode change(Bluetooth, FM mode, TF card, USB mode).
- 2) Dual press for clear pairing devices.
- 3) Triple press for awake Google/Siri.
- 4) Long press for switch on/off original sound.

**5: Lights button.**

- 1) Long press for switch on/off RGB light.
- 2) Short press for switching different RGB lights effect.

**6: Type-c port/DC 5V charging port.**

1) Plug in USB-C cable to get charging.


**7: LED light indicator.**

1) There is red light on when you plug into charging, the red light will be off once full charged.

**8: TF card slot.**

**9: USB slot.**

**10: AUX/3.5mm port**



**1: Switch On/Off button.**

1) Long press of 3 second for Switch on/off.

2) Short press for reverb volume mode, mic volume mode, speaker volume mode, the user can increase of decrease the volume accordingly.

3) Dual press for Play/Pause.

**2: Volume up/Next song button.**

- 1) Long press will be change to next song.
- 2) Short press will be volume up (reverb, microphone, speaker mode).

**3: Volume down/Previous song button.**

- 1) Long press will be change to previous song.
- 2) Short press will be volume down (reverb, microphone, speaker mode).

**4: Microphone button.**

- 1) Short press for magic sound effect(There is totally 4 difference sound options)
- 2) Long press for original sound on/off.

**5: LED light indicator.**

- 1) There is red light on when you plug into charging, the red light will be off once full charged.

**FCC Caution:**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) The device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**FCC Statement:**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

**Thank you for your reading, hope you have a nice experience!**